

Legal Information

The information provided in this document contains general descriptions, technical characteristics and/or recommendations related to products/solutions.

This document is not intended as a substitute for a detailed study or operational and site-specific development or schematic plan. It is not to be used for determining suitability or reliability of the products/solutions for specific user applications. It is the duty of any such user to perform or have any professional expert of its choice (integrator, specifier or the like) perform the appropriate and comprehensive risk analysis, evaluation and testing of the products/solutions with respect to the relevant specific application or use thereof.

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this document are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owner.

This document and its content are protected under applicable copyright laws and provided for informative use only. No part of this document may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the document or its content, except for a non-exclusive and personal license to consult it on an "as is" basis.

Schneider Electric reserves the right to make changes or updates with respect to or in the content of this document or the format thereof, at any time without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this document, as well as any non-intended use or misuse of the content thereof.

Table of Contents

Safety Information	5
About the Book	7
Cybersecurity	9
Schneider Electric Guidelines.....	12
Introduction.....	16
Basics	16
Prerequisites, Installing, and Uninstalling the TeSys island DTM	
Library	18
Prerequisites	18
Installing the TeSys island DTM Library	19
Uninstalling the TeSys island DTM Library.....	24
User Interface.....	30
Launching the TeSys island DTM Library.....	30
Introduction to TeSys island DTM Library	35
Tool Bar, Status Bar, and Trip or Event Status.....	37
Tabs	40
MY ISLAND Tab.....	40
MY AVATAR Tab.....	45
Avatar	45
MY AVATAR	49
SETTINGS Tab	56
Introduction	56
System Avatar Settings.....	57
IO PORT ASSIGNMENT	63
Switch Avatar Settings	72
Analog I/O Avatar Settings	75
Load Avatar Settings.....	75
Application Avatar Settings.....	84
DIAGNOSTICS Tab.....	88
Introduction	88
AVATARS Tab	89

- DEVICES Tab 94
- COMPARE Tab 100
- Test Mode 103
- Force Mode..... 104
- ENERGY MONITORING Tab 106
- Control Panel..... 114
 - Overview 114
 - Control Panel Functions..... 114
- User Functions 118
 - Firmware Update 118
 - Customize Units..... 120
 - Import the TeSys island Configuration File..... 121
 - Import Custom Avatar..... 122
 - Export 123
 - Factory Reset 125
- Troubleshooting 126
- Index..... 129

Safety Information

Important Information

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.



WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.



CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

Please Note

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified personnel is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

About the Book

Document Scope

The purpose of this document is to help you to:

- Install and use different functions of TeSys island DTM Library configuration software.
- Configure the parameters of TeSys island .

Validity Note

This document has been updated with the release of SoMove software V2.9.4 or later version and TeSys island DTM Library V2.4.1 or later.

This instruction bulletin is valid for all TeSys island configurations. The availability of some functions described in the bulletin depends on the communication protocol used and the physical modules installed on theTeSys island.

For product compliance with environmental directives such as RoHS, REACH, PEP, and EOL, go to www.se.com/green-premium.

The technical characteristics presented in this online help should be the same as those that appear online. In line with our policy of constant improvement, we may revise content over time to improve clarity and accuracy. In the event that you see a difference between the online help and online information, use the online information as your reference.

Related Documents

Title of Documentation	Reference Number
TeSys island System, Installation, and Operation Guide	DOCA0270EN
TeSys island – EtherNet/IP™ – Quick Start and Function Block Library Guide	DOCA0271EN
TeSys island – PROFINET and PROFIBUS – Quick Start and Function Block Library Guide	DOCA0272EN
TeSys island – Functional Safety Guide	8536IB1904
TeSys island – Third Party Function Block Guide	8536IB1905
TeSys island – ATEX Adaptation Guide	DOCA0452EN

You can download these technical publications and other technical information from our website at www.se.com/ww/en/download/ .

Cybersecurity

Introduction

Cybersecurity is a branch of network administration that addresses attacks on or by PCs and through PC networks that can result in accidental or intentional disruptions. The objective of cybersecurity is to help provide increased levels of protection for information and physical assets from theft, corruption, misuse, or accidents while maintaining access for their intended users.

No single cybersecurity approach is adequate. Schneider Electric recommends a defense-in-depth approach. Conceived by the National Security Agency (NSA), this approach layers the network with security features, appliances, and processes. The basic components of this approach are:

- Risk assessment
- Security plan built on the results of the risk assessment
- Multi-phase training campaign
- Physical separation of the industrial networks from enterprise networks using a demilitarized zone (DMZ) and the use of firewalls and routing to establish other security zones
- System access control
- Device hardening
- Network monitoring and maintenance

This section defines elements that help you configure a system that is less susceptible to cyber attacks. For detailed information on the defense-in-depth approach, refer to the *Recommended Cybersecurity Best Practices* on the Schneider Electric website.

Schneider Electric's Approach on Cybersecurity

Schneider Electric adheres to industries best practice in the development and implementation of control systems. This includes a defense-in-depth approach to secure an industrial control system. This approach places the controllers behind one or more firewalls to restrict access to authorized personnel and protocols only.

 **WARNING**

UNAUTHENTICATED ACCESS AND SUBSEQUENT UNAUTHORIZED OPERATION

- Evaluate whether your equipment or complete environment are connected to your critical infrastructure and, if so, take appropriate steps in terms of prevention, based on defense-in-depth, before connecting the automation system to any network.
- Limit the number of devices connected to a network inside your company.
- Isolate your industrial network from other networks inside your company.
- Protect any network against unintended access by using firewalls, VPN, or other, proven security measures.
- Monitor activities within your systems.
- Prevent subject devices from direct access or direct link by unauthorized parties or unauthenticated actions.
- Prepare a recovery plan including backup of your system and process information.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Cyber Threats

Cyber threats are deliberate actions or accidents that can disrupt the normal operations of PCs and PC networks. These actions can be initiated from within the physical facility or from an external location. Security challenges for the control environment include:

- Diverse physical and logical boundaries
- Multiple sites and large geographic spans
- Adverse effects of security implementation on process availability
- Increased exposure to worms and viruses migrating from business systems to control systems as business-control communications become more open
- Increased exposure to malicious software from USB devices, vendor and service technician laptops, and the enterprise network

- Direct impact of control systems on physical and mechanical systems

Sources of Cyber Attacks

Implement a cybersecurity plan that accounts for various potential sources of cyber attacks and accidents, including:

Source	Description
Internal	• Inappropriate employee or contractor behavior • Disgruntled employee or contractor
External opportunistic (non-directed)	• Script kiddies⁽¹⁾ • Recreational hackers • Virus writers
External deliberate (directed)	• Criminal groups • Activists • Terrorists • Agencies of foreign states
Accidental	
⁽¹⁾ Slang term for hackers who use malicious scripts written by others without necessarily possessing a comprehensive understanding of how the script works or its potential impact on a system.	

A deliberate cyber attack on a control system may be launched to achieve a number of malicious results, including:

- Disrupt the production process by blocking or delaying the flow of information.
- Damage, disable, or shut down equipment to negatively impact production or the environment.
- Modify or disable safety systems to cause intentional harm.

How Attackers Gain Access

A cyber attacker bypasses the perimeter defenses to gain access to the control system network. Common points of access include:

- Dial-up access to remote terminal unit (RTU) devices
- Supplier access points (such as technical support access points)
- IT-controlled network products
- Corporate virtual private network (VPN)
- Database links
- Poorly configured firewalls
- Peer utilities

Reporting and Management

To submit a cybersecurity question, report security issues, or to get the latest news from Schneider Electric, visit our [Schneider Electric website](#).

Schneider Electric Guidelines

Introduction

Your PC can run a variety of applications to enhance security in your control environment. The system has factory default settings that require reconfiguration to align with Schneider Electric's device hardening recommendations of the defense-in-depth approach.

The following guidelines describe procedures in a Windows operating system. They are provided as examples only. Your operating system and application may have different requirements or procedures.

Disabling Unused Network Interface Cards

Verify that network interface cards not required by the application are disabled. For example, if your PC has two cards and the application uses only one, verify that the other network card (Local Area Connection 2) is disabled.

Perform the following steps to disable a network card in Windows:

Step	Action
1	Open Control Panel > Network and Internet > Network and Sharing Center > Change Adapter Settings .
2	Right-click the unused connection, and select Disable .

Configuring the Local Area Connection

Various Windows network settings provide enhanced security aligned with the defense-in-depth approach that Schneider Electric recommends.

In Windows systems, access these settings by opening **Control Panel > Network and Internet > Network and Sharing Center > Change Adapter Settings > Local Area Connection (x)**.

This list is an example of the configuration changes you might make to your system on the **Local Area Connection Properties** screen:

- Disable all IPv6 stacks on their respective network cards. (For example this PC doesnot require the IPv6 address range and disabling the IPv6 stacks limits vulnerability to potential IPv6 security risks.
- Disable **File and Print Sharing for Microsoft Network**.

Schneider Electric defense-in-depth recommendations also include the following:

- Define only static IPv4 addresses, subnet masks, and gateways.
- Do not use DHCP or DNS in the control room.

Managing Windows Firewall

Schneider Electric defense-in-depth approach recommendations include enabling the Windows host firewall on all PC. Enable the firewalls for any public or private profile listed.

It is recommended practice that users define firewall rules that refuse connections to or from any unknown or untrusted external host.

Disabling the Remote Desktop Protocol

Schneider Electric defense-in-depth approach recommendations include disabling remote desktop protocol (RDP) unless your application requires the RDP.

The following steps describe how to disable the protocol:

Step	Action
1	In Windows 2008R2 or Windows 7, disable RDP via Computer > System Properties > Advanced System Settings .
2	On the Remote tab, deselect the Allow Remote Assistance Connections to this Computer check box.
3	Select the Don't Allow Connection to this Computer check box.
4	In Windows 10, remote desktop protocol (RDP) is disabled using Settings > System > Remote Desktop > Enable Remote Desktop (Toggle to Off)

Updating Security Policies

Update the security policies on the PC by `gpupdate` in a command window. For more information, refer to the Microsoft documentation on `gpupdate`.

Disabling LANMAN and NTLM

The Microsoft LAN Manager protocol (LANMAN or LM) and its successor NT LAN Manager (NTLM) have vulnerabilities that make their use in control applications inadvisable.

The following steps describe how to disable LM and NTLM in a Windows system:

Step	Action
1	In a command window, execute <code>secpol.msc</code> to open the Local Security Policy window.
2	Open Security Settings > Local Policies > Security Options .
3	Select Send NTLMv2 response only. Refuse LM & NTLM in the Network Security: LAN Manger authentication level field.
4	Select the Network Security: Do not store LAN Manager hash value on next password change check box.
5	In a command window, enter <code>gpupdate</code> to commit the changed security policy.

Managing Updates

Before deployment, update all PC operating systems using the utilities on Microsoft's **Windows Update** web page. To access this tool in Windows, select **Start > All Programs > Windows Update**.

Workstation Protection

To reduce the security risks associated with the engineering workstation, enable the memory exploit settings such as Data Execution Prevention (DEP) and Address Space Layout Randomization (ASLR). These security settings can be enabled by using the system exploit protection settings in Windows 10 operating system. For more information, refer to the [Microsoft security features webpage](#).

Introduction

Basics

TeSys island is a modular, multifunctional system providing integrated functions inside an automation architecture, primarily for the direct control and management of low-voltage loads. TeSys island can switch, help protect, and manage motors and other electrical loads up to 80 A (AC1) or 65 A (AC3) installed in an electrical control panel.

This system is designed around the concept of TeSys avatars .

These avatars:


- Represent both the logical and physical aspects of the automation functions.
- Determine the configuration of the island.

The logical aspects of the TeSys island are managed with software tools, covering all phases of product and application lifecycle: design, engineering, commissioning, operation, and maintenance.

The physical TeSys island consists of a set of devices installed on a single DIN rail, and connected together with a flat cable providing the internal communication between modules. The external communication with the automation environment is made through a single bus coupler module, and the TeSys island is seen as a single node on the network.

The other modules include starters, power interface modules, analog and digital IO modules, voltage interface modules, and SIL interface modules, covering a wide range of operational functions.

TeSys island Overview



- A** Bus Coupler
- B** Analog I/O Module
- C** Digital I/O Module
- D** Voltage Interface Module
- E** Standard Starter
- F** SIL Starter
- G** SIL Interface Module
- H** Power Interface Module

DTM Overview

The DTM (Device Type Manager) is used together with FDT container (Field Device Tool container, also referred to as FDT frame) to commission and diagnose TeSys island. The combination of FDT and DTM is also called commissioning software.

Once a DTM is installed, it can be used by different FDT containers.

Examples of FDT containers:

- SoMove software(Schneider Electric)
- FDT CONTAINER (M&M Software GmbH)

Functions of the DTM

The functions of the DTM include:

- Scanning various fieldbuses for devices
- Device power and energy monitoring
- Management of configuration of device parameters
- Project file management
- Customization of device parameter units
- Troubleshooting

Prerequisites, Installing, and Uninstalling the TeSys island DTM Library

Prerequisites

Accessing the TeSys island DTM Library Software

The latest version of the TeSys island DTM Library software is available from the website www.se.com/en/download.

NOTE: You must have administrator rights to install or uninstall the TeSys island DTM Library software on your PC.

System Requirements

This software can be installed on the following operating system:

- Microsoft Windows 7 SP1 (32/64-bit) or
- Microsoft Windows 10

Software Requirements

The TeSys island DTM Library requires the following software installed on the PC:

- Microsoft .NET Framework v3.5 SP1
- SoMove v2.9.2 or later or FDT Frame Application compliant to the FDT standard v1.2.1
- Modbus DTM Library v2.6.12 or later

Hardware Requirements

Minimum hardware requirements are:

PC hardware	Specification
Processor	Pentium 4/Core 2 Duo, 2 GHz
RAM	2 GB

PC hardware	Specification
Hard disk space	1 GB of disk space must be available.
Display resolution	Resolution: 1024 x 768, 1366 x 768, 1600 x 1200 and 1920 x 1080 pixels. DPI: 96 (100%) and 120 (125%)

Recommended hardware requirements are:

PC hardware	Specification
Processor	Intel (R) Core (TM) i3
RAM	4 GB
Hard disk space	2 GB
Display resolution	Resolution: 1600 x 1200 and 1920 x 1080 pixels. DPI: 96 (100%) and 120 (125%)

Installing the TeSys island DTM Library

Overview



The TeSys island DTM Library is installed with the following file:



Schneider_Electric_TeSys_island_DTM_Library_V2.4.1.exe or later



This table describes the procedure to install the TeSys island DTM Library:

Step	Action
1	Verify that the hardware and software requirements mentioned in the section <i>Prerequisites</i> , page 18 are fulfilled.
2	Double-click the <i>Schneider_Electric_TeSys_island_DTM_Library_V2.4.1.exe</i> or later file.

Step	Action
3	Select the language of the software to be installed and click OK. Schneider Electric TeSys island DTM Library - InstallShield ...  Select the language for the installation from the choices below. English (United States) ✓ Chinese (Simplified) English (United States) French (Standard) German Italian Portuguese (Brazilian) Spanish Turkish
4	Click Next to start the installation process. Schneider Electric TeSys island DTM Library - 1.0.1303 Welcome to the Installation Wizard for Schneider Electric TeSys island DTM Library The Installation Wizard will install Schneider Electric TeSys island DTM Library on your computer. To continue, click Next.  < Back Next > Cancel

Step	Action
5	Click Release Notes to view product information or click Next. 
6	Read the license agreement carefully, and select I accept the terms in the license agreement option and click Next. 

Step	Action
7	Enter the required details in the Customer Information and click Next. 
8	Click Next to install in the selected path, or click Change... to select a different path for the installation. 

Step	Action
9	Click Install to start the installation. 
10	Click Finish to exit the installer. 

Uninstalling the TeSys island DTM Library


Overview


You can uninstall the TeSys island DTM Library via the setup (.exe) file or from the **Control Panel** in Windows.


Procedure



This table describes the procedure to uninstall the TeSys island DTM Library from the computer:

Step	Action
1	Close all instances of the FDT container running TeSys island DTM Library.
2	Select one of the following based on the operating system installed on the PC: - For Microsoft Windows 7, from the Microsoft Windows taskbar icon, click Start > Control Panel > Programs > Programs and Features. - For Microsoft Windows 10, from the Microsoft Windows taskbar icon, click Start → search. Type Control Panel. When the Control Panel appears, click Programs and Features. Select the TeSys island DTM Library file.
3	Right-click on the TeSys island DTM Library file and select Change .

Step	Action
	Result: The following screen appears. 
4	Click Next .

Step	Action
5	Select Remove and click Next. 
6	Click Next.

Step	Action
	 Admin privileges required Proceeding with the wizard demands administrator privileges, which are currently not active. In order to enable administrator privileges an operating system prompt will request the admin privileges and the wizard will be restarted. Click Next to enable administrator privileges.  < Back Next > Cancel Result: A message box appears, prompting you to confirm the administrator privileges.
7	Click Yes .

Step	Action
8	Click Remove to uninstall TeSys island DTM Library from your PC.  Result: A message box appears. 
9	Click Yes to confirm the removal of TeSys island DTM Library.
10	Click Finish to exit the installer.

Step	Action
	 Schneider Electric TeSys island DTM Library - 1.0 1303  Installation Wizard Completed The Installation Wizard has successfully uninstalled Schneider Electric TeSys island DTM Library. Click Finish to exit the wizard.  < Back Finish Cancel

User Interface

Launching the TeSys island DTM Library

Launching SoMove software

To create an instance of the TeSys island DTM Library, you need to first launch SoMove software.

You can open SoMove software in one of the following ways:

- Double-click the  icon located on the desktop.
- In Microsoft Windows 7 SP1, from the windows taskbar, go to **Start > All Programs > Schneider Electric > SoMove** and click the  icon.
- In Microsoft Windows 10, from the windows taskbar, click **Start** → search. Type SoMove. Click **SoMove** when it appears.

Creating an Instance of the TeSys island DTM Library

This table describes the procedure to create an instance of the TeSys island DTM Library:

Step	Action
1	Open SoMove software. Result: The following screen is displayed. ■ SoMove 2.7.6 Project Create a Project OFF-line Open a Project Connect Transfer (back-up / done configuration) Load from Device Store to Device Tools Edit Connection / Scan Import / Export Device Conversion Help Language English  schneider-electric/drives schneider-electric/servos schneider-electric/starters To view the installed DTM's, click here For more flexibility, the DTM libraries can now be downloaded and installed individually, independently of the SoMove software. The DTM's and the language packs are available at the following location.  SoMove Build Catalog  This Catalog has been modified, do you want to Update? OK Cancel
2	Click OK to update the catalog. NOTE: The Catalog window appears for the first time when you install the TeSys island DTM Library and launch SoMove.

Step	Action
3	Click Create a Project OFF-line. Result: The Select a Device screen appears. Select a Device  TeSys island Right click for rearrangement options  Update Select Communication Modbus TCP ▾ Create Cancel Help
4	Select TeSys island, and click Create. NOTE: The communication between TeSys island and DTM is through only Modbus TCP protocol irrespective of other fieldbus protocols. Result: The TeSys island DTM Library work area, <i>My island</i>, page 35 opens.

Connecting the Device on Network

This action retrieves the configuration of the connected device. SoMove software remains connected to this device during the session.

This table describes the procedure to connect to the device:

Step	Action
1	Open SoMove software.
2	You can use one of the following ways to connect to the device: - In the start page, click Edit Connection/Scan. - On the toolbar, click .


Step	Action
	On the menu bar, click Communication > Edit Connection/Scan. Result: The following screen appears. Scan Result Modbus Serial Modbus TCP Modbus IPV6 Remote gateway CANOpen Bluetooth TeSys island 192.168.10.50 Device Information:- Device: TeSys island Device Type: TeSysisland Reference: TPRBCEIP DTM-Version: 1.0.0 Selected Protocol: Modbus TCP Comm. Port: Address: 192.168.10.50 Scan Network Last Scan Date/Time 4/16/2019 11:07:24 AM Apply Connect Close
3	In the Scan Result dialog box, click Modbus TCP tab.
4	Click . Result: The following screen appears. Advanced Settings ModbusTCP Scan Settings Target Address: 192 . 168 . 10 . 1 Scan Type ☒ Single ☐ Range ☐ All More Help OK Cancel
5	In the Advanced Settings dialog box, enter the network address in the Target Address .
6	Select the Scan Type: Single: Scans a single address of one target device in the range from 0 to 255 of the specified network range. Range: Scans a specified address range from 0 to 255 in the defined network range. All: Scans the complete address range of the defined network range (all addresses from 0 to 255).

Step	Action
7	Click OK. Result: The modifications are saved and the Advanced Settings dialog box is closed. The new values will be applied at the next scan. NOTE: • If you click Cancel, the Advanced Settings dialog box closes without any changes and the default values are applied at the next scan. • You can click More to configure additional settings.
8	Click  in Scan Result dialog box. Result: Displays all the devices on the network with Modbus TCP connectivity.

Step	Action
9	Select the suitable TeSys island device and click Connect. Result: The following safety message appears. ▲WARNING UNINTENDED EQUIPMENT OPERATION TeSys island may perform unexpectedly in case of incorrect installation or setting. • Only appropriately trained persons who are familiar with and understand the content of all pertinent product documentation and who have received safety training to recognize and avoid the hazards involved are authorized to work on and with this system. • Verify that all used parameters and settings are suitable for the intended application. Failure to follow these instructions can result in death, serious injury, or equipment damage. ☐ I have read and fully understood these instructions and all pertinent product documentation. OK Cancel
10	When all the requirements of the safety message have been met, select the checkbox and click OK. Result: The TeSys island is connected to your computer. NOTE: If your computer is unable to establish the connection with the device: • Verify that the cable between the device and the computer is connected correctly. • Verify that the device is connected to the power supply. • Click the Advanced Setting button to verify that the connection parameters are defined correctly.

Introduction to TeSys island DTM Library

The TeSys island DTM Library contains the following:




- 1 Tool bar, page 37
- 2 Trip/Event status, page 39
- 3 Tabs, page 40
- 4 Status bar, page 37

For details on user functions of TeSys island DTM Library, refer to User Functions, page 118.

Tool Bar, Status Bar, and Trip or Event Status

Tool Bar




Item	Name	Description
1	Control Panel	Shows or hides the Control Panel bar. For more information, refer to Control Panel, page 114.
2	Refresh	Refreshes the data. When the DTM is in Online mode, the configuration parameters are loaded from the device and updated in the DTM.
3	Synchronization Status	Indicates the connection status of the device. The status bar is displayed with a color coding: • Device connected: Orange • Device not connected: Blue FULL-CONTROL: Indicates that you have full control of the island and can configure the parameters. READ-ONLY: Indicates that you do not have full control of the device and cannot modify the parameters. NOTE: • When the connection with the device is established for the first time, the DTM is in FULL-CONTROL mode. • When the device is already connected to another DTM instance or OMT, the DTM is in READ-ONLY mode. • When the other connection with the device is closed, the DTM changes to FULL-CONTROL mode automatically.

Status Bar

Online mode:




Offline mode:



Item	Name	Description
1	DTM connection	 Disconnected: The device is not connected.  Connected: The device is connected.  Disturbed: The connection with device has been lost.
2	Data source	 Data set: The parameter values in the data set can be modified in Online mode.  Data set or device locked: The device is protected in Online mode.  Device: The device data set contains information.  Device/Data set: All parameter values are stored to both data sources.
3	Pen icon	The parameter values have been changed in the data source.
4	Device status	 Detected event: The device has detected an event.  Device OK: The device is functioning properly.
5	Communication status	Shows the active communication protocol and the device network address.
6	Project status	Project Loaded: A project is displayed in the work area. No Project Open: The work area is empty NOTE: The project status is displayed in both Online and Offline modes.

Trip/Event Status



Item	Name	Description
1	Trip/Event	Displays the number of detected trips or events.
2	Alarm	Displays the number of detected alarms.

Tabs

MY ISLAND Tab

Overview

This tab displays the characteristics of the TeSys island and allows you to configure them.

NOTE: You can configure the characteristics of the **MY ISLAND** tab only when the device is not connected to the TeSys island (offline mode).

MY ISLAND Tab Description

MY ISLANDMY AVATARSETTINGSDIAGNOSTICSENERGY MONITORING

ISLAND CHARACTERISTICS

Name:

Max Width: 112.5 cm

Description:

Available Space:

92 %

Width: 9.5 cm

Weight: 0.86 kg

Heat Dissipation: 10.5 W

Power Supply Type:

Three Phase

Main Voltage:

380-415

 V

Mounting Direction:

Horizontal

Maximum Width:

112.5

 cm

Ambient Temperature:

< 50

 °C

▲

 ATEX Adaptation:

No

BILL OF MATERIALS

Position	Device Type	Name Tag	Reference	Avatar Num...	SIL Group
1	Bus Coupler - Ethernet Switch	Device1	TPRBCEIP	A1	
2	I/O Digital - 4 IN / 2 OUT	Device4	TPRDG4X2	A4	
3	Starter 4 kW	Device3	TPRST009	A2	
4	Starter 4 kW	Device2	TPRST009	A3	
5	SIL Starter 4 kW	Device5	TPRSS009	A5	1
6	SIL Interface	Device6	TPRSM001	A5	1

PHYSICAL VIEW



1

2

3

4

5

6

OK

Cancel

The **MY ISLAND** tab has the following sections:

- **ISLAND CHARACTERISTICS**
- **BILL OF MATERIAL**
- **PHYSICAL VIEW**

ISLAND CHARACTERISTICS

ISLAND CHARACTERISTICS

Name:

Description:

Power Supply Type:

Three Phase

Main Voltage:

380-415

 V

Mounting Direction:

Horizontal

Maximum Width:

112.5

 cm

Ambient Temperature:

< 50

 °C

ATEX Adaptation:

No

Max Width: 112.5 cm

Available Space: 92 %

Width: 9.5 cm

Weight: 0.86 kg

Heat Dissipation: 10.5 W

This table lists the characteristics of the island:

Characteristics	Description
Name	Enter the name of the TeSys island.
Description	Enter the description.
Power Supply Type	Select the type of power supply from the drop-down list. Supply type: Single Phase or Three Phase .
Main Voltage	Select the main voltage of the TeSys island from the drop-down list. NOTE: The main voltage values depend on the Power Supply Type selected and the Customized Units , page 120 for motor rating.
Mounting Direction	Select the mounting direction of the device (Horizontal or Vertical). NOTE: If the ambient temperature exceeds 50 °C or if Vertical mounting is selected, the derating factor is accounted for in the starter selection.
Maximum Width	Set the maximum width of the TeSys island. Range: 7.5 cm to 112.5 cm
Ambient Temperature	Select the ambient temperature from the drop-down list. Range: <50 °C or ≥50 °C
Max Width	Displays the maximum width which you have set.
Available Space	Displays the available space on the TeSys island.

Characteristics	Description
	NOTE: The available space is calculated based on the width, energy consumption, size of input dataset* and number of modules on the island. NOTE: * indicates that it is applicable for Profibus protocol only.
Width	Displays the total width of the configured devices on the TeSys island.
Weight	Displays the total weight of the configured devices on the TeSys island.
Heat Dissipation	Displays the total heat dissipation of the configured devices on the TeSys island.
ATEX Adaptation	Configure ATEX Adaptation as Yes or No for TeSys island. NOTE: For more information on ATEX Adaptation for TeSys island, refer to TeSys island ATEX Adaptation Guide – DOCA0452EN and TeSys island System, Installation, and Operation Guide – DOCA0270EN

ATEX Adaptation

Configuring the ATEX Adaptation as yes for TeSys island displays the following danger message:

DANGER

FIRE HAZARD

- Enabling ATEX Adaptation disables Motor Overheat, Thermal Overload and Current Phase Loss protections at the island level.
- In ATEX environment, it is mandatory to use ATEX-certified TeSys GV series Motor Protection Circuit Breaker before enabling this configuration.
- In non ATEX environment, it is strictly forbidden to enable this configuration.
- Make sure the right Motor Protection Circuit Breaker is selected as per the TeSys island ATEX Adaptation Guide.
- Make sure the Motor Protection Circuit Breaker is configured with right protection setting with respect to load.
- Make sure to use one Motor Protection Circuit Breaker per motor for protection.
- Make sure to read, understand, and apply the information provided in the ATEX instruction sheet for the ATEX-certified MPCBs.
- ATEX-certified MPCBs and TeSys island system must be installed outside the explosive (ATEX) zone.
- Using TeSys island without associating it as above mentioned with a right Motor Protection Circuit Breaker and without enabling this ATEX adaptation to protect motors installed in an ATEX environment is strictly prohibited.

Failure to follow these instructions will result in death or serious injury.

☒ I have read and fully understood these instructions and all related product documentation.

OK

Cancel

A message is displayed under the **ISLAND CHARACTERISTICS** section after configuring the ATEX Adaptation as yes.

ISLAND CHARACTERISTICS

Name:

Description:

Max Width: 112.5 cm

Available Space: 92 %

Width: 9.5 cm

Weight: 0.86 kg

Heat Dissipation: 10.5 W

Power Supply Type:

Three Phase

Main Voltage:

380-415

 V

Mounting Direction:

Horizontal

Maximum Width:

112.5

 cm

Ambient Temperature:

< 50

 °C

ATEX Adaptation:

Yes

ATEX Adaptation is configured as Yes
(Disables: avoid Thermal Overload Protection,
Current Phase Loss and Motor Overheat
Protection)

Under the **SETTINGS** tab, internal protection such as thermal overload, current phase loss, and motor overheat are disabled and a tool tip with the message **ATEX Adaptation is Enabled** is displayed.

MY ISLAND

MY AVATAR

SETTINGS

DIAGNOSTICS

EMERGENCY STOP SETTINGS

Default PMS

AVATARS

TeSys
Microsyst

Enter the description
of the avatar

GENERAL SETTINGS

CONTROL MODE

FLA

Control Mode Selection:

Remote Control Mode

THERMAL PROTECTION

Thermal Overload Trip

Disable

Trips Class:

10

Reset Timeout:

30

 s

Thermal Overload Alarm:

Enable

Overload Alarm Level:

85

 %

ELECTRICAL PROTECTION

CURRENT PHASE LOSS

GROUNDING CURRENT DETECTION

CURRENT PHASE UNBALANCE

PHASE REVERSAL

Current Phase Loss Trip:

Disable

Current Phase Loss Trip Delay:

0

 s

Current Phase Loss Trip Level:

80

 %

8536IB1907-07

43

BILL OF MATERIAL

The bill of material displays the devices and accessories configured on the TeSys island.

Based on the avatar type and the reference numbers of the devices selected to compose the island, the related accessories will be included in bill of material.


BILL OF MATERIAL					
Position	Device Type	Name Tag	Reference	Avatar Number	SIL Group
1	Bus Coupler - Ethernet Switch	Device1	TPRBCEIP	A1	
2	I/O Digital - 4 IN / 2 OUT	Device4	TPRDG4x2	A3	
3	SIL Starter 4 kW	Device2	TPRSS009	A2	1
4	SIL Interface	Device3	TPRSM001	A2	1
5	Starter 4 kW	Device5	TPRST009	A4	
6	Starter 4 kW	Device6	TPRST009	A4	

Characteristics	Description
Position	Displays the position of the device on the bus.
Device Type	Displays the type of device along with the number of I/Os and the voltage and current ratings of the device.
Name Tag	Displays the tag name configured for the device.
Reference	Displays the reference of the selected device or accessory.
Avatar Number	Displays the avatar number which is associated with the device or accessory.
SIL Group	Displays the SIL group number of the SIL avatar.

PHYSICAL VIEW

This section displays the physical view of the devices configured on the TeSys island, along with the position of each device on the bus.

NOTE: You can double click on the device image to navigate to the associated avatar in **My Avatar** tab.



MY AVATAR Tab

Avatar

Introduction

Avatars are digital representations of the physical modules on the TeSys island.

There are three types of TeSys island avatars:

- **System**

A single avatar representing the entire island provides communication and management of the TeSys island. The **System** avatar does not directly provide load control or protection functions as the **Device** and **Load** avatars do.

- **Device**

Device avatars provide the functionality of a single module used in the island, such as a starter or an I/O module.

- **Load**

Load avatars provide functionality specific to different load types, by including multiple modules on the island in a single avatar. When load avatars are used, the island applies the appropriate number of modules, types of modules, and operating characteristics to serve the load type.

For example, a forward-reverse motor avatar includes a forward starter, a reverse starter, and pre-programmed forward-reverse operating logic.

- Application

Application avatars provide the functionality specific to different application types, by including multiple modules on the island in a single avatar. When application avatars are used, the island applies the appropriate number of modules, types of modules, and operating characteristics to serve the application type.

For example, a pump avatar includes a digital input output module, a starter and pre-programmed operating logic.

List of Avatars

This table lists the available avatars and their descriptions:

Name		Icon	Description
System Avatar			A required Avatar that enables a single point of communication to the island.
Device Avatars	Switch		To make or break a power line in an electrical circuit.
	Switch - SIL Stop, W. Cat 1/2		To make or break a power line in an electrical circuit with Stop category 0 or Stop category 1, wiring category 1 and category 2. Stop category 0 or Stop category 1 is according to IEC 60204-1.
	Switch - SIL Stop, W. Cat 3/4		To make or break a power line in an electrical circuit with Stop category 0 or Stop category 1, wiring category 3 and category 4. Stop category 0 or Stop category 1 is according to IEC 60204-1.
	Digital I/O		To provide control of 2 digital outputs and the status of 4 digital inputs.
	Analog I/O		To provide control of 1 analog output and the status of 2 analog inputs.
Load Avatars	Power Interface without I/O (measure)		To monitor current supplied to an external device, such as a solid-state relay, soft starter, or variable speed drive.
	Power Interface with I/O (control)		To monitor current supplied to an external device and to control the external device, such as a solid-state relay, soft starter, or variable speed drive.
	Motor One Direction		To manage a motor in one direction.
	Motor One Direction - SIL Stop, W. Cat 1/2		To manage a motor in one direction, with Stop category 0 or Stop category 1, wiring category 1 and category 2. Stop category 0 or Stop category 1 is according to IEC 60204-1.

Name		Icon	Description
	Motor One Direction - SIL Stop, W. Cat 3/4		To manage a motor in one direction, with Stop category 0 or Stop category 1, wiring category 3 and category 4. Stop category 0 or Stop category 1 is according to IEC 60204-1.
	Motor Two Directions		To manage a motor in two directions (forward and reverse).
Load Avatars	Motor Two Directions - SIL Stop, W. Cat 1/2		To manage a motor in two directions (forward and reverse), with Stop category 0 or Stop category 1, wiring category 1 and category 2. Stop category 0 or Stop category 1 is according to IEC 60204-1.
	Motor Two Directions - SIL Stop, W. Cat 3/4		To manage a motor in two directions (forward and reverse), with Stop category 0 or Stop category 1, wiring category 3 and category 4. Stop category 0 or Stop category 1 is according to IEC 60204-1.
	Motor Y/D One Direction		To manage a wye/delta (star/delta) motor in one direction.
	Motor Y/D Two Directions		To manage a wye/delta (star/delta) motor in two directions (forward and reverse).
	Motor Two Speeds		To manage a two-speed motor.
	Motor Two Speeds - SIL Stop, W. Cat 1/2		To manage a two-speed motor, with Stop category 0 or Stop category 1, wiring category 1 and category 2. Stop category 0 or Stop category 1 is according to IEC 60204-1.
	Motor Two Speeds - SIL Stop, W. Cat 3/4		To manage a two-speed motor, with Stop category 0 or Stop category 1, wiring category 3 and category 4. Stop category 0 or Stop category 1 is according to IEC 60204-1.
	Motor Two Speeds Two Directions		To manage a two-speed motor in two directions (forward and reverse).
	Motor Two Speeds Two Directions - SIL Stop, W. Cat 1/2		To manage a two-speed motor in two directions (forward and reverse), with Stop category 0 or Stop category 1, wiring category 1 and category 2. Stop category 0 or Stop category 1 is according to IEC 60204-1.
	Motor Two Speeds Two Directions - SIL Stop, W. Cat 3/4		To manage a two-speed motor in two directions (forward and reverse), with Stop category 0 or Stop category 1, wiring category 3 and category 4. Stop category 0 or Stop category 1 is according to IEC 60204-1.
	Resistor		To manage a resistive load.
	Power Supply		To manage a power supply.

Name		Icon	Description
	Transformer		To manage a transformer.
Application Avatars	Pump		- To energize a motor attached to a pump. - To provide electrical protection and motor overload protection. Additional functions: - To detect cavitation and jam. - To avoid repetitive restart.
	Conveyor		- To energize a motor attached to a 1-direction conveyor. - To provide electrical protection and motor overload protection. Additional function: - To detect stall, long start and jam.
	Conveyor One Direction - SIL Stop, W. Cat 1/2		- To energize a motor attached to a 1-direction conveyor. - To provide electrical protection and motor overload protection. - To perform SIL Stop by removing the energy applied to the motor. Additional function: - To detect stall, long start and jam.
	Conveyor Two Directions		- To energize a motor attached to a two-direction conveyor. - To provide electrical protection and motor overload protection. Additional function: - To detect stall, long start and jam.
	Conveyor Two Directions - SIL Stop, W. Cat 1/2		- To energize a motor attached to a two-direction conveyor. - To provide electrical protection and motor overload protection. - To perform SIL Stop by removing the energy applied to the motor. Additional function: - To detect stall, long start and jam.
NOTE: W. Cat refers to wiring category.			

MY AVATAR


Overview

This tab allows you to modify the island topology. You can add, remove, configure, and reorder the avatars.

NOTE: You can modify the parameters of **MY AVATAR** tab only when the device is not connected to the TeSys island (offline mode).

MY AVATAR Tab Description

The following illustration is an example of the **MY AVATAR** tab:



- 1 Island space, page 50
- 2 Avatar list, page 51
- 3 Save custom avatar, page 51
- 4 Rearrange Avatar(s), page 51
- 5 Add avatar, page 51
- 6 Avatar parameters, page 52
- 7 Device parameters, page 56

Island Space

The TeSys island space displays the available space on the TeSys island DTM Library.

The available space changes when you:

- Add avatars to or delete them from the TeSys island.
- Modify the device references.

- Enable or disable additional devices on the TeSys island.

Avatar List

Displays the list of the avatars added in the TeSys island DTM Library.

NOTE:

- You can drag and drop the avatar to a required position (this will change the TeSys island topology).
- In avatar list, you can click  icon to delete the avatar from the TeSys island DTM Library.

Save Custom Avatar


Saves the selected customized avatars in the TeSys island DTM Library.

Rearrange Avatar(s)

This option helps the user to automatically try and resolve the warnings like Electromagnetic Interference and Mounting Positions by rearranging the position of avatars.

Add Avatar

You can add the avatars of the TeSys island DTM Library. You can also search for a required avatar based on the name of the avatar entered.

Step	Action
1	In the My Avatar tab, click Add Avatar. Result: The Add Avatar screen appears. 
2	Select the avatar from the DEVICE tab or the LOAD tab or APPLICATION tab and click Add. Result: The new avatar is added in the avatar list. NOTE: Click the ☆ icon to add frequently used avatars in the FAVORITES tab. The customized avatars appears in the CUSTOM tab.

For more details, refer to [List of Avatars](#), page 46.

AVATAR PARAMETERS

The **Avatar Parameters** section shows the parameters of the avatar based on the type of avatar you have selected. It also allows you to modify the parameters of the selected avatar.

NOTE: The list of parameters described below depends on the selected avatar.

Parameters	Description
Avatar Name	Enter name of the avatar.
Fieldbus Protocol	Select the protocol for communication with the devices.
Power Supply Type	Select the type of power supply from the drop-down list.
Upstream Voltage	Select the upstream voltage from the drop-down list.
Rating power	Select the power rating from the drop-down list.
Rating current	Select the current rating from the drop-down list.
Type Of Utilization	Select the type of utilization of a device from the drop-down list:

Parameters	Description
	• Start/Stop: Starts or stops the motor. • Plugging: Breaks the motor. • Inching: Runs the motor at low speed. • Resistor⁽¹⁾: Controls non-inductive or slightly inductive loads. • Power Supply⁽¹⁾: Controls capacitor bank switching. • Transformer⁽¹⁾: Controls transformer switching. • Compressor⁽¹⁾: Controls compressor motor switching with automatic reset of overload release. NOTE: ⁽¹⁾ This category is available only for Switch, Switch - SIL Stop, W. Cat 1/2 and Switch - SIL Stop, W. Cat 3/4 avatars.
PV Inputs Nb	Select the number of PV inputs from the drop-down list.
PV Switches Nb	Select the number of PV switches from the drop-down list.
Individual Short-Circuit Protection	Select the type of short-circuit protection of a device from the drop-down list: • Yes: Short circuit protection applied. • No: No short-circuit protection applied. • Coordination Type 1: Under short circuit conditions, the contactor or starter shall cause no danger to person or installation and may not be suitable for further service without repair and replacement of parts. • Coordination Type 2: Under short circuit conditions, the contactor or starter shall cause no danger to person or installation and shall be suitable for further use. The risk of contact welding is recognized, in which case the manufacturer shall indicate the measures to be taken in regards to equipment maintenance. NOTE: • The possible values depend on the type of power unit selected: ◦ If the power unit selected is kW, possible values are No, Coordination Type 1, and Coordination Type 2. ◦ If the power unit selected is hp, possible values are No and Yes. • The short circuit protection ratings are optimized for the TeSys™ GVL circuit breakers (for more details, refer to <i>TeSys™ Catalog</i>). • The GV circuit breakers are not recommended to be used with TeSys island for loads exceeding trip class 15.
Load Energy Monitoring For conditions to enable Load Energy Monitoring , refer to Conditions for Enabling Load Energy Monitoring Parameter, page 55.	Enable energy monitoring, which monitors the amount of voltage, power, and energy consumption of the load. If enabled, a voltage interface module is added in the island. NOTE: TeSys island has only one voltage interface module even if you have enabled load energy monitoring function in multiple avatars. For more details, refer to ENERGY MONITORING Tab, page 106.

Parameters	Description
Temperature Sensor Available	Enable functions using the motor temperature sensor. If enabled, an analog I/O module is added in the TeSys island.
SIL Group	Enter the SIL group number for the SIL avatar. You can have multiple SIL avatars within a SIL group. Range: 1 to 10
Local Control Enabled	Select Yes to enable the local control mode.
Local Trip Reset	Select Yes to enable the local trip reset. If enabled, a digital I/O module (DIOM) is added in the island. NOTE: • If both Local Control Enabled and Local Trip Reset Enabled are enabled, then Local Control Enabled and Local Trip Reset Enabled will be listed in one DIOM module. • Digital input 4 will be assigned to Local Trip Reset. If digital input 4 is occupied for PvSwitch 1, which is mandatory in few applications, such as Pump avatar, then new DIOM module will be added and the first input of the new DIOM module will be used for Local Trip Reset Enabled.

Parameters	Description
Dahlander Control Enabled	Select Yes to enable the Dahlander control mode. NOTE: This parameter is available for only Motor Two Speeds avatar. Disabled (Default setting)
Fallback Mode	When TeSys island is in degraded mode and no command is active, then configure the states for Starters, SIL Starters, or Outputs as On, Off, or Hold. For more information, refer <i>System state</i> section page 144 in TeSys island-System, Installation and Operation guide. When user select On option, below warning message will display. ⚠ WARNING UNINTENDED EQUIPMENT OPERATION In the event of communication loss and no local command, Fallback Mode 'On' directs island to 1. 'On' the logic state of avatar 2. 'On' the unassigned outputs of digital IO module 3. 'Hold' the unassigned outputs of analogue IO module Failure to follow these instructions can result in death, serious injury, or equipment damage. OK Cancel When user select Hold option, below warning message will display. ⚠ WARNING UNINTENDED EQUIPMENT OPERATION In the event of communication loss and no local command, Fallback Mode 'Hold' directs island to 1. 'Hold' the logic state of avatar 2. 'Hold' the unassigned outputs of digital IO module 3. 'Hold' the unassigned outputs of analogue IO module Failure to follow these instructions can result in death, serious injury, or equipment damage. OK Cancel

Conditions for Enabling the Load Energy Monitoring Parameter

Power Supply Type		Load Energy Monitoring
Island	Avatar	
Three Phase	Three Phase	Can enable the function, if the island and the avatar voltage values are the same.
Three Phase	Single Phase	Can enable the function.

Power Supply Type		Load Energy Monitoring
Island	Avatar	
Single Phase	Single Phase	Can enable the function, if the island and the avatar voltage values are the same.
Single Phase	Three Phase	Cannot enable the function.

DEVICE PARAMETERS


The **Device Parameters** section displays the physical representation of the module along with its position on TeSys island. This section also displays the characteristics of the selected avatar with an option to configure the tag name and product reference.

Parameters	Description
Name Tag	Enter the name tag of the device.
Product Code	Displays the sized Reference in accordance with the rating selected. You can select higher references for heavy duty performance needs.
Utilization Category ¹	Displays the utilization category of the device.
Firmware Version	Displays the firmware version of the bus coupler.
Hardware Version	Displays the firmware version of the hardware.
⁽¹⁾ This parameter is not available for the System avatar, Digital I/O avatar, Analog I/O avatar, Power Interface avatar, and Power Interface with I/O avatar.	

SETTINGS Tab

Introduction

In the **SETTINGS** tab, you can configure the parameters of the selected avatars. You can modify the parameter value in offline or online mode. In online mode, when you click **OK**, the DTM writes the set parameter value to the connected island.



- Avatar list, page 57
- Display area, page 57

Avatar List

Displays the list of the avatars added in the TeSys island.

Display Area

A display area on the right side shows the group of parameters of the avatar selected in avatar list.

System Avatar Settings


Overview

You can configure the parameters linked to the network and configuration ports of the **System** avatar.

The settings of the **System** avatar are grouped as follows:

- Fieldbus, page 58
- Ethernet services, page 60
- System settings, page 62
- IO Port Assignment, page 63

The following illustration is an example of the **System** avatar settings:



FIELDBUS

Section	Setting	Description
START-UP	Product Code	Displays the product reference of a system avatar.
	DCP Override ⁽³⁾	Indicates when the controller is using the DCP addressing mechanism to configure the bus coupler, which can override the IP address settings such as Fieldbus IPv4 Address , Fieldbus Subnet Mask , Gateway Address , and Network Name .
	IP Address NOTE: You must restart the device to activate the modified IP settings.	IP address is defined based on the IP Mode selected.
	Fieldbus MAC Address 1	Displays the MAC address of fieldbus Ethernet port 1.
	PROFINET Station Name ⁽³⁾	Enter the name which identifies the device on the PROFINET network.

Section	Setting	Description
	Profibus Node ID ⁽⁴⁾	Enter the number which identifies the device on the PROFIBUS network.
	IP Mode	Select the IP mode from the list: • Fixed Address: When this option is selected, you can type the address into the Fieldbus IPv4 Address, Fieldbus Subnet Mask, and Gateway Address fields. • BOOTP: When this option is selected, the device obtains the IP address from BOOTP server. • DHCP: When this option is selected, the device obtains the IP address from the DHCP server.
	Network Name	Enter the network name.
	Fieldbus IPv4 Address ⁽¹⁾	Enter the fieldbus IPv4 address.
	Fieldbus Subnet Mask ⁽¹⁾	Enter the fieldbus subnet mask address.
	Gateway Address ⁽¹⁾	Enter the gateway address.
PROTOCOL	Fieldbus Protocol	Displays the selected Fieldbus Protocol .
	Unit ID ⁽²⁾	Displays the Modbus TCP unit ID.
	Fallback Management	Displays how the fallback behavior of the system is managed during a communication interruption with the controller.
LOGIC CONTROLLER	Client (PLC) IP Address	Enter the IP address of the Modbus client device connection which is controlling the island (mainly a PLC).
	Modbus Client Port	Enter the port of the Modbus client device connection which is controlling the island (mainly a PLC).
	Enable Modbus Client	Enable or disable the exempting of the client IP connection from the Modbus servers Least Recently Used (LRU) connection management algorithm.
	Enable Degraded Mode Auto-Reset	Enable or disable the auto degraded reset mode, which automatically exits from degraded mode when communication is restored.
	Communication Loss Timeout	Set the communication loss timeout value for Field bus Protocol .
⁽¹⁾ This parameter can be configured when IP Mode is Fixed Address. ⁽²⁾ This parameter is displayed for Modbus TCP Fieldbus Protocol. ⁽³⁾ This parameter is displayed for PROFINET Fieldbus Protocol. ⁽⁴⁾ This parameter is displayed for PROFIBUS-DP Fieldbus Protocol.		

ETHERNET SERVICES

You can configure the following Ethernet services:

- **SNMP:** Simple Network Management Protocol (SNMP) is an internet-standard protocol for managing devices on IP networks. It is used for monitoring devices connected to the network.
- **SNTP:** Simple Network Time Protocol (SNTP) is a time maintenance application that allows you to synchronize the time of devices connected to the network.
- **RSTP:** Rapid Spanning Tree Protocol (RSTP) provides event tolerance if any active links fail and provides recovery through cable redundancy.
- **FDR:** The FDR (Fast Device Replacement) service allows automatic reconfiguration of a new device installed to replace an existing device.

 **WARNING**

POTENTIAL COMPROMISE OF SYSTEM AVAILABILITY, INTEGRITY, AND CONFIDENTIALITY
Change default SNMP community names to help prevent unauthorized access to device.
Failure to follow these instructions can result in death, serious injury, or equipment damage.

Section	Setting		Description
SNMP		SNMP	Enable: Enables SNMP service. Disable: Disables SNMP service. NOTE: By default, SNMP is disabled.
	Manager's IP Address	Manger 1	Enter the IP address of SNMP Manger 1 . NOTE: SNMP manager is a central system, which is used for monitoring and controlling the SNMP agents.
		Manger 2	Enter the IP address of SNMP Manager 2 .
	Agent	System Location	Enter the location of the system.
		System Contact	Enter the system contact. NOTE: System Contact is a contact point to get the information about the system.
	Community Name	Get	Requests are sent from SNMP manager to agent to retrieve the data. NOTE: The default value is public . For better security, it is recommended

Section	Setting		Description
			to change the default community name.
		Set	Requests are sent from SNMP manager to agent to change the data. NOTE: The default value is private . For better security, it is recommended to change the default community name.
		Trap	Requests are sent from SNMP manager to agent to find the available data. NOTE: The default value is alert . For better security, it is recommended to change the default community name.
SNTP	SNTP Configuration	SNTP	Enable: Enables SNTP service. Disable: Disables SNTP service.
		Primary SNTP Server Address	Enter the IP address of the primary SNTP server.
		Secondary SNTP Server Address	Enter the IP address of the secondary SNTP server.
		Polling Period	Select the scanning interval for checking the time change.
RSTP	RSTP Enable NOTE: You must restart the device to activate the modified settings.		Enable or Disable the RSTP service.
	RSTP Operation State	Bridge Identifier Priority	Select the priority from the dropdown list. NOTE: The bridge priority is a 2-byte value for the switch, used to establish the relative position of the switch in the RSTP hierarchy.
FDR ⁽¹⁾ NOTE: You can enable FDR only if the IP Mode selected is DHCP .	Device FDR Function Start-up Control	FDR Enable	Select Yes to enable or No to disable the FDR service.
	Device FDR Scheduling	FDR Synchronization Enable	Select Yes to enable FDR synchronization, which sends the device configuration data to the FDR server at regular time intervals.
		FDR Synchronization Period	Set the time interval for automatic synchronization.
(1) This parameter is displayed for EtherNet/IP and Modbus TCP Fieldbus Protocol .			

SYSTEM SETTINGS

Section	Setting	Description
SETTINGS	Force Mode Data Retention	Enable or Disable the force mode data retention. When enabled, the bus coupler retains force mode data (force mode commands to avatar inputs and outputs) during a power cycle or system restart. When disabled, the bus coupler does not retain force mode data during a power cycle or system restart.
POWER VOLTAGE NOTE: The Power Voltage settings are displayed in settings tab if you have enabled the Load Energy Monitoring option for a selected avatar. To enable, go to My Avatar tab → Avatar Parameters > Load Energy Monitoring and select Yes .	Voltage Dip Level	Set the voltage dip level.
	Voltage Swell Level	Set the voltage swell level.


IO PORT ASSIGNMENT

For more details, refer to IO PORT ASSIGNMENT, page 63.

IO PORT ASSIGNMENT

The **IO PORT ASSIGNMENT** section displays the ports assigned to the I/O of the avatar and the trip status of the motor.

The following illustration is an example of the **IO PORT ASSIGNMENT** section:



Name	Description
Avatar Name	Displays the name of the avatar. NOTE: The field is not editable in SETTINGS page. The name is taken from My Avatar tab.
I/O Name	Displays the analog input/output and digital input/output along with the starter auxiliary contact. NOTE: This field is not editable.
I/O Device Name	Displays the name of the input/output device DIOM/ AIOM. NOTE: The user can select the assigned I/O device in the avatar from the drop-down menu.
I/O Number	Displays the name of the input/output number. NOTE: The user can select the assigned input/output number in the avatar from the drop-down menu.
Value	Displays the value. NOTE: The value is updated with the real value if the TeSys island is in online mode.
Fallback Mode	Displays the Fallback Mode configured for the IO module.

I/O Module Assignment to Multiple Avatars

Digital I/O modules TPRDG4X2 or analog I/O modules TPRAN2X1 can be assigned to multiple avatars. Refer to [IO Optimization](#), page 64.

NOTE: Only analog module can be assigned to power interface avatar.

The number of analog I/O modules added to TeSys island is based on the number of PV inputs and temperature sensor configured in avatars.

The number of digital I/O modules added to TeSys island is based on the number of PV switches and the configuration of **Local Control Enabled** or **Local Trip Reset Enabled** selected in the avatars.

NOTE: I/O modules assigned to application avatars as part of default configuration cannot be removed. If application avatar is removed, then the I/O module also gets deleted. The I/O added as part of PV switch/PV input can be optimized.

IO Optimization

The unused I/O port of one avatar can be used by another avatar using **IO Optimization** feature. The user can click the **IO Optimization** button to optimize the I/O port assignment and to store the TeSys island configuration.

The following illustration is an example of the **IO Optimization** section:

MY ISLAND

MY AVATAR

SETTINGS

DIAGNOSTICS

ENERGY MONITORING

AVATARS

system
AvSystem01

Motor One Direction
AvOneDirection02

Motor Two Directions
AvTwoDirection03

Digital IO
AvDigitalIO04

A1

A2

A3

A4

FIELDBUS

ETHERNET SERVICES

SYSTEM SETTINGS

IO PORT ASSIGNMENT

Avatar Name	I/O Name	I/O Device Name	I/O Number	Value
AvOneDirection02	LoadCurrent	Not Assigned	Not Assigned	0 A
AvOneDirection02	AvtStatusThOverTrip	Not Assigned	Not Assigned	Off
AvOneDirection02	AvtStatusJamTrip	Not Assigned	Not Assigned	Off
AvOneDirection02	AvtStatusLongStTrip	Not Assigned	Not Assigned	Off
AvOneDirection02	AvtStatusStallTrip	Not Assigned	Not Assigned	Off
AvOneDirection02	BypassCommand	Device3	10	Off
AvOneDirection02	LocalForwardCommand	Device3	11	Off
AvOneDirection02	ManualModeOverride	Device3	12	Off
AvOneDirection02	Device2 AUX Contact	Not Assigned	Not Assigned	Off
AvTwoDirection03	LoadCurrent	Not Assigned	Not Assigned	0 A
AvTwoDirection03	AvtStatusThOverTrip	Not Assigned	Not Assigned	Off
AvTwoDirection03	AvtStatusJamTrip	Not Assigned	Not Assigned	Off
AvTwoDirection03	AvtStatusLongStTrip	Not Assigned	Not Assigned	Off
AvTwoDirection03	AvtStatusStallTrip	Not Assigned	Not Assigned	Off
AvTwoDirection03	Local TripReset	Device6	10	Off
AvTwoDirection03	Device4 AUX Contact	Not Assigned	Not Assigned	Off
AvTwoDirection03	Device5 AUX Contact	Not Assigned	Not Assigned	Off

Device Optimization

IO Optimization

Apply

Cancel

Save

The **IO Optimization** button will run the below algorithm:

If the algorithm detects the number of unused I/O point greater or equal to the maximum number of I/O point of an I/O module, it starts optimization.

For example:

- **Scenario 1:** Detecting 4 or more unused digital inputs and 2 or more digital outputs - minimum one DIOM can be removed.
- **Scenario 2:** Detecting 2 or more unused analog inputs and 1 or more analog outputs - minimum one AIOM can be removed.

If scenario 1 or scenario 2 is true, then the algorithm will fill up the configured logical I/O to the physical I/O in the order of the avatar configuration.

The user must confirm, by clicking the **Apply** button to save the configuration or click **Cancel** to discard the configuration.

If **IO Optimization** is not possible with the selected port options, a pop-up message will appear.

The unused I/O modules that has to be removed from the avatar configuration will be added as device avatar to the configuration.

NOTE:

- For IO PORT ASSIGNMENT, device avatar need to move top of all load or application avatar
- First avatar parameters are to be configured and then IO optimization or device optimization must be performed. Whenever there is a change in the avatar parameters the IO PORT ASSIGNMENT should be rechecked before proceeding for IO optimization.

Device Optimization

The device optimization feature, helps the user to update the TeSys island configuration by removing the unused I/O modules. By clicking the **Device Optimization** option, the unused I/O devices will be removed from the TeSys island configuration.

NOTE: Device Optimization algorithm will run independently of **IO Optimization** and it is completely optional for a user.

During offline mode, the user can download the updated TeSys island configuration by clicking **Store to device** option.

Auxilliary Contact Listing in IO PORT ASSIGNMENT

The auxiliary contact information of each configured starter of an avatar can be assigned to digital output only and shown in **IO PORT ASSIGNMENT** table.

Auxiliary contact status can be configured or selected to only digital outputs of DIOM module or not assigned to any module.

These logical I/O by default will not be assigned to any digital output; user must manually assign to any unused digital output.

When there are multiple auxiliary contact status assigned to a single output, then output will be triggered if any of the input is high.

If there are not enough unused I/O points for the status information, the user wants to assign an I/O point and then add I/O device or I/O **Device** avatar to the main configuration.

NOTE: For the Auxilliary contact, DIOM (Q0, Q1) are available for selection in the I/O number column.

If there are not enough unused I/O points for the auxiliary contact status assignment, user must add DIOM avatar from **Device** avatar Configuration Tab.

I/O Listing in IO PORT ASSIGNMENT Table

Digital I/O

The trip status information will be listed in the **IO PORT ASSIGNMENT** table and assigned to a digital output.

The following digital I/O are listed in the **IO PORT ASSIGNMENT** table :

Trip Status	Thermal Overload
	Jam
	Long Start
	Stall
	Undercurrent
	Overcurrent
	Ground Current Detected
	Motor Overheat Trip
	Current Phase Loss
	Current Phase Unbalance
	Current Phase Reversal
	Rapid Cycle Lockout
	Rapid Restart Lockout
	Avatar Trip Status

Local I/O	Local Control*
	Local Trip Reset
	Manual Mode Override
	Bypass Command
Starter AUX Contact	Auxilliary contact
PV Switches	PV Switches (0 to 5)
1. *Local control includes following control listed below: - LocalForwardCommand - LocalReverseCommand - LocalLowSpeedForwardCommand - LocalHighSpeedForwardCommand - LocalLowSpeedReverseCommand - LocalHighSpeedReverseCommand NOTE: Depending upon the avatar type selected, any of the above listed control will be available. 2. *This will be applicable only for PIM with IO avatar. - LocalOutput1 command - LocalOutput2 command It is recommended not to assign multiple local control signals to a single input.	

Analog I/O

For analog output point, there is range options (-10 Vdc/+10 Vdc, 0 Vdc/+10 Vdc, 0 mA/20 mA, 4 mA/ 20 mA).

The following analog I/O are listed in the **IO PORT ASSIGNMENT**:

Analog I/O	Load Current
	Motor Overheat
	PV Input (0...5)

Load current can be assigned to analog output. Motor overheat and PV input can be assigned to Analog I/O only.

I/O Port Listing

The following table shows the list of possible digital and analog input/output for each avatar which, will be listed in the IO PORT ASSIGNMENT table.

In the following table, **Ok** indicates the particular data for that particular avatar.

Name	Digital I/O				Analog I/O		
	Trip Status	Local I/O	Auxilliary Contact	PV Switch	Load Current	Motor Overheat	PV Input
System avatar	–	–	–	–	–	–	–
Switch	–	–	Ok	–	–	–	–
Switch - SIL Stop, W. Cat 1/2 ¹	–	–	Ok	–	–	–	–
Switch - SIL Stop, W. Cat 3/4 ²	–	–	Ok	–	–	–	–
Digital I/O	–	–	–	–	–	–	–
Analog I/O	–	–	–	–	–	–	–
Power Interface without IO (measure)	–	–	–	–	Ok	Ok	–
Power Interface with IO (control)	Ok	Ok	–	–	Ok	Ok	–
Motor One Direction	Ok	Ok	Ok	Ok	Ok	Ok	Ok
Motor One Direction - SIL Stop, W. Cat 1/2	Ok	Ok	Ok	–	Ok	Ok	–
Motor One Direction - SIL Stop, W. Cat 3/4	Ok	Ok	Ok	–	Ok	Ok	–
Motor Two Directions	Ok	Ok	Ok	Ok	Ok	Ok	Ok
Motor Two Directions - SIL Stop, W. Cat 1/2	Ok	Ok	Ok	–	Ok	Ok	–
Motor Two Directions - SIL Stop, W. Cat 3/4	Ok	Ok	Ok	–	Ok	Ok	–
Motor Y/D One Direction	Ok	Ok	Ok	Ok	Ok	Ok	Ok
Motor Y/D Two Directions	Ok	Ok	Ok	Ok	Ok	Ok	Ok
Motor Two Speeds	Ok	Ok	Ok	Ok	Ok	Ok	Ok

⁽¹⁾ Safety Integrity Level according to standard IEC 61508. Wiring Category 1 and Category 2 according to ISO 13849.

⁽²⁾ Safety Integrity Level according to standard IEC 61508. Wiring Category 3 and Category 4 according to ISO 13849.

Name	Digital I/O				Analog I/O		
	Trip Status	Local I/O	Auxilliary Contact	PV Switch	Load Current	Motor Overheat	PV Input
Motor Two Speeds - SIL Stop, W. Cat 1/2	Ok	Ok	Ok	–	Ok	Ok	–
Motor Two Speeds - SIL Stop, W. Cat 3/4	Ok	Ok	Ok	–	Ok	Ok	–
Motor Two Speeds Two Directions	Ok	Ok	Ok	Ok	Ok	Ok	Ok
Motor Two Speeds Two Directions - SIL Stop, W. Cat 1/ 2	Ok	Ok	Ok	–	Ok	Ok	–
Motor Two Speeds Two Directions - SIL Stop, W. Cat 3/ 4	Ok	Ok	Ok	–	Ok	Ok	–
Resistor	Ok	Ok	Ok	–	Ok	–	–
Power Supply	Ok	Ok	Ok	–	Ok	–	–
Transformer	Ok	Ok	Ok	–	Ok	–	–
Pump	Ok	Ok	Ok	Ok	Ok	Ok	Ok
Conveyor One Direction	Ok	Ok	Ok	Ok	Ok	Ok	Ok
Conveyor One Direction - SIL Stop, W. Cat 1/2	Ok	Ok	Ok	Ok	Ok	Ok	Ok
Conveyor Two Directions	Ok	Ok	Ok	Ok	Ok	Ok	Ok
Conveyor Two Directions - SIL Stop, W. Cat 1/2	Ok	Ok	Ok	Ok	Ok	Ok	Ok

The following illustration is an example of default trip status for **Motor One Direction** avatar.

MY ISLANDMY AVATARSETTINGSDIAGNOSTICSENERGY MONITORING

AVATARS

SystemAvSystem01

Motor One DirectionAvOneDirection02

A1A2

IO PORT ASSIGNMENT

Avatar Name	I/O Name	I/O Device Name	I/O Number	Value
AvOneDirection02	LoadCurrent	Not Assigned	Not Assigned	0 A
AvOneDirection02	AvtStatusThOverTrip	Not Assigned	Not Assigned	Off
AvOneDirection02	AvtStatusJamTrip	Not Assigned	Not Assigned	Off
AvOneDirection02	AvtStatusLongStTrip	Not Assigned	Not Assigned	Off
AvOneDirection02	AvtStatusStallTrip	Not Assigned	Not Assigned	Off
AvOneDirection02	Device2 AUX Contact	Not Assigned	Not Assigned	Off

All status information of each avatar is shown as logical I/O in the **IO PORT ASSIGNMENT** table in the **System** avatar settings except for power interface avatar.

NOTE: For **Power Interface with IO** avatar, the I/O assignment is applicable.

These logical I/O will not be assigned to device; user must manually assign to any unused digital or analog output.

When there are multiple Inputs assigned to a single digital output, then the output will be triggered if any of the input is high.

When analog input is assigned to analog output, the output will be triggered with the same value as analog input.

- For DIOM, the available I/O port numbers are (I0, I1, I2, I3, Q0, Q1)
- For AIOM, the available I/O port numbers are (I0+/I0-, I1+/I1-, O+/O-)

NOTE: If the user select the sensor NI100 or N1000 or PT 100 or PT1000 sensor in the PV input, NC0 and NC1 will be added in the input port of the **IO PORT ASSIGNMENT** table.

If there are not enough unused I/O points for the status information and the user wants to assign an I/O point, then an I/O device or I/O **Device** avatar has to be added to the main configuration.

Possible Assignments

The following section describe the possible assignments of digital and analog input/output.

- Trip status can be assigned only to output of DIOM module.
- Local I/O can be assigned only to input of DIOM module.
- Auxiliary contact status can be configured/selected to only digital output of DIOM module or not assigned to any module.
- **PV Switch** can be configured/selected to only digital input of DIOM module.
- Load current can be configured/selected to only analog output of AIOM module or not assigned to any module.
- **Motor overheat** can be configured/selected to only analog input of AIOM module.
- **PV Input** can be configured/selected to only analog input of AIOM module.

List of Mandatory or Optional Ports

- Trip status and auxiliary contact status are optional which means they can be not assigned to any IO module.
- PV switch, Local IO, Load current, Motor overheat, PV input must be assigned to IO module in the TeSys island.

- IO module which are added by default for avatar like PIM with IO avatar, application avatars will not participate in IO optimization.

Switch Avatar Settings

Overview

The following sections describe the settings of **Switch**, **Switch - SIL Stop, W. Cat. 1/2** and **Switch - SIL Stop, W. Cat. 3/4** avatars.

The settings of the switch avatars are grouped as follows:

- General settings, page 72
- Electrical protection, page 73
- Automatic reset, page 74

The following illustration is an example of the **Switch** avatar settings:

MY ISLANDMY AVATARSETTINGSDIAGNOSTICSENERGY MONITORING

AVATARS

System
AvSystem1

A1

Switch
AvSwitch2

A2

Switch - SIL Stop, W. Cat 1/2
AvSwitchSafeStopCat3

A3

GENERAL SETTINGS

FLA>Ir (FLA): 0.18A

ELECTRICAL PROTECTION

CURRENT PHASE LOSS>

GROUND CURRENT DETECTION

CURRENT PHASE UNBALANCE

PHASE REVERSAL

Current Phase Loss Trip: Enable

Current Phase Loss Trip Delay: 3sec

Current Phase Loss Trip Level: 80%

AUTOMATIC RESET

ELECTRICAL PROTECTION GROUP>Auto-Reset Retry Attempt Maximum: 0

Auto-Reset Timer: 1200sec

GENERAL SETTINGS

The following general settings are available for the selected avatars:

Section	Setting	Description
FLA	Ir (FLA)	Set the rated current of the motor. NOTE: Full-load amperage (FLA) refers to the motor's rated current (Ir) at rated load and rated voltage. This is the amount of current (A) that the motor draws from the electrical system when producing its rated output horsepower.

ELECTRICAL PROTECTION

The avatars with electrical protection functions enable detected electrical conditions between the starter and the load, and issue an alarm or a trip. The following electrical protection settings are available for the selected avatars:

Section	Setting	Description
CURRENT PHASE LOSS (1)	Current Phase Loss Trip	Enable or Disable the current phase loss trip. If this function is enabled, a trip is initiated when the current phase unbalance exceeds the Current Phase Loss Trip Level in the Motor Start State or Motor Run State for a period longer than the Current Phase Loss Trip Delay .
	Current Phase Loss Trip Delay	Set the trip delay for current phase loss.
	Current Phase Loss Trip Level	Displays the trip level. NOTE: Trip level is fixed at 80% and you cannot change it.
GROUND CURRENT DETECTION	Ground Current Trip	Enable or Disable the ground current trip. If this function is enabled, a trip is initiated when the ground current exceeds the Ground Current Trip Level for a period longer than the Ground Current Trip Delay .
	Ground Current Trip Delay	Set the trip delay for ground current.
	Ground Current Trip Level	Set the trip level for ground current.
	Ground Current Alarm	Enable or Disable the ground current alarm. This function is activated to indicate when the ground current exceeds the Ground Current Alarm Level .
	Ground Current Alarm Level	Set the alarm level percentage for ground current.
CURRENT PHASE UNBALANCE (1)	Current Phase Unbalance Trip	Enable or Disable the current phase unbalance trip. Avatars set to three-phase operation, with the Current Phase Unbalance Trip function enabled, initiate a trip when the unbalance in phase current exceeds the Current Phase Unbalance Trip Level : in the motor start state for a period longer than the Current Phase Unbalance Trip Delay - Start. or

Section	Setting	Description
		in the motor run state for a period longer than the Current Phase Unbalance Trip Delay - Run. You can configure separate trip delays for run state and start state.
	Current Phase Unbalance Trip Delay - Start	Set the trip delay for a current phase unbalance during the motor start state.
	Current Phase Unbalance Trip Delay - Run	Set the trip delay for a current phase unbalance during the motor run state.
	Current Phase Unbalance Trip Level	Set the trip level percentage for current phase unbalance.
	Current Phase Unbalance Alarm	Enable or Disable the current phase unbalance alarm. Avatars set to three-phase operation, with the Current Phase Unbalance Alarm function enabled, indicate when the current phase unbalance exceeds the Current Phase Unbalance Alarm Level .
	Current Phase Unbalance Alarm Level	Set the alarm level percentage for current phase unbalance.
PHASE REVERSAL ⁽¹⁾	Current Phase Reversal Trip	Enable or Disable the current phase reversal trip. If this function is enabled, a trip is initiated when the detected current phase sequence does not match with the current phase sequence setting for 100 ms. NOTE: There is no alarm for current phase reversal. This function is not adjustable.
	Current Phase Sequence	Select the order of the phases (ABC or ACB) in rotation for the avatar.
⁽¹⁾ This parameter is displayed if the Power Supply Type is Three Phase .		


AUTOMATIC RESET

For more details, refer to AUTOMATIC RESET, page 82.

Analog I/O Avatar Settings

Overview

The following illustration is an example of the **Analog I/O** avatar settings:



CONFIGURATION

Section	Setting	Description
INPUT	Type Of Analog Input 0	Select the type of analog input from the drop-down list.
	Type Of Analog Input 1	
OUTPUT	Type Of Analog Output 0	Select the type of analog output from the drop-down list.

Load Avatar Settings

Overview

The settings of **LOAD** avatars are described in the following sections.

NOTE: The settings of Load avatars, page 46 are displayed based on the type of avatar you have selected.

The settings of the avatars are grouped as follows:

- Configuration, page 76
- General settings, page 77
- Thermal protection, page 77
- Electrical protection, page 78
- Load protection, page 80
- Automatic reset, page 82
- Predictive alarms, page 83

The following illustration is an example of the settings for the **Motor Y/D Two Directions** avatar:

MY ISLANDMY AVATARSETTINGSDIAGNOSTICSENERGY MONITORING

AVATARS

System
AvSystem01

Motor Y/D Two Directions
AvYDTwoDirection02

A1A2

CONFIGURATION

PV INPUT>Type PV Input 0: Sensor Type NI100Type PV Input 1: Sensor Type NI100

GENERAL SETTINGS

CONTROL MODE>Control Mode Selection: Remote Control ModeTIME TO SWITCHFLA

THERMAL PROTECTION

THERMAL OVERLOAD>Thermal Overload Trip: EnableTrip Class: 10Reset Threshold: 85 %Motor Auxiliary Fan Cooled: OffThermal Overload Alarm: Enable

PREDICTIVE ALARMS

ALARM INPUT 1>Type Of Input: TemperatureALARM INPUT 2Alarm High Threshold Value 0 °CALARM 1 DEFINITIONAlarm Low Threshold Value 0 °CALARM 2 DEFINITIONALARM 3 DEFINITIONALARM 4 DEFINITIONALARM 5 DEFINITIONALARM 6 DEFINITIONALARM 7 DEFINITIONALARM 8 DEFINITIONALARM 9 DEFINITIONALARM 10 DEFINITION

OKCancel

CONFIGURATION

The following configuration settings are available for the selected avatars:

76

8536IB1907–07

Section	Setting	Description
PV INPUT	Type PV Input NOTE: The Type PV Input settings are displayed if you have set the number of PV Inputs Nb for the selected avatar. To set, go to My Avatar tab → Avatar Parameters and set PV Inputs Nb from 0 to 5.	Select the type of analog input to be measured.

GENERAL SETTINGS

The following general settings are available for the selected avatars:

Section	Setting	Description
TIME TO SWITCH	Y/D Timer⁽¹⁾	Set the Y/D time. NOTE: The Y/D timer is used to change the circuit from star to delta connection when the motor reaches the specified rated speed.
FLA	Ir (FLA)	Set the rated current of the motor. NOTE: Full-load amperage (FLA) refers to the motor's rated current (Ir) at rated load and rated voltage. This is the amount of current (A) that the motor draws from the electrical system when producing its rated output horsepower.
	Ir (FLA) 2⁽²⁾	Set the rated current of the motor for two-speed avatars.
⁽¹⁾ This parameter is displayed for the Motor Y/D One Direction and Motor Y/D Two Directions avatars. ⁽²⁾ This parameter is displayed for the Motor Two Speeds , Motor Two Speeds - SIL Stop, W. Cat. 1/2 , Motor Two Speeds Two Directions , Motor Two Speeds Two Directions - SIL Stop, W. Cat. 1/2 , Motor Two Speeds - SIL Stop, W. Cat. 3/4 , and Motor Two Speeds Two Directions - SIL Stop, W. Cat. 3/4 avatars.		

THERMAL PROTECTION

The thermal protection function signals a trip if the motor thermal capacity used exceeds the thermal overload or overheat trip level. The following thermal protection settings are available for the selected avatars:

Section	Setting	Description
THERMAL OVERLOAD	Thermal Overload Trip	Enable or Disable the thermal overload trip.

Section	Setting	Description
	Trip Class	Select the trip class. The option selected determines how quickly the overload relay trips upon detection of a thermal overload.
	Reset Threshold	Set the reset threshold as a percentage of the motor thermal capacity.
	Thermal Overload Alarm	Enable or Disable the thermal overload alarm. This function is activated when the thermal capacity of the motor exceeds the thermal overload alarm level.
	Overload Alarm Level	Set the percentage for the overload alarm level.
MOTOR OVERHEAT NOTE: This setting is displayed, if you have enabled Temperature Sensor Available parameter in the My Avatar tab. To enable, go to My Avatar tab → AVATAR PARAMETERS → Temperature Sensor Available and select Yes .	Motor Overheat Trip	Enable or Disable the motor overheat trip. If this function is enabled, a trip is initiated when the motor temperature measurement exceeds the motor overheat Trip Level for a period longer than the motor overheat Trip Delay .
	Trip Delay	Set the time delay before a trip occurs.
	Trip Level	Set the level of an input that triggers a trip
	Reset Threshold	Set the reset threshold.
	Motor Overheat Alarm	Enable or Disable the motor overheat alarm. If enabled, this function indicates when the motor temperature measurement exceeds the motor overheat alarm level.
	Alarm Threshold	Set the alarm threshold of the motor overheat trip.
	Temperature Sensor	Select the temperature sensor from the drop-down list. NOTE: The temperature sensor provides motor temperature output.
NOTE: The THERMAL PROTECTION function is not displayed for the Resistor , Power Supply , or Transformer avatars.		

ELECTRICAL PROTECTION

The avatars with electrical protection functions enabled detect electrical event, and issue an alarm or a trip. The following electrical protection settings are available for the selected avatars:

Section	Setting	Description
CURRENT PHASE LOSS (1)	Current Phase Loss Trip	Enable or Disable the current phase loss trip. If this function is enabled, a trip is initiated when the current phase unbalance exceeds the Current Phase Loss Trip Level in the Motor Start State or Motor Run State for a period longer than the Current Phase Loss Trip Delay.
	Current Phase Loss Trip Delay	Set the trip delay for current phase loss.
	Current Phase Loss Trip Level	Set the trip level percentage for current phase loss.
GROUND CURRENT DETECTION	Ground Current Trip	Enable or Disable the ground current trip. If this function is enabled, a trip is initiated when the ground current exceeds the Ground Current Trip Level for a period longer than the Ground Current Trip Delay.
	Ground Current Trip Delay	Set the trip delay for ground current.
	Ground Current Trip Level	Set the trip level for ground current.
	Ground Current Alarm	Enable or Disable the ground current alarm. This function is activated to indicate when the ground current exceeds the Ground Current Alarm Level.
	Ground Current Alarm Level	Set the alarm level percentage for ground current.
CURRENT PHASE UNBALANCE (1)	Current Phase Unbalance Trip	Enable or Disable the current phase unbalance trip. Avatars set to three-phase operation, with the Current Phase Unbalance Trip function enabled, initiate a trip when the unbalance in phase current exceeds the Current Phase Unbalance Trip Level: - in the motor start state for a period longer than the Current Phase Unbalance Trip Delay - Start. - or - in the motor run state for a period longer than the Current Phase Unbalance Trip Delay - Run. You can configure separate trip delays for run state and start state.
	Current Phase Unbalance Trip Delay - Start	Set the trip delay for a current phase unbalance during start state.

Section	Setting	Description
	Current Phase Unbalance Trip Delay - Run	Set the trip delay for a current phase unbalance during run state.
	Current Phase Unbalance Trip Level	Set the trip level percentage for current phase unbalance.
	Current Phase Unbalance Alarm	Enable or Disable the current phase unbalance alarm. Avatars set to three-phase operation, with the Current Phase Unbalance Alarm function enabled, indicate when the current phase unbalance exceeds the Current Phase Unbalance Alarm Level .
	Current Phase Unbalance Alarm Level	Set the alarm level percentage for current phase unbalance.
PHASE REVERSAL⁽¹⁾	Current Phase Reversal Trip	Enable or Disable the current phase reversal trip. If this function is enabled, a trip is initiated when the detected current phase sequence does not match the current phase sequence setting for 100 ms. NOTE: There is no alarm for current phase reversal. This function is not adjustable.
	Current Phase Sequence	Select the order of the phases (ABC or ACB) in rotation for the avatar.
⁽¹⁾ This parameter is displayed if the Power Supply Type is Three Phase .		

LOAD PROTECTION

The avatars with load protection functions enabled detect mechanical or operating problems on the load and issue as alarm or a trip. The following load protection settings are available for the selected avatars:

Section	Setting	Description
JAM	Jam Trip	Enable or Disable the jam trip. If this function is enabled, a trip is initiated when the maximum phase current exceeds the Jam Trip Level in the motor run state for a time longer than the Jam Trip Delay .
	Jam Trip Delay	Set the jam trip delay.
	Jam Trip Level	Set the threshold for jam trip level.
	Jam Alarm	Enable or Disable the jam alarm.

Section	Setting	Description
		This function is activated to indicate when the maximum phase current exceeds the Jam Alarm Level in the motor run state.
	Jam Alarm Level	Set the threshold for jam alarm level.
LONG START	Long Start Trip	Enable or Disable the long start trip. Avatars with the Long Start function detect a long start and initiate a trip if either of the following conditions occur during the time specified in Long Start Trip Delay, after the motor has entered the start phase: - Average current exceeds the Long Start Trip Level and does not fall below it again. - Average current does not reach the Long Start Trip Level.
	Long Start Trip Delay	Set the long start trip delay.
	Long Start Trip Level	Set the long start trip level.
STALL	Stall Trip	Enable or Disable the stall trip. If this function is enabled, a trip is initiated when the maximum phase current exceeds the Stall Trip Level in the motor start state for a period longer than the Stall Trip Delay.
	Stall Trip Delay	Set the stall trip delay.
	Stall Trip Level	Set the threshold for the stall trip level.
UNDERCURRENT	Undercurrent Trip	Enable or Disable the undercurrent trip. If this function is enabled, a trip is initiated when the average phase current is less than the Undercurrent Trip Level in the motor run state for a period longer than the Undercurrent Trip Delay.
	Undercurrent Trip Level	Set the threshold for undercurrent trip level.
	Undercurrent Trip Delay	Set the undercurrent trip delay.
	Undercurrent Alarm	Enable or Disable the undercurrent alarm. This function is activated to indicate when the average phase current is less than the Undercurrent Alarm Level in the motor run state.
	Undercurrent Alarm Level	Set the threshold for the undercurrent alarm level.
OVERCURRENT	Overcurrent Trip	Enable or Disable the overcurrent trip. If this function is enabled, a trip is initiated when the maximum phase current exceeds the Overcurrent

Section	Setting	Description
		Trip Level in the motor run state for a period longer than the Overcurrent Trip Delay .
	Overcurrent Trip Level	Set the threshold for the overcurrent trip level.
	Overcurrent Trip Delay	Set the overcurrent trip delay.
	Overcurrent Alarm	Enable or Disable the overcurrent alarm. This function is activated to indicate when the maximum phase current exceeds the Overcurrent Alarm Level in the motor run state.
	Overcurrent Alarm Level	Set the threshold for the overcurrent alarm level.
RAPID CYCLE LOCKOUT	Rapid Cycle Lockout	Enable or Disable the rapid cycle lockout. The Rapid Cycle Lockout function ignores new run commands for the time specified in the Rapid Cycle Lockout Timeout after a transition to the motor start state.
	Rapid Cycle Lockout Timeout	Set the rapid cycle lockout timeout.
RAPID RESTART LOCKOUT	Rapid Restart Lockout	Enable or Disable the rapid restart lockout. The Rapid Restart Lockout function ignores run commands for the time specified in the Rapid Restart Lockout Timeout after a transition to the motor Off state.
	Rapid Restart Lockout Timeout	Set the rapid restart lockout timeout.
NOTE: The JAM , STALL , RAPID CYCLE LOCKOUT , and RAPID RESTART LOCKOUT functions are not displayed for the Resistor , Power Supply , or Transformer avatars.		

AUTOMATIC RESET

NOTE: The **Auto-Reset** function may lead to immediate energizing of the load, with an active command from the PLC or the **Force Mode** function.

 **WARNING**

UNINTENDED EQUIPMENT OPERATION

Configure this function in a such a way that this function does not result in unsafe conditions.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

The automatic reset function allows you to automatically reset the trips of avatars grouped in the thermal, electrical, or load protection sections. The following automatic reset settings are available for the selected avatars:

Section	Setting	Description
THERMAL PROTECTION GROUP	Maximum Auto-Reset Retries	Set the maximum number of auto-reset retry attempts.
ELECTRICAL PROTECTION GROUP		The Maximum Auto-Reset Retries specifies the number of reset attempts made if the previous ones are unsuccessful (for instance, if the external conditions causing the trip to occur still exist).
LOAD PROTECTION GROUP	Auto-Reset Timer	Set the auto-reset timer. The Auto-Reset Timer is a delay between the moment a protection function detects the presence of trip conditions (and triggers a trip), and the first auto-reset attempt.
NOTE: The THERMAL PROTECTION GROUP function is not displayed for the Resistor , Power Supply , or Transformer avatars.		

PREDICTIVE ALARMS

The following settings are available for the selected avatars:

Section	Setting	Description
ALARM INPUT1	Type of Input	Select the type of measurement represented by the analog input, for display purposes only.
ALARM INPUT2 NOTE: The PV inputs enabled for the avatar are also the predictive alarm inputs. The first PV input is the first alarm input, the second PV input is the second alarm input, and so on. To set, go to My Avatar tab → Avatar Parameters and set PV Inputs Nb to the desired number of avatar PV inputs, from 0 to 5.	Alarm High Threshold Value	Enter the high threshold value for the alarm based on the input selected.
	Alarm Low Threshold Value	Enter the low threshold value for the alarm based on the input selected.

Application Avatar Settings

Overview

The settings of **Application** avatars are described in the following sections.

NOTE: The settings of Application avatars, page 46 are displayed based on the type of avatar you have selected.

The settings of the avatars are grouped as follows:

- Configuration, page 85
- General settings, page 86
- Thermal protection, page 88
- Electrical protection, page 88
- Load protection, page 88
- Automatic reset, page 88
- Predictive alarms, page 88

The following illustration is an example of the settings for the **Conveyor Two Directions** avatar:

MY ISLAND

MY AVATAR

SETTINGS

DIAGNOSTICS

ENERGY MONITORING

AVATARS

System

AvSystem01

A1

Switch

AvSwitch02

A2

Switch – SIL Stop, W. Cat 3/4

AvSwitchSafeCt3403

A3

Power Interface with IO

AvPIMwIO04

A4

Conveyor Two Directions

AvConveyorTwoDir08

A5

CONFIGURATION

PV INPUT/SWITCH

Type PV Input 0: Sensor Type NI100

GENERAL SETTINGS

CONTROL MODE

FLA

Control Mode Selection: Remote Control Mode

THERMAL PROTECTION

THERMAL OVERLOAD

MOTOR OVERHEAT

Thermal Overload Trip: Enable

Trip Class: 10

Reset Threshold: 85 %

Motor Auxiliary Fan Cooled: Off

Thermal Overload Alarm: Enable

Overload Alarm Level: 85 %

ELECTRICAL PROTECTION

CURRENT PHASE LOSS

GROUND CURRENT DETECTION

CURRENT PHASE UNBALANCE

PHASE REVERSAL

Current Phase Loss Trip: Enable

Current Phase Loss Trip Delay: 3 sec

Current Phase Loss Trip Level: 80 %

LOAD PROTECTION

AUTOMATIC RESET

PREDICTIVE ALARMS

CONFIGURATION

The following configuration settings are available for the selected avatars:

Section	Setting	Description
PV INPUT/SWITCH	Type PV Input NOTE: The Type PV Input settings are displayed if you have set the number of PV Inputs Nb for the selected avatar. To set, go to My Avatar tab → Avatar Parameters and set PV Inputs Nb to the desired number of avatar PV inputs, from 0 to 5.	Select the type of analog input to be measured.

GENERAL SETTINGS

The following general settings are available for the selected avatars:

Section	Setting	Description
CONTROL MODE	Control Mode Selection	Select the type of control mode from the drop-down list. • Remote The avatar is controlled by PLC command. By default, Remote mode is selected. • Local The avatar is controlled by Local Command & PV Control. • Autonomous The avatar is controlled by PV Control.
CONTROL MODE	PV CONTROL INPUT SOURCE	Select the required control source from the drop-down list. • PVInput • PVSwitch When PVInput selected, the following parameters appear. • PV Control Input Level Enter the required input level. • PV Control Input Hysteresis Enter the input hysteresis value in percentage. • PV Control Input Hysteresis High Level Displays the high level of the PV Control Input Hysteresis.

Section	Setting	Description
		• PV Control Input Hysteresis Low Level Displays the low level of the PV Control Input Hysteresis. • PV Control Input0 Logic Select the type of PV control logic: ◦ Positive logic: The PV control input provides a run command when the associated PV input is above the PV control level. ◦ Negative logic: The PV control input provides a run command when the associated PV input is below the PV control level. • PV Control Input1 Logic Select the type of PV control logic: ◦ Positive logic: The PV control input provides a run command when the associated PV input is above the PV control level. ◦ Negative logic: The PV control input provides a run command when the associated PV input is below the PV control level.
CONTROL MODE		• Combined PV Control Select the type of PV control mode: ◦ Separate control: The logical OR provides a run command to the avatar if one of the PV control inputs provides a run command. ◦ Combined control: The logical AND provides a run command to the avatar only if both PV control inputs provide a run command. When PVSwitch selected, the following parameters appear. • PV Control Input Debounce Delay Enter the delay for the control input in secs.
FLA	Ir (FLA)	Set the rated current of the motor. NOTE: Full-load amperage (FLA) refers to the motor's rated current (Ir) at rated load and rated voltage. This is the amount of current (A) that the motor draws from the electrical system when producing its rated output horsepower.

THERMAL PROTECTION

For more details, refer to THERMAL PROTECTION, page 77.

ELECTRICAL PROTECTION

For more details, refer to ELECTRICAL PROTECTION, page 78.

LOAD PROTECTION

For more details, refer to LOAD PROTECTION, page 80.

AUTOMATIC RESET

For more details, refer to AUTOMATIC RESET, page 82.

PREDICTIVE ALARMS


For more details, refer to PREDICTIVE ALARMS, page 83.

DIAGNOSTICS Tab

Introduction

Overview

The **DIAGNOSTICS** tab displays the status and diagnostic information of avatars and devices connected to the island. You can also reset the trip and alarm counters.



- 1 Avatars tab, page 89
- 2 Devices tab, page 94
- 3 Compare tab, page 100
- 4 Test mode status indicator, page 103
- 5 Force mode status indicator, page 104


NOTE: The **Motor Thermal Capacity** is displayed when the **Thermal Overload Alarm** is enabled for a selected avatar. To enable, go to **Settings > THERMAL PROTECTION > THERMAL OVERLOAD > Thermal Overload Alarm** and select **Enable**.

AVATARS Tab

Overview

In this tab, the list of the configured avatars is displayed, along with **STATUS**, **EVENT LOGS**, **COUNTERS**, and **POWER VOLTAGE** diagnostics information.

The following illustration is an example of the **AVATARS** tab in the **DIAGNOSTICS** tab:



- 1 Avatar list, page 90
- 2 Status icons, page 90
- 3 Name of avatar, page 91
- 4 Status, page 91
- 5 Event logs, page 92
- 6 Counters, page 93
- 7 Power voltage, page 93

Avatar List

Displays the avatars added in the TeSys island.

Status Icons

The status icons displayed in avatar list indicate the following:


-  : DTM is in offline mode.
-  : Avatar is OK or ready.
-  : Avatar has issued an alarm.
-  : Avatar is tripped or has detected an event.

Name of Avatar

This field displays the **Avatar Name** that you have entered into the **MY AVATAR** tab.

STATUS

The **STATUS** section displays the status of the selected avatar.



For more details on functionality of the **STATUS** section, refer to **Force Mode**, page 104.

NOTE:

- **Motor Overheat** is displayed when the motor overheat trip or alarm is enabled in avatar settings.
- **Motor Thermal Capacity** is displayed when the thermal overload trip or alarm is enabled in avatar settings.

Process Variable (PV)

PV Name	PV Value
PvInput1	0 °C
PvInput2	0 °C
PvInput3	0 mA
PvSwitch1	False
PvSwitch2	False

This section displays the process variable name and value of the selected application avatar which you have configured in CONFIGURATION, page 85 section.

The process variable table is shown for the avatars which support process variables. PV inputs and PV switches that are configured for the avatar are shown in the table. The PV names are the names configured in the My **Avatar** tab. The PV value (On or Off) are shown for PV switches. The PV value for PV inputs is shown in units corresponding to the PV input type configured in the avatar settings.

EVENT LOGS


The **EVENT LOGS** section displays the event logs of the selected avatar.

STATUS	Date & Time	Avatar Name or Safe Group	Device Name Tag	Event Name	Description
EVENT LOGS >	12/18/75 6:55:23 AM	Avatar1	Device1	System Warning	Device Data Not Updated
COUNTERS	12/18/75 1:58:57 AM	Avatar1	Device1, Device2	System Warning	Device Data Not Updated
POWER VOLTAGE	12/18/75 7:14:15 AM	Avatar1		System State Transition	enter DegradedModality
	12/18/75 4:07:33 AM	Avatar1		System State Transition	enter ForwardModality
	12/18/75 3:48:25 AM	Avatar1	Device1	System Warning	Device Data Not Updated
	12/18/75 3:48:25 AM	Avatar1	Device1	System Warning	Device Data Not Updated
	12/18/75 3:48:25 AM	Avatar1	Device1	System Warning	Device Data Not Updated
	12/18/75 3:48:25 AM	Avatar1	Device1	System Warning	Device Data Not Updated
	12/18/75 12:10:50 AM	Avatar1		System State Transition	exit ForwardModality
	12/18/75 12:10:27 AM	Avatar1		System State Transition	enter ForwardModality
	12/18/75 12:10:16 AM	Avatar1		System State Transition	exit TestModality
	12/18/75 12:10:16 AM	Avatar1		System State Transition	enter PreOperationalModality
	12/18/75 12:10:16 AM	Avatar1		System State Transition	exit PreOperationalModality
	12/18/75 12:10:16 AM	Avatar1		System State Transition	enter OperationalModality

Item	Description
Date & Time	Displays the date and time that the event occurred.
Avatar	Displays the name of the avatar.
Device or SIL Group	Displays the name tag of the device or SIL group number.
Event Name	Displays the name of event that has occurred.
Description	Displays the description of the event that has occurred.

COUNTERS

The **COUNTERS** section displays the trip, alarm, minor event, avatar minor event, and auto-reset retry counters of the selected avatar.



To reset the **TRIP COUNTERS**, **ALARM COUNTERS** and **MINOR EVENT COUNTERS**, click **Reset**.

POWER VOLTAGE

The **POWER VOLTAGE** section displays the power voltage status of the island.

NOTE:

- This function is displayed only for the **System** avatar.
- The **Power Voltage** section is displayed if you have enabled the **Load Energy Monitoring** option for a selected avatar.

AvSystem1

STATUS

EVENT LOGS

COUNTERS

POWER VOLTAGE >

POWER VOLTAGE STATUS

Average RMS Voltage:498 V

Voltage Fluctuation Status:On

Maximum Average RMS Voltage:498 V

Maximum Voltage Unbalance:100 %

Maximum Average RMS Voltage Timestamp:

Maximum Voltage Unbalance Timestamp:

RMS Voltage Phase 1 - Neutral:495 V

Voltage Phase Sequence:ABC

RMS Voltage Phase 2 - Neutral:498 V

Voltage Dip Count:3

RMS Voltage Phase 3 - Neutral:500 V

Voltage Swell Counter:1

Frequency (Hz):50 Hz

Percentage of Voltage Unbalance:1 %

Voltage Fluctuation:

Reset

POWER VOLTAGE DIP & SWELL

VOLTAGE DIP RECORD REGISTER

Voltage Magnitude	Start	End
872 V		
53 V		
53 V		
0 V	20/06/2015 12:00:00 AM	20/06/2015 12:00:00 AM
0 V	20/06/2015 12:00:00 AM	20/06/2015 12:00:00 AM
Voltage Dip Count:	3	Reset

VOLTAGE SWELL RECORD REGISTER

Voltage Magnitude	Start	End
130 V		
0 V	20/06/2015 12:00:00 AM	20/06/2015 12:00:00 AM
0 V	20/06/2015 12:00:00 AM	20/06/2015 12:00:00 AM
0 V	20/06/2015 12:00:00 AM	20/06/2015 12:00:00 AM
0 V	20/06/2015 12:00:00 AM	20/06/2015 12:00:00 AM
Voltage Swell Counter:	1	Reset


To reset the voltage dip and swell record register, click **Reset**.

DEVICES Tab

Overview

In this tab, the **PHYSICAL VIEW** of the devices is displayed, along with **STATUS**, **ASSET DATA**, and **PRODUCT IDENTIFICATION**.

The following illustration is an example of the **DEVICES** tab:



- 1 Device status, page 95
- 2 Physical view, page 96
- 3 Status, page 96
- 4 Asset data, page 97
- 5 Product identification, page 99

Device Status


The status icons indicate the following:

- : DTM is in offline mode.
- ✓ : Device is OK or ready.
- ! : Device has issued an alarm.
- ! : Device has detected an event.

PHYSICAL VIEW

In this section, the physical view of the devices configured on the TeSys island is displayed, indicating the position of each device on the bus.


The following illustration is an example of the **PHYSICAL VIEW** section:



To see the details in **STATUS**, **ASSET DATA**, and **PRODUCT IDENTIFICATION** sections, click the devices.

STATUS

The following illustration is an example of the **STATUS** section:



Name		Description
Name Tag		Displays the name tag of the module.
Product Code		Displays the product reference of the module
System Status		Displays the System status.
Command	Locate	The bus coupler’s PWR LED illuminates a yellow pattern for 5 seconds to help you identify the device to which the DTM is communicating.

Name		Description
		NOTE: This command is displayed only for the bus coupler device.
	System Restart	Starts the complete system again. NOTE: System Restart will disconnect the DTM from the island. NOTE: This command is displayed only for the bus coupler device.
Device Status		Displays the device status.
SIL Stop 0 LED State		Displays the LED status of the SIL interface module.
Upstream Voltage Presence		Displays the presence of upstream voltage.
Average RMS Current		Displays the average RMS current.
Test Command		Activate or deactivate the Test Mode , page 103. NOTE: This command is displayed only for Switch and SIL Switch devices.
Input 0		Displays the status of Input 0 of the Digital I/O module.
Input 1		Displays the status of Input 1 of the Digital I/O module.
Input 2		Displays the status of Input 2 of the Digital I/O module.
Input 3		Displays the status of Input 3 of the Digital I/O module.
Output 1		Displays the status of Output 1 of the Digital I/O module.
Output 2		Displays the status of Output 2 of the Digital I/O module.

ASSET DATA

The following illustration is an example of the **ASSET DATA** section:

ASSET DATA	
Number Of Device Power Cycles:	0
Number Of Contactor Cycles:	0
Time Device On:	0 hour
Time Switch ON:	0 hour
Maximum RMS Current:	0 A
Number of Device Events:	0
Lifetime Average RMS Current:	0 A

Name	Description
Number Of Device Power Cycles	Displays the number of times that the device has been powered On from the Off state.
Number Of Contactor Cycles	Displays the number of contactor cycles of the device.
Time Device On	Displays the total time in hours that the device has been powered On in its lifetime.
Time Switch ON	Displays the total time in hours that the switch has been closed in its lifetime.
Number of Device Events	Displays the number of events occurred.
Max Average Voltage	Displays the maximum average voltage of the device.
Average Lifetime Voltage	Displays the total lifetime average voltage of the device.
Maximum RMS Current	Displays the maximum RMS current of the device.
Lifetime Average RMS Current	Displays the total lifetime average RMS current of the device.
Number Of SIL-In 1 Operations	Displays the number of SIL operations of SIL input 1 of the SIL interface device.
Number Of SIL-In 2 Operations	Displays the number of SIL operations of SIL input 2 of the SIL interface device.
Mirror Relay Operations Counter	Displays the number of counts of mirror relay operations.

PRODUCT IDENTIFICATION

The following illustration is an example of the **PRODUCT IDENTIFICATION** section:

PRODUCT IDENTIFICATION

Vendor Name:

Schneider Electric

Product Code:

TPRBCEIP

Firmware Version:

Vendor URL:

http://www.schneider-electric.com

Product Family:

TeSys island

Model Name:

Bus Coupler

Fieldbus MAC Address 1:

Serial Number:

Production Date Code:

Name	Description
Vendor Name	Displays the vendor name of the selected device.
Product Code	Displays the product reference of the selected device.
Firmware Version	Displays the firmware version of the selected device.
Vendor URL	Displays the vendor URL of the selected device.
Product Family	Displays the product family of the selected device.
Model Name	Displays the model name of the selected device.
Fieldbus Mac Address1	Displays the fieldbus MAC address of the selected device. NOTE: This command is displayed only for the bus coupler device.
Serial Number	Displays the serial number of the selected device.
Product Date Code	Displays the date code of the selected device.

COMPARE Tab

Overview

The **COMPARE** tab displays the difference between the offline project topology with the connected island topology and also compares the configured parameters of an offline project with the connected island.


The **COMPARE** tab has the following sub tabs:

- **AVATAR VIEW**
- **DEVICE VIEW**

AVATAR VIEW

This tab displays the avatar topology configured in your project. It also displays the difference between the avatar topology, configured parameters, and the values of parameters.

The following illustration is an example of the **AVATAR VIEW** section:



- 1 Project, page 101
- 2 Island, page 101
- 3 Comparison status, page 101
- 4 Mismatch, page 101

PROJECT

This section displays the avatar topology configured in your offline project.

ISLAND

This section displays the avatar topology configured in the connected island.

Comparison Status

The icons represent the following:

- : No mismatch.
- : Avatars are the same, but the settings are different.
- : Avatars do not match.


MISMATCH

This section displays the difference between the configured parameters of an avatar in an offline project with the connected island in a tabular format. It also displays the missing avatar information.

DEVICE VIEW

This tab displays the device topology configured in your project. It also displays the difference between the device topology, configured parameters, and the values of the parameters.

The following illustration is an example of the **DEVICE VIEW** tab:



- 1 Project, page 102
- 2 Island, page 102
- 3 Comparison status, page 102
- 4 Mismatch, page 103

PROJECT

This section displays the device topology configured in your offline project.

ISLAND

This section displays the device topology configured in the connected island.

Comparison Status

The icons represent the following:


- : No mismatch.
- : Devices are the same, but the settings are different.
- : Devices do not match.

MISMATCH

This section displays the difference between the configured parameters of the device in an offline project with the connected island in a tabular format. It also displays the missing device information.

Test Mode

In **Test Mode**, the DTM enables you to send the test command (open or close) to the contactor to verify the working of an individual device.



The **Test Mode** is available when the DTM is in **Full-Control**, page 37 mode.

Procedure

To activate the **Test Mode**, perform the following steps:

NOTE: The **Test Command** is available only for digital I/O and starters.

Step	Action
1	Go to the DIAGNOSTICS > DEVICES tab and click on the device in the PHYSICAL VIEW section.
2	In the STATUS, page 96 section, click Close or Open next to the Test Command parameter. Result: • The DTM sends the test command (Close or Open) to the contactor. • The Device Status changes to the Ready CLOSED status (for Close command) or to the Ready status (for Open command). • The Test Mode is activated. Test Mode Exit The blinking icon indicates that the Test Mode is active. You can click Exit to deactivate the Test Mode. NOTE: Exit test mode will close all test commands.

NOTE: When **Test Mode** is active, the DTM cannot change the settings of the avatars.


Force Mode

In **Force Mode**, you can force the input from the PLC to the device, or the output from the device to the PLC.

The **Force Mode** is available when the DTM is in **Full-Control**, page 37 mode.

Force Mode Interface

The following screen is an example of the **Motor One Direction** avatar:





- 1 Indicates input or output is ON.
- 2 Indicates input or output is OFF.
- 3 Input from PLC to the device.
- 4 Output from device to the PLC

The table describes the **Force Mode** inputs:

Input	Description
Not Applied	No value is forced and the value coming from/to the PLC is processed.
Force 0	The command input processed by the Avatar logic is forced to OFF, or the status output from the Avatar logic is forced to OFF.
Force 1	The command input processed by the Avatar logic is forced to ON, or the status output from the Avatar logic is forced to ON.

Procedure

To activate the **Force Mode**, perform the following steps:

Step	Action
1	Go to the DIAGNOSTICS > AVATARS tab and click on the required avatar from avatar list, page 90. Result: The avatar diagnostic interface with pictorial representation is displayed in the STATUS section. 
2	Click Force 1 to force an On command to the logic for this Avatar input.  Result: The Force Mode is activated. ● Force Mode Exit The blinking icon ● indicates that the Force Mode is active. You can click Exit to deactivate the Force Mode. NOTE: Exit force mode changes all force commands to Not Applied.

ENERGY MONITORING Tab


Overview

This tab displays the voltage, energy, and power monitoring at the island level and at the avatar level with a voltage interface module.

System Energy Monitoring: Energy monitoring at the island level provides the voltage, power, and energy data for the TeSys island.

Avatar Energy Monitoring: Energy monitoring at the avatar level provides the power and energy data for the TeSys island.

The following illustration is an example of the **ENERGY MONITORING** tab:



- Avatar list, page 107
- Status icons, page 108
- Name of avatar, page 108
- Voltage monitoring, page 108
- Energy monitoring, page 110
- Power monitoring, page 111
- Time of use, page 112

NOTE: **TIME OF USE** is displayed in the **Load** and **Application** avatars only when **Load Energy Monitoring** is enabled for an avatar in the **MY AVATAR** tab.

Avatar List

Displays the list of the avatars added in the TeSys island DTM.

Status Icons

The status icons displayed in avatar list indicate the following:

-  : Avatar is OK or ready.
-  : Avatar has issued an alarm.
-  : Avatar is tripped or has detected an event.

Name of Avatar

Displays the **Avatar Name** which you have configured in the **MY AVATAR** tab.

VOLTAGE MONITORING

NOTE: VOLTAGE MONITORING is displayed in the **System** avatar only when **Load Energy Monitoring** is enabled for an avatar in the **MY AVATAR** tab.

DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Do not use the voltage monitoring function to verify an electrically safe working condition as defined in NFPA 70E. Use properly rated measuring device to verify absence of the voltage.

Failure to follow these instructions will result in death or serious injury.

The following illustration is an example of the **VOLTAGE MONITORING** section:

MY ISLAND

MY AVATAR

SETTINGS

DIAGNOSTICS

ENERGY MONITORING

AVATARS

System

AvSystem1

A1

Motor One Direction

AvMotorOneDirection2

A2

Motor Two Speeds

AvMotorTwoSpeeds3

A3

AvSystem1

VOLTAGE MONITORING

ENERGY MONITORING

POWER MONITORING

Average RMS Voltage:

0 V

Maximum Average RMS Voltage:

0 V

Reset

Maximum Average RMS Voltage Timestamp:

RMS Voltage Phase 1 - Neutral:

0 V

RMS Voltage Phase 2 - Neutral:

0 V

RMS Voltage Phase 3 - Neutral:

0 V

RMS Voltage, Phase 1 - Phase 2:

0 V

RMS Voltage, Phase 2 - Phase 3:

0 V

RMS Voltage, Phase 3 - Phase 1:

0 V

Percentage of Voltage Unbalance:

0 %

Maximum Voltage Unbalance:

0 %

Reset

Maximum Voltage Unbalance Timestamp:

Frequency (Hz):

0 Hz

Voltage Phase Sequence:

ABC

Voltage Fluctuation Status:

Off

Reset

Voltage Dip Count:

0

Reset

Voltage Swell Counter:

0

Reset

Parameter	Description
Average RMS Voltage	Displays the average RMS voltage.
Maximum Average RMS Voltage	Displays the maximum average RMS voltage. You can click Reset to reset the maximum average voltage to 0 and reset the associated timestamp.
Maximum Average RMS Voltage Timestamp	Displays the timestamp of the maximum average RMS voltage.
RMS Voltage Phase 1 - Neutral	Displays the RMS voltage of phase 1.
RMS Voltage Phase 2 - Neutral	Displays the RMS voltage of phase 2.
RMS Voltage Phase 3 - Neutral	Displays the RMS voltage of phase 3.
RMS Voltage Phase 1 - Phase 2	Displays the RMS voltage between phase 1 and phase 2.
RMS Voltage Phase 2 - Phase 3	Displays the RMS voltage between phase 2 and phase 3.
RMS Voltage Phase 3 - Phase 1	Displays the RMS voltage between phase 3 and phase 1.
Percentage of Voltage Unbalance	Displays the percentage of voltage unbalance.
Maximum Voltage Unbalance	Displays the maximum voltage unbalance. You can click Reset to reset the maximum unbalance voltage to 0 and reset the associated timestamp.

8536IB1907–07


109

Parameter	Description
Maximum Voltage Unbalance Timestamp	Displays the timestamp of the maximum voltage unbalance.
Frequency (Hz)	Displays the frequency.
Voltage Phase Sequence	Displays the phase sequence of the voltage. Sequence ABC: Indicates clockwise. Sequence CBA: Indicates counterclockwise.
Voltage Fluctuation Status	Displays ON when a voltage dip or swell has occurred. You can click Reset to reset the status.
Voltage Dip Count	Displays the count of voltage dips detected. You can click Reset to reset the counter to 0.
Voltage Swell Counter	Displays the count of voltage swells detected. You can click Reset to reset the counter to 0.

ENERGY MONITORING

ENERGY MONITORING displays the **Total Active Energy** and **Total Reactive Energy**.

The following illustration is an example of the **ENERGY MONITORING** section:




You can click **Reset** to reset the active and reactive energy to zero.

NOTE: Resetting does not affect the load energy data.

POWER MONITORING

The following illustration is an example of the **POWER MONITORING** section:



Parameter	Description
Instantaneous Total Active Power	Displays the instantaneous total active power.
Maximum Total Active Power	Displays the maximum total active power. You can click Reset to reset the maximum total active power to 0 and reset the associated timestamp.
Maximum Total Active Power Timestamp	Displays the timestamp of the maximum total active power.
Instantaneous Total Reactive Power	Displays the instantaneous total reactive power.
Maximum Total Reactive Power	Displays the maximum total reactive power. You can click Reset to reset the maximum total reactive power to 0 and reset the associated timestamp.
Maximum Total Reactive Power Timestamp	Displays the timestamp of the maximum total reactive power.
True Power Factor	Displays the true power factor.
Minimum True Power Factor	You can change the power factor to 1 and reset the associated timestamp.
Maximum True Power Factor	You can change the power factor to 0 and reset the associated timestamp.


Parameter	Description
Minimum True Power Factor Timestamp	Displays the timestamp of the minimum true power factor.
Maximum True Power Factor Timestamp	Displays the timestamp of the maximum true power factor.

TIME OF USE

NOTE: TIME OF USE is displayed in the **Load** and **Application** avatar only when **Load Energy Monitoring** is enabled for an avatar in the **MY AVATAR** tab.

The **TIME OF USE** window provides graphs showing accumulated energy when each channel is enabled. The channels can be enabled/disabled through the **TIME OF USE** configuration window in DTM or through the PLC. The four channels are independent of each other. The **TIME OF USE** configuration window in the DTM also allows you to preset energy data in these graphs.

The following illustration is an example of the **TIME OF USE** section:



To access the settings in the **TIME OF USE** window for the avatar, click the wheel icon in the top right corner. After you have changed the values, click **OK** and close the window.


TOU Configuration
×

Channel 1

Active Energy Time of Use Preset Value:

0.001

kWh

Reactive Energy Time of Use Preset Value:

0.001

kvarh

Record the Time of Use, Channel 1:

Yes

Channel 2

Active Energy Time of Use Preset Value:

0

kWh

Reactive Energy Time of Use Preset Value:

0

kvarh

Record the Time of Use, Channel 2:

No

Channel 3

Active Energy Time of Use Preset Value:

0

kWh

Reactive Energy Time of Use Preset Value:

0

kvarh

Record the Time of Use, Channel 3:

No

Channel 4

Active Energy Time of Use Preset Value:

0

kWh

Reactive Energy Time of Use Preset Value:

0

kvarh

Record the Time of Use, Channel 4:

No

OK

Cancel

Help

Control Panel

Overview

The control panel allows you to do the following:

- View the island status.
- Physically locate the device with which the DTM is communicating.
- Reset trips and the system.
- Restart the system.
- Switch off the island.

Accessing the Control Panel

You can access the **CONTROL PANEL** in one of the following ways:


- On the menu bar, go to **Device** and click **Control Panel**.
- On the toolbar, click the control panel button .

Result: The control panel appears at the bottom of the screen.

Control Panel Functions

The control panel buttons are enabled when TeSys island is in Online mode.

The control panel has the following sections:



- 1 Island status, page 115
- 2 Physically locate, page 115
- 3 Reset trips, page 115
- 4 Reset system, page 116
- 5 Restart system, page 116
- 6 Switch off island, page 117

Island Status

Status	Description
 Offline	Displays when the TeSys island is in Offline mode.
 Operational	Displays when the TeSys island is in Online mode.
 Test Mode	Displays when the TeSys island is in Test Mode, page 103.

Physically Locate

When the **Physically Locate** button is clicked, the **PWR** LED of the bus coupler illuminates a yellow pattern for 5 seconds. This action helps you to identify the device with which the DTM is communicating.

Reset Trips

The reset function may lead to immediate energizing of the load, with an active command from the PLC or the **Force Mode** function.

⚠ WARNING

UNINTENDED EQUIPMENT OPERATION

Before resetting the protection functions, verify that this function does not result in unsafe conditions.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Click the **Reset Trips** button to clear the protection trips which meet the trip reset conditions of all avatars.

NOTE: **Reset Trips** button is disabled in **Test Mode**, page 103.

Reset System

Click the **Reset System** button to clear alarms and detected minor events of the system.

Restart System

Perform the following steps to reboot the system:

1. Click the **Restart System** button.
Result: The warning message is displayed on the screen.

⚠ WARNING

UNINTENDED EQUIPMENT OPERATION

The Restart function will restart the island and attempt to reset events.
Verify that restarting the island will not result in unsafe conditions.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

CONTINUE

Cancel

2. Read the warning message and click **CONTINUE** to reboot the system.
Result: The system enters into reboot state.

NOTE: The DTM is disconnected from the island device after executing this command.

Switch Off Island

Click the **Switch Off Island** button to turn off all the loads on the island.

NOTE: The system can be used for maintenance purpose after executing this command.

User Functions

Firmware Update

Overview

You can update the firmware of the TeSys island using one of the following sources:


- **Server**
- **PC**

Accessing the Firmware Update

Perform the following steps to access the firmware update:

1. On the menu bar, click **Device > Firmware Update**.

Result: The **Firmware Update** screen appears.



2. Perform either of the steps:
 - a. When you select **Server** in the **Update Firmware From** section, the available firmware packages from the server are listed in the **Firmware Package List**, where you can select and update or download to your PC.
 - b. When you select **PC** in the **Update Firmware From** section, you can select the firmware package which is already downloaded on your PC.

Updating the Firmware

You can update the firmware from the **Server** or **PC**.

NOTE: To update the firmware from the **Server**, you must have an internet connection.

To update the firmware from the **Server**, perform the following steps:

Step	Action
1	On the Firmware Update screen, select Server in the Update Firmware From section.
2	Select the firmware package from the Firmware Package List and click Update.  NOTE: You can also click the  icon to download the firmware package and save on your PC to update from the PC. Result: An update successful message is displayed at the bottom of the Firmware Update screen.

To update the firmware from **PC**, perform the following steps:

Step	Action
1	On the Firmware Update screen, select PC in the Update Firmware From section.
2	Click the  icon to browse and select the firmware package file from the PC.
3	Click Update. Result: An update successful message is displayed at the bottom of the Firmware Update screen.

Customize Units

Overview

The **Customize Units** function allows you to define units for:

- Length
- Weight
- Motor rating
- Date format
- Temperature

Accessing the Customize Units Dialog Box

On the menu bar, click **Device > Customize Units**.

Result: **Customize Units** dialog box appears.

Selecting Display Units

Select the required units from the **Customize Units** dialog box and click **OK** to apply the changes in the project.

NOTE: The units for the parameters change, depending on the units defined in the **Customize Units** dialog box.

Import the TeSys island Configuration File

Overview

The **Import** function allows you to replace the TeSys island configuration with the configuration file saved on your computer.

The **Import TeSys island Configurator Format** function allows you to import the file generated from the TeSys island Configurator tool. This file includes the island configuration and avatar topology information. This file does not include the avatar parameter settings.

Accessing the Import


On the menu bar, click **Device > Import**.

Importing the Configuration File

NOTE:

- When the DTM is in offline mode, the imported configuration is applied to the offline project.
- Before importing the configuration, make sure that the configuration file is compatible with the connected device.

To import the configuration file to the TeSys island, proceed as follows:

Step	Action
1	On the menu bar, click Device > Import > Import TeSys island Configurator Format. Result: A message box appears. 
2	Click Yes. Result: The Open File dialog box appears.
3	In the Open File dialog box, select the required configuration file (.xml).
4	Click Open. Result: The selected configuration file is imported to the TeSys island.

Import Custom Avatar

Overview

The **Import Custom Avatar** function imports the customized avatar.

Accessing the Function

On the menu bar, click **Device > Import**.

Importing the Customized Avatars

Perform the following steps to import the custom avatar:

Step	Action
1	On the menu bar, click Device > Import > Import Custom Avatar . Result: The Open File dialog box appears.
2	In the Open File dialog box, select the required custom avatar file (.xml).
3	Click Open . Result: The selected custom avatar is imported to the TeSys island.

Export

Overview

The **Export** function allows you to save the TeSys island configuration on your PC.

Accessing the Export

On the menu bar, click **Device > Export**.

Export

You can export:

- **TeSys island Configurator Format**
- **EDS File Format**
An EDS (Electronic Data Sheet) file is a plain text format, and used to specify various descriptive and communication data for hardware devices. The file can be imported in any engineering tool to configure the TeSys island.
- **EDS to L5X File Format**
L5X file is a xml format and used in Rockwell automation systems.
- **AML File Format**
AML file format is an XML format used for data exchange with Siemens TIA Portal automation systems.

- **Predictive Alarms File Format**

Predictive alarms file format is global data block format used for exporting the defined predictive alarms messages for data exchange with Siemens TIA portal automation systems.

To export the **TeSys island Configurator Format** configuration file to your computer, proceed as follows:

Step	Action
1	On the menu bar, click Device > Export > TeSys island Configurator Format . Result: The Save File dialog box appears.
2	In the Save File dialog box, select the required location and click Save . Result: The selected configuration file is exported to your computer.

To export the **EDS File Format**, **EDS to L5X File Format** configuration file to your computer, proceed as follows:

Step	Action
1	On the menu bar, click Device > Export > EDS File Format or EDS to L5X File Format . Result: • If you select the EDS File Format option, the Save File dialog box appears. • If you select the EDS to L5X File Format option, the Select directory dialog box appears.
2	In the Save File or Select directory dialog box, select the required location and click Save . Result: The selected configuration file is exported to your computer.

To export the **AML File Format** configuration file to your computer, proceed as follows:

Step	Action
1	On the menu bar, click Device > Export > AML File Format . Result: • If you select the Create new AML from this configuration option and click Export, the Save File dialog box appears. Use this option when you want to create a new AML file. • If you select the Merge this configuration into existing AML option and click Select, the Open File dialog box appears. Use this option when you have an existing AML file to be merged with this configuration.
2	In the Save File dialog box, select the required location and click Save . Result: The selected configuration file is exported to your computer. In the Open File dialog box, select the AML file to be updated and click Export . Result: The selected configuration file is merged on existing AML file and exported to your computer.

To export the predictive alarms configuration file to your computer, proceed as follows:

Step	Action
1	On the menu bar, click Device > Export > Predictive Alarms File Format . Result: The Save File dialog box appears.
2	In the Save File dialog box, select the required location and click Save . Result: The selected configuration file is exported to your computer.

Factory Reset

The **Factory Reset** function allows you to reset the bus coupler to the factory set values.

When the **Factory Reset** command is executed, this function restores the configuration of the bus coupler to the factory settings and restarts the island.

⚠ WARNING

UNINTENDED EQUIPMENT OPERATION

The Factory Reset function restores the Bus Coupler to a factory state and restarts the island. Verify activating this function does not result in unsafe conditions.

Failure to follow these instructions can result in death, serious injury, or equipment damage.



OK


Cancel

NOTE: The DTM is disconnected from the island after executing this command. When the DTM is reconnected, it is loaded with **no context** scenario.

NOTE: Except **Diagnostics Tab > Device View** tab, all other tabs are disabled.

Troubleshooting

Problem	Probable cause	Solution
Context file not found on the device. Only diagnostic device view is available 	The DTM, which connects to a bus coupler has not been configured.	User must disconnect and exit back to the home screen of SoMove (the engineering tool) and configure a new project (Create project OFF-line). Once that project is created with avatars and an IP address for the bus coupler, choose Store to Device and connect back to the island to configure it.
Download not possible. Please check the following and try again: - Verify the connection to the device - Verify that the system is not in test mode - Verify that no other engineering tools are connected to the device 	Probable cause 1 The DTM tries to store a configuration to the bus coupler, but it is rejected. This could happen if there is a mismatch between versions of the DTM and the bus coupler firmware. Probable cause 2 This message will also display if the bus coupler reference is inconsistent, i.e. storing a configuration for a profinet bus coupler (TPRBCPFN) on an EtherNet/IP bus coupler (TPRBCEIP).	Solution 1 Check the compatibility matrix from the release notes and then verify with your DTM and firmware version if it matches.
Cannot download the firmware. Cannot validate the file 	This message is shown if the DTM tries to store a firmware image on the bus coupler but it is considered invalid. This could happen if the image was corrupted during download. However: if you are participating in a field trial or using an internal device from a Schneider Electric employee that could potentially be a prototype, the likely reason for this message is that the firmware and the bus coupler do not have a consistent signature.	Prototype bus couplers must use prototype-signed firmware. Production bus couplers must use production-signed firmware. NOTE: The firmware on the SESU server or se.com is always production firmware.

Problem	Probable cause	Solution
This avatar as configured cannot be added due to capacity constraints of the island. Removing or reconfiguring another avatar may be required to allow adding this avatar  DTM can only have a maximum of 5 – Starters with current rating >= 65A Please reconfigure it to continue 	The constraints are: - Maximum of 21 bus devices, (20 starters + 1 VIM or 20 starters + 1 SIM). 21 starters is invalid - Maximum of 5 Starters with current rating >= 65A devices active (a reverser avatar counts as 1 Starters with current rating >= 65A, because only one is ever on at a given moment) - Maximum of ~15 avatars (depends on specific avatars) with Profibus	Remove avatar, IO module, or split up into two islands if this constraint arrives.
Before configuring the TeSys island, update the firmware. Launch firmware update function from the device menu. 	The DTM you have used to connect to TeSys island is detecting an older version of firmware that it knows is incompatible.	Check the release notes and ensure you are using the right DTM, updated your TeSys island firmware to the compatible version, then proceed. To update the firmware, follow the below steps: 1. Save the DTM project (or open a new instance of SoMove). 2. Connect the DTM project to the device (do not store a config, load one). 3. Update the firmware. 4. Then, go back to your configuration and store it.

Index

A	
Avatar	45
Analog I/O Avatar	75
Application Avatar	84
Load Avatar	75
Switch Avatar	72
System Avatar	57
C	
Control Panel	114
Customize Units	120
cybersecurity	
firewall	13
guidelines	12
LANMAN / NTLM	14
local area connection	13
network interface cards	12
remote desktop	14
D	
DIAGNOSTICS	88
E	
ENERGY MONITORING	106
Export	123
F	
Firmware Update	118
I	
Import	121
L	
Launching the TeSys island	30
M	
MY AVATAR	49
MY ISLAND Tab	40
S	
SETTINGS	56

Schneider Electric Industries SAS

35 rue Joseph Monier
92500 Rueil Malmaison
France

www.se.com

As standards, specifications, and design change from time to time, please ask for confirmation of the information given in this publication.

© 2026 Schneider Electric. All rights reserved.

8536IB1907-07