

LOGIC CONTROL UNIT

Logic Control Unit MCO Sense Edition


The MCO Logic Unit controls functions in the Esmi Sense Fire Detection System. The MCO communicate with the FDP panel via the INFO serial communication line.

The logical functions of the MCO are configured with the MCO configuration tool. The MCO unit can control addressable outputs, control panel outputs and OC100R and OC100L outputs. MCO is compatible with Esmi Sense FDP panels and FX3Net system.



Mechanical installation

Figure 2. Logic Control Unit MCO Sense Edition Mechanical installation



Technical information

Table 1. Logic Control Unit MCO Sense Edition technical data

Product number	FFS00703854
Dimensions (W x H x D)	379 x 231 x 54 mm
Weight	2,1 kg
Colour	White
Operating Temperature	+5°C ... +40°C
Humidity	max. RH 95%
Operating Voltage	19 ...30 VDC
Standby current	50 mA
Serial communication ports	In: RS485 or RS232 Out: RS485
IP Rating	IP30


Schneider Electric Fire & Security Oy reserves the right to make modifications

Product Codes

Table 2. Logic Control Unit MCO Sense Edition product codes

Product	Code	Description
MCO	FFS00703854	Panel version, wall mounting
MCOX-OB	FFS00703835	PCB version. Card slot mounting
OC-100L	FFS00703843	Open collector output for 100 LEDs
OC-100R	FFS00703844	Open collector output for 100 relays
COL-10	FFS00703846	10 LED cable
CCLO	FFS00703845	Connection cable for 10 LED output, 3m
RB20	FFS00703847	Relay board of 20 relays

Electrical connections



Note! Both 24V power inputs must be connected.

Settings and LED indications

A dip switch

Table 3. Logic Control Unit MCO Sense Edition settings and LED indications

A1	OFF	NA
	ON	NA
A2	OFF	NA
	ON	NA
A3	OFF	FDP-panel connection
	ON	ESA/MESA panel connection (message set F or older)
A4	OFF	Not in use
	ON	
A5	OFF	Not in use
	ON	

A6	OFF	Not in use
	ON	
A7	OFF	Not in use
	ON	
A8	OFF	Normal state
	ON	Acknowledge to erase configuration memory

B dip switch

B1	OFF	"EXT" isolated line faults monitored
	ON	"EXT" isolated line faults not monitored
B2	OFF	"EXT" isolated line not in use
	ON	"EXT" isolated line in use
B3	OFF	OUT "B" port not in use
	ON	OUT "B" port in use
B4	OFF	"EXT" isolated port baud rate. See table below.
	ON	"EXT" isolated port baud rate. See table below.
B5	OFF	"EXT" isolated port baud rate. See table below.
	ON	"EXT" isolated port baud rate. See table below.
B6	OFF	IN "A" port baud rate 1200
	ON	IN "A" port baud rate 9600
B7	OFF	IN "B" port baud rate 1200
	ON	IN "B" port baud rate 9600
B8	OFF	To be "OFF"! Only for service purposes.
	ON	

“EXT” isolated port baud rate

B4	B5	“EXT” port baud rate
OFF	OFF	1200
ON	OFF	2400
OFF	ON	4800
ON	ON	9600

LED indications in normal use

LED	State	Description
LED 1	Continuous	Faults in configuration file
	Blinking (1s)	Configuration state
	Blinking quickly (100 ms)	Waiting for the acknowledge of the erasure of the configuration memory
LED 2	Continuous	MCO logical error
	Blinking(1s)	MCO logic ok
LED 3	Blinking slowly(4s)	MCO installed but not configured
	Continuous	Power supply input 1 or 2 fault
LED 4	Blinking	NA
	Continuous	IN “A” line fault
LED 5	Blinking	IN”A” HW fault
	Continuous	OUT “B” line fault
LED 6	Blinking	OUT “B” HW fault
	Continuous	“EXT” isolated line fault
LED 6	Blinking	“EXT” isolated HW fault

Note! In system fault all LED indications are continuous.

LED indications in start up condition (10 seconds)

LED	State	Description
LED 1	Continuous	Display HW installed
	OFF	Display HW not installed
LED 2	Continuous	Isolated port installed
	OFF	Isolated port not installed
LED 3	Continuous	NA
	OFF	NA
LED 4	Continuous	LED board connector installed
	OFF	LED board connector not installed
LED 5	Continuous	NA
	OFF	NA
LED 6	Continuous	MCO HW installed
	OFF	MCO HW not installed

Jumpers for service purposes

Jumper	ON	OFF
Program update	Program update	Normal use
Configuration	Configuration state	Normal use

Configuration

The configuration is done with MCO configuration tool via incoming RS232 serial port. During the configuration of the MCO unit the communication line to the FDP panel (RS485) must be disconnected. INFO protocol must be configured / enabled on the used port on fire panel (RS485 or RS232).

Configuration memory erasure


The configuration memory can be erased back to the factory defaults by the following:

- disconnect power from the unit (power inputs PI1 and PI2)
- set "config" jumper ON
- turn panel ID number switches to E and F (E = 10's, F=1's)
- connect power back
- follow the LED number 1:
 - when the LED is blinking quickly turn dip switch A8 ON
 - LED1 OFF: erasure in progress
 - LED ON continuous: erasure is ready
- disconnect power, set ID switches back to "0" and remove the "config" jumper
- connect power back
- unit is starting without configuration data


Software update

The unit is set to software update state by setting "prog update" jumper ON and restarting the panel (by pressing the CPU reset button). The software update is done with PC loader software via incoming RS232 serial port. During the software update of the MCO unit communication line to the FDP panel (RS485) must be disconnected.


Electrical connections of OC-100L and OC-100R



Electrical connections RB-20



System principle



Note!

Only one MCO unit can be connected to the FDP Fire Detection system.
The maximum number of MCO, MCOX-OB, FMP, DAP, REP, REPX-OB, ZLPX and ZLPX-IC units connected to one FDP panel is 16.
The RS232 setting is used for the configuration and software update.
The RS232 and RS485 on IN port may not be connected at the same time.
The INFO-line in the MCO (MCOX-OB) unit must be disconnected during the MCO (MCOX-OB) configuration.

Note!

The maximum RS485 cable length between 2 devices is 1000 m.
The maximum RS232 cable length is 10 m.
The dimensioning of power supply cables must be calculated separately. An extra power supply unit must be used as needed.