

ASCO 7000 SERIES ACTB

Automatic Closed-Transition Transfer & Bypass-Isolation Switches

H design 600 through 1200 A

Operator's Manual

381333-194 B
9/2016

DANGER

DANGER is used in this manual to warn of a hazard situation which, if not avoided, will result in death or serious injury.

WARNING

WARNING is used in this manual to warn of a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION is used in this manual to warn of a hazardous situation which, if not avoided, could result in minor or moderate injury.

Refer to the outline and wiring drawings provided with your 7000 Series ACTB for all installation and connection details and accessories.

Refer to *Group 5 Controller User's Guide* 381333-126 for ATS status display messages, time delays, pickup & dropout settings, and adjustments.

Rating Label

Each 7000 Series 7ACTB contains a rating label to define the loads and fault circuit withstand/closing ratings. Refer to the label on the Transfer Switch for specific values.

WARNING

Do not exceed the values on the rating label. Exceeding the rating can cause personal injury or serious equipment damage.

An experienced licensed electrician must install the 7ACTB.



600-1200 amp sizes

This page left blank intentionally.

Table of Contents

Rating Label	1
Nameplate	4
Catalog Number Identification	4
 Installation	5
Remove the Skid	5
Supporting Foundation	5
Mounting	5
Line Connections	5
Testing Power Conductors	5
Connecting Power Conductors	5
Controller Ground	5
Harnesses	5
Engine Starting Contacts	6
Auxiliary Circuits	6
Functional Test	6
Functional Test – Voltage Checks	7
Functional Test - -Electrical Operation	8
 Testing & Service	9
Transfer Test	9
Preventive Maintenance	9
Replacement Parts	9
Disconnecting the Controller	9
Manual Load Transfer	9
Trouble-Shooting	10
Maintenance Handle	10
 Bypassing & Isolating	12
Bypassing the ATS	12
To Bypass Normal Source	13
To Bypass Emergency Source	13
Isolating the ATS	14
Contact Inspection	15
Return to Service	16
To Un-Bypass Normal Source	18
To Un-Bypass Emergency Source	18
 Index	19


Nameplate

The Transfer Switch nameplate includes data for each specific 7000 Series ACTB. Use the switch only within the limits shown on this nameplate. A typical catalog number is shown below with its elements explained.

Catalog Number Identification

Typical 7000 Series ACTB catalog no. for switched neutral, 3 pole, 600 amp, 480 V, in Type 1 enclosure:

H7ACTB	B	3	600	N	5	C
Frame & Series	Neutral	Phase Poles	Amperes	Voltage	Controller	Enclosure
	A-solid	2-single	600	C 208	K 415	5- standard
	B-switch	3-three	800	D 220	L 440	5X- if accessories ordered
	blank- none		1000	E 230	M 460	C- Type 1
			1200	F 240	N 480	F- Type 3R
				G 277	P 550	G- Type 4
				H 380	Q 575	L- Type 12
				J 400	R 600	blank- open type



Open-type H7ACTB with the lower door open (transfer switch shown).

Installation

ASCO 7000 Series Automatic Transfer & Bypass-Isolation Switches (7ACTBs) are factory wired and tested. Field installation requires mounting and connection of service cables, and auxiliary control circuits (if required).

Remove the Shipping Skid

Open the enclosure's lower front door and also remove the lower rear access panel. Then remove the four lag screws (2 in front, 2 in rear) securing the enclosure to the shipping skid.

Supporting Foundation

The supporting foundation for the enclosure must be level and straight. Refer to the applicable enclosure outline drawing included with the switch for all mounting details including door opening space.

If bottom cable entry is used, the foundation must be prepared so that the conduit stubs are located correctly. Refer to the enclosure outline drawing for specified area and location. Provide cable bending space and clearance to live metal parts. When a concrete floor is poured, use interlocking conduit spacer caps or a wood or metal template to maintain proper conduit alignment.

Mounting

Refer to the applicable enclosure outline drawing furnished with this switch and mount the automatic transfer switch according to details and instructions shown on diagram.

Line Connections

Refer to the Wiring Diagram provided with the switch. All wiring must be made in accordance with the National Electrical Code and local codes.

Do not remove the barrier from the transfer switch. Always protect the transfer switch, bypass switch, and isolation contacts and mechanisms from construction grit and metal chips when cabling.



De-energize the conductors before making any line or auxiliary circuitry connections. Be sure that Normal and Emergency line connections are in proper phase rotation. Place engine generator starting control in the OFF position. Make sure engine generator is not in operation.

Testing Power Conductors

Do not connect the power conductors to the transfer switch until they are tested. Installing power cables in conduit, cable troughs and ceiling-suspended hangers often requires considerable force. The pulling of cables can damage insulation and stretch or break the conductor's strands. For this reason, after the cables are pulled into position, and before they are connected, they should be tested to verify that they are not defective or have been damaged during installation.



Protect the switch from construction grit and metal chips to prevent malfunction or shortened life of the 7ACTB switch.

Connecting Power Conductors

After the power cables have been tested, connect them to the appropriate terminal lugs on the bypass switch as shown on the wiring diagram provided with the switch. Make sure the lugs provided are suitable for use with the cables being installed. Standard terminal lugs are solderless screw type and will accept the wire sizes listed on the drawings provided with the 7ACTB. Be careful when stripping insulation from the cables; avoid nicking or ringing the conductor. Remove surface oxides from cables by cleaning with a wire brush. When aluminum cable is used, apply joint compound to conductors. Tighten cable lugs to the torque specified on rating label.

Controller Ground

A grounding wire must be connected to the controller's lower left mounting stud. Because the controller is mounted on the enclosure door, a conductive strap must be used between the enclosure and the door. This connection provides proper grounding which does not rely upon the door hinges.

Harnesses

The transfer switch is connected to the left side of the controller by a plug-in harness (two plugs).

Installation

Engine Starting Contacts

All customer connections, including the engine control contact connections, are located on terminal block TB which is mounted on the top right side of the enclosure. Refer to the wiring diagram provided with the automatic transfer switch and connect the engine start wires to the appropriate terminals. See Figure 1 and Table A.

Table A. Engine start connections.

When normal source fails	Terminals on transfer switch
contact closes	TB1 and TB2
contact opens	TB1 and TB3

Auxiliary Circuits

Connect auxiliary circuit wires to appropriate terminals on transfer switch terminal block TB as shown on the wiring diagram provided with this automatic transfer switch.




Figure 1. Customer terminal block on the top right side of the enclosure.

Functional Test

The Functional Test consists of two checks:

- 1 - Voltage Checks, page 7
- 2 - Electrical Operation, page 8

! CAUTION

Do these checks in the order presented to avoid damaging the ACTB.

Read all instructions on the Wiring Diagram and labels affixed to the automatic transfer switch. Note the control features that are provided and review their operation before proceeding.

Continue to **1 – Voltage Checks** on next page.

Installation




Figure 2. Standard controls and indicators.

Functional Test

Read all instructions on the *Wiring Diagrams* and labels affixed to the 7ACTB. Note the control features that are provided and review their operation before proceeding.

After installing the 7ACTB check the following:

- Bypass Handle should be in the *NORMAL* position.
- Isolation Handle should be in the *CONN* position.
- CN transfer switch should be C (closed)
- CE transfer switch should be O (open)

If handles are not in correct positions, follow instructions for Bypassing and Isolating the automatic transfer switch on pages 12-18. **Do not force the handles.** Electrical interlocks prevent a wrong sequence of operation.

1 – Voltage Checks

First check nameplate on transfer switch; rated voltage must be the same as normal and emergency line voltages.

DANGER

Use extreme caution when using a meter to measure voltages. Do not touch power terminals; shock, burns, or death could result!

Perform steps 1 through 6 at the right. Observe the status lights. See Figure 2

■ Black square means light is on.

□ White square means light is off.

* If necessary, adjust voltage regulator on generator per the manufacturer's recommendations. The ACTB will respond only to rated voltage specified on the nameplate.

Now continue to 2 – **Electrical Operation** on next page.

1 Close the normal source circuit breaker. The Transfer Switch Connected To Normal and the Normal Source Accepted lights should come on.	
2 Use an accurate voltmeter to check phase to phase and phase to neutral voltages present at the transfer switch normal source terminals.	
3 Close the emergency source circuit breaker. Turn the Engine Control switch to Run to start the generator. The Transfer Switch Connected To Normal & Emergency Source Accepted lights should come on.	
4 Use an accurate voltmeter to check phase to phase and phase to neutral voltages present at the transfer switch emergency source terminals.*	
5 Use a phase rotation meter to check phase rotation of emergency source; it must be the <u>same</u> as the normal source.	
6 Turn the Engine Control switch to Auto to stop the generator. The Emergency Source Accepted light should go off. Then put the starting control selector switch (on the generator set) in the automatic position. Close the enclosure door.	

Installation




Figure 3. Standard controls and indicators.

2 – Electrical Operation

This procedure checks electrical operation of the ACTS.



Close enclosure door before proceeding to prevent personal injury in case of electrical system fault.

Transfer Test

The ATS should still be bypassed. Both normal and emergency sources must be available and the emergency source generator (if used) must be capable of being started; put engine starting control in *automatic* position. The *Transfer Switch Connected to Normal* light and the *Normal Source Accepted* light should be on.

1. Turn the **Isolation Handle** counterclockwise to the **TEST** position.

NOTE: The engine generator may be signaled to start while turning the Isolation Handle. If emergency source is available, the ATS may operate to the emergency position. If it does, operate **Retransfer Delay Bypass** switch.

2. Perform steps 1–5 at right. Observe the status lights. See Figure 3.

■ Black square means light is on.

□ White square means light is off.

3. Turn the **Isolation Handle** clockwise to the **CONN** (connected) position.
4. Turn the **Bypass Handle** clockwise to the **OPEN** position.

** If you do not want closed-transition transfer, press the Closed Transition Bypass pushbutton while the controller display shows Waiting for In-Sync. This action causes open-transition (momentary load interruption) transfer to the opposite source, if conditions permit. Also refer to the Group 5 Controller User's Guide 381333-126.

<p>1</p> <p>The <i>Transfer Switch Connected To Normal</i> and <i>Normal Source Accepted</i> lights should be on.</p>	
<p>2</p> <p>Turn and <u>hold</u> Transfer Control switch clockwise to <i>Transfer Test</i> until the engine starts and runs (within 15 sec.). <i>Emergency Source Accepted</i> light should come on.</p>	
<p>3</p> <p>Transfer switch CE closes and then transfer switch CN opens (closed-transition overlap). The <i>Transfer Switch Connected To Emergency</i> light should come on and the <i>Transfer Switch Connected to Normal</i> light goes off (you might see and hear the brief overlap transfer). **</p>	
<p>4</p> <p>Transfer switch will operate back to Normal position after Feature 3A time delay. For immediate retransfer turn Transfer Control counter-clockwise to <i>Retransfer Delay Bypass</i>. The <i>Transfer Switch Connected To Normal</i> light should come on; <i>Transfer Switch Connected to Emergency</i> light should go off.</p>	
<p>5</p> <p>The engine-generator will stop after the Feature 2E time delay (unloaded running engine cooldown). The <i>Emergency Source Accepted</i> light should go off.</p>	

This completes the Functional Test of the 7ACTB

Testing & Service

TRANSFER TEST

Test the Automatic Transfer Switch portion of the 7000 Series 7ACTB at least once a month. This procedure checks the electrical operation of the Transfer Switch and Controller. Put the engine-generator starting control (at the engine-generator set) in automatic mode.

In the following test the generator will start, the load will be transferred to the Emergency source, then back to the Normal source. With both sources available the load will be transferred in a closed-transition mode.

WARNING

Be sure to close the enclosure door before proceeding to prevent personal injury in case of electrical system fault.

Perform the five-step **Electrical Operation – Transfer Test** procedure on page 8.

PREVENTIVE MAINTENANCE

Reasonable care in preventive maintenance will insure high reliability and long life for the 7000 Series 7ACTB. An annual preventive maintenance program is recommended.

ASCO Power Services, Inc. is ASCO Power Technologies service organization for the United States and Canada. Call 1-800-800-2726 (ASCO) to request a service call and information on preventive maintenance agreements.

Annual Inspection Checklist

DANGER

Hazardous voltage capable of causing shock, burns, or death is used in this switch. Deenergize both Normal & Emergency power sources before performing inspections!

Cleaning the 7ACTB enclosure

Brush and vacuum away any excessive dust accumulation. Remove moisture with a clean cloth.

Check the transfer switch contacts.

Bypass, isolate, and withdraw the transfer switch. Then remove the transfer switch interphase barriers and check the condition of the contacts. Replace contacts when pitted or worn excessively. Reinstall the interphase barriers carefully. See page 15

Maintain transfer switch lubrication.

If switch is subjected to severe dust or abnormal operating conditions, renew factory lubrication on all movements and linkages. Relubricate solenoid operator if TS coil is replaced. Don't use oil; order ***lubrication kit 75-100***

Check all cable connections & retighten them.

REPLACEMENT PARTS

Replacement parts are available in kit form. When ordering parts provide the Serial No., Bill of Material No. (BOM), and Catalog No. from the transfer switch nameplate. Contact your local ASCO Power Technologies Sales Office or ASCO Power Services, Inc.

In the United States and Canada
call 1 – 800 – 800 – ASCO (2726)

DISCONNECTING THE CONTROLLER

The harness disconnect plugs are furnished for repair purposes only and should not have to be unplugged. If the controller must be isolated, follow these steps.

DANGER

Bypass–Isolation Switch is energized! Do not touch isolation contact fingers; shock, burns, or death could result!

Disconnecting the Plugs

1. Bypass and Isolate the Automatic Transfer Switch.
2. Open the upper enclosure door.
3. Separate the two quick disconnect plugs by squeezing the latches. Do not pull on the harness wires.

Reconnecting the Plugs

1. The ATS should be still bypassed and isolated.
2. The two harness plugs and sockets are keyed. Carefully align the plugs with the sockets and press straight in until the latches click.
3. Close the enclosure doors.
4. Follow *Return to Service* instructions on page 16.

MANUAL LOAD TRANSFER

This procedure manually transfers load to other source if the Transfer Switch or Control Panel are out of service.

WARNING

Close enclosure doors to prevent personal injury in case of electrical system fault.

1. Bypass the connected ACTB source. Turn Bypass Handle to *EMERGENCY* or *NORMAL* (page 13).
2. Isolate to Test. Turn the Isolation Handle to *TEST* position (see page 14).
3. Turn the Bypass Handle to *OPEN*, then to the other source (see page 12). The load will be interrupted.
4. Turn the Isolation Handle clockwise to the *CONN* [connected] position (see page 15).

Testing & Service

TROUBLE-SHOOTING

Note any optional accessories that may be furnished on the 7ACTB and review their operation. Refer to any separate drawings and/or instructions that may be packed with the 7ACTB. See Table B.

DANGER

Hazardous voltage capable of causing shock, burns, or death is used in this switch. Do not touch the power or load terminals of the bypass switch or transfer switch!

Table B. Trouble-Shooting Checks.

PROBLEM	CHECK IN NUMERICAL SEQUENCE		
	1 OPERATION	2 GEN-SET	3 VOLTAGE
Engine-generator set does not start when the Transfer Control switch is turned and <u>held</u> in <i>Transfer Test</i> position or when normal source fails.	Hold <i>Transfer Test</i> switch 15 seconds or the outage must be long enough to allow for Feature 1C time delay plus engine cranking and starting time.	Starting control must be in the automatic position. Batteries must be charged and connected. Check wiring to engine starting contacts.	-
Transfer switch does not transfer the load to the emergency source after the engine-generator set starts.	Wait for Feature 2B time delay to time out (if used)	Generator output circuit breaker must be closed. Generator frequency must be at least 95% of nominal (57 Hz for a 60 Hz system.) *	Voltmeter should read at least 90% of nominal phase to phase voltage between transfer switch terminals EA and EC (or EL1 and EL2 for 2 pole switches). *
Transfer switch does not transfer the load to normal source when normal returns or when the Transfer Control switch is released.	Wait for Feature 3A time delay to time out (if used)	-	Voltmeter should read at least 90% of nominal phase to phase voltage between transfer switch terminals NB and NC, NC and NA, and NA and NB (or NL1 and NL2 for 2 pole switches).
Engine-generator-set does not stop after load retransfer to the normal source.	Wait for Feature 2E time delay to time out (if used)	Starting control must be in the automatic position.	-
<i>Failure to Synchronize</i> light comes on.	Conditions of Normal or Emergency Sources not suitable for closed transition transfer. Recheck voltage and frequency of both sources. Press Alarm Reset pushbutton.		
<i>Extended Parallel Time</i> light comes on.	CN and CE contacts are closed longer than setting in the Controller. Open the disconnected source circuit breaker, then call your nearest ASCO Service Center for assistance.		
<i>TS Locked Out</i> light comes on.	Transfer lockout operation has occurred; transfer switch is disabled from automatic operation. Open the disconnected source circuit breaker, then call your nearest ASCO Power Services, Inc. for assistance		

These are factory settings. Refer to the **Controller User's Guide**.

If the problem is isolated to circuits on the controller or the transfer switch, call your local ASCO Power Technologies sales office or ASCO Power Services, Inc.: in the United States or Canada, call 1-800-800-2726. Furnish the Serial No., Catalog No., and Bill of Material (BOM) No. from the transfer switch nameplate.

MAINTENANCE HANDLE

DANGER

Bypass and isolate the Transfer Switch before using the maintenance handle! See pages 12-15. Remove the maintenance handle after using it; store it inside.

1. Bypass, isolate, and withdraw the transfer switch (pages 12 through 15). Then locate and remove the maintenance handle from the clip (inside lower left side). Insert the handle onto the shaft on the left side of the operator of the transfer switch. See Figures 4, 5, 6 and Table C.
2. Move the maintenance handle up or down as shown to manually operate the transfer switch. Operate both upper and lower contact shafts. Observe the window indicators (right side). Remove the maintenance handle and store it on the lower left side.







Figure 4. Contact position indicators

ATS Position		Handle	Indicators
Normal			E = O upper contacts open N = C lower contacts closed
Emergency			E = C upper contacts closed N = O lower contacts open

Note: If Normal and Emergency connections are reversed this operation is also reversed.




Figure 4. Maintenance handle operation for Emergency source contacts (upper shaft).






Figure 5. Maintenance handle operation for Normal source contacts (lower shaft).



Bypassing & Isolating




Figure 7. Status lights and Engine Control.




Figure 8. Status lights for Transfer Switch main contact position.




Figure 9. Status lights for Transfer Switch isolation contact position.

BYPASSING THE ATS*

This procedure explains how to Bypass the closed transfer switch contacts. Bypassing is required before the Transfer Switch can be tested or isolated. The Bypass Switch Handle must be in the *OPEN* position (green window indicator) and the Isolation Handle must be in the *CONN* [connected] position (window indicator). The *TS Connected* light must be on. See Figures 7, 8, and 9.

! CAUTION

You can only bypass to the same source that the Transfer Switch is connected. Solenoid interlock prevents incorrect operation.

1. Observe which *Transfer Switch Connected To* light is on (*Normal* or *Emergency*) on the door. This is the position of the transfer switch (see Figure 8).
2. Follow the directions on next page to Bypass to the same source as connected to transfer switch (select *Normal* or *Emergency*).




Figure 10 Bypass Handle and three position window indicators.

Allowable Positions of the Bypass Switch in relation to Positions of the Transfer Switch
(with Isolation Handle in the *Conn* [connected] position and *TS Connected* light on)

Transfer Switch	Bypass Switch can be in either	
If Transfer Switch is in Normal position	Open or	Normal
If Transfer Switch is in Emergency position.	Open or	Emergency


Bypassing & Isolating

To Bypass Normal Source*

(Load connected to Normal Source)

The Transfer Switch Connected To Normal light is on and Transfer Switch Connected To Emergency light is off.

Push in the handle and turn it counterclockwise.*



Push in* the Bypass Handle all the way, then turn it counterclockwise until *Bypass Switch Position* shows closed on NORMAL (yellow window indicator). The green light *Bypassed to Normal* will come on and the amber light *Not In Automatic* will flash.




Figure 11. Bypass to Normal diagram.





Figure 12. Status light and window indicator for Bypassed to Normal Source.

To Bypass Emergency Source*

(Load connected to Emergency Source)

The Transfer Switch Connected To Emergency light is on and Transfer Switch Connected To Normal light is off.

Turn the handle clockwise.*



Turn* the Bypass Handle clockwise until *Bypass Switch Position* shows closed on EMERGENCY (yellow window indicator). The red light *Bypassed to Emergency* will come on and the amber light *Not In Automatic* will flash.




Figure 13. Bypass to Emergency diagram.





Figure 14. Status light and window indicator for Bypassed to Emergency Source.

The automatic transfer switch can now be put in the *TEST* or *OPEN* position. See **ISOLATING** on page 14.

* **NOTE:** When Accessory 40*B (reversed Normal & Emergency connections) is specified, the handle operation is reversed. Follow instructions on the door.

Bypassing & Isolating

ISOLATING THE ATS

Isolating is required before any service work can be performed on the automatic transfer switch (ATS). Refer to Figures 15, 16, 17 and 18.

1. Bypass the closed automatic transfer switch contacts. See **BYPASSING** on pages 12 and 13.
2. Turn the Isolation Handle counterclockwise (approx. 8 turns) until window shows *TEST*. The *TS Test* amber light should come on. The ATS can be tested now without load interruption (see page 9).




Figure 15. CONNECTED to TEST position.

NOTE: In the TEST position the transfer switch solenoid operator circuit is energized through secondary disconnects.

DANGER

Hazardous voltage capable of causing electrical shock, burns, or death; do not touch any control circuit terminals.

3. Continue turning Isolation Handle counterclockwise (approx. 6 turns) until the window shows *ISOLATE*. The *TS Isolated* amber light should come on.




Figure 17. TEST to ISOLATE position.






Figure 16. Isolation Handle turned to TEST.




Figure 18. Isolation Handle turned to ISOLATE

Bypassing & Isolating

- Open the lower enclosure door. Pull out both left and right side rails then use the two tab handles to roll out the transfer switch. It can be safely inspected in this position. The transfer switch can also be removed for easier maintenance operations. See Figure 19.

DANGER

Hazardous voltage capable of causing electrical shock, burns, or death; do not touch any control circuit terminals




Figure 19. Transfer switch isolated and pulled out for inspection.

See page 10 for maintenance handle use. A lifting yoke 734408 is available to facilitate lifting by using an overhead crane or similar equipment. See **WARNING**

WARNING

The Transfer Switch weighs 165–235 lbs. depending upon the number of poles. Use lifting device 734408 or other device capable of lifting this weight to avoid personal injury or equipment damage. Two persons are recommended

Contact Inspection

The main contacts are protected by arcing contacts. The arcing contacts make first and break last to avoid arcing at the main contacts. Contact condition should be checked annually. Contacts should be replaced when contact material becomes severely worn. Discoloration is normal. Do not file contacts because it wastes material. Instead use light emery paper to clean up the contact surfaces.

If the contacts need to be replaced see page 10

DANGER

To prevent the possibility of fatal electrical shocks and burns, bypass, isolate, and withdraw the transfer switch before working on it.

The contact assemblies (two for each pole) are located to the right of the operator mechanism.

- Deenergize transfer switch** (pages 12 thru 15)
Bypass, isolate, and withdraw transfer switch. Use a voltmeter to verify that no electrical power is present at the transfer switch terminals.
- Use the maintenance handle** (page 10).
Open the contacts that will be inspected by using the detachable maintenance handle.
- Remove the interphase barriers** (Figure 20).
Use a blade screwdriver to loosen (ccw) four round-head screws holding each barrier to the arc chutes. Slide barrier up until keyholes clear the round-head screws, then remove it.




Figure 20. Interphase barrier removal

- Remove the arc chutes.**
Use a 5/8" nutdriver to remove (ccw) two long insulator nuts. Then pull the arc chute outward (off the long threaded rods). See Figure 20.

Bypassing & Isolating

5. Remove the movable contact cover.

Use your thumb and fingers to squeeze the sides inward until the contact cover is released from the shaft clamp (both sides). Then remove the movable contact cover. See Figures 21 and 22.




Figure 21. Movable contact cover release




Figure 22. Movable contact cover removal

6. Reinstall the movable contact cover.

After inspection reinstall the movable contact cover onto the movable contact assembly. Use your thumb and fingers to squeeze the sides inward until the contact cover is latched onto the metal bracket (both sides). Figures 21 & 22.

7. Reinstall the arc chute.

Slide the arc chute (arc splitters toward the contacts and recess for nuts outward) between the two long threaded rods. Reinstall the two long insulator nuts (round shoulder in) and use a 5/8" nutdriver to GENTLY tighten (cw) until snug. Do not overtighten these nuts. See Figure 20.

8. Reinstall the interphase barrier.

Install the barrier over the arc chutes and slide it up until the four round-head screws align in the four keyholes in the barrier. Then slide the barrier down. Use a blade screwdriver to tighten (cw) the four round-head screws to secure the barrier to the arc chute insulator nuts. See Figure 20.

RETURN TO SERVICE

This procedure explains how to return the automatic transfer switch (ATS) to service after inspection and maintenance. Observe the *Bypass Switch Position* indicator and lights).

1. Use the two tab handles to roll the transfer switch into the enclosure (isolation contacts facing inward) until the crank bearings stop against the draw-in plates. Next push in both side rails and close the enclosure door.




Figure 23. Transfer switch isolated and pulled out for inspection.

WARNING

Close the enclosure door to prevent personal injury in case of electrical system fault.

2. Turn Isolation Handle clockwise (approx. 6 turns) until the window shows *TEST* and *TS TEST* light comes on.




Figure 24 *ISOLATE* to *TEST* position.

Bypassing & Isolating





Figure 25 Isolation Handle turned to *TEST*

- The ATS can be tested now without load interruption (see page 9).

CAUTION

Solenoid interlock prevents you from closing the isolation contacts until the ATS is in the same position as the Bypass Switch.

- Observe which *Bypass Switch Position* window indicator is yellow (*NORMAL* or *EMERGENCY*) at the Bypass Switch Handle. This indicates the source connected to the load.
- Observe which *Transfer Switch Connected To* light is on (*Normal* or *Emergency*) on the door. This is the position of the Transfer Switch. If it is not in the same position as the Bypass Handle change the position of the Transfer Switch as follows:

To change the position of transfer switch

Operate to NORMAL	Operate to EMERGENCY
Turn Transfer Control switch to Retransfer Delay Bypass.	Turn Transfer Control switch to Transfer Test (hold 15 seconds).*
Connected To Normal light should come on.	Connected To Emergency light should come on.

* If Feature 2B time delay is used, there will be a delay before transfer to Emergency

NOTE: With Normal available, the automatic transfer switch will not stay in the emergency position unless Feature 3A time delay is used (at least 30 seconds).

WARNING

Do not close the isolation contacts unless the Transfer Switch (ATS) and Bypass Switch are in the same position!

- When the transfer switch is in the same position as the Bypass Switch handle, continue turning the Isolation Handle clockwise (about 8 turns) until the window shows *CONN* (connected).




Figure 26. *TEST* to *CONN* (connected) position.





Figure 27. Isolation Handle turned to *CONN*

Bypassing & Isolating

RETURN TO SERVICE continued*

This procedure explains how to return the Bypass Switch Handle to the OPEN position. The Bypass Handle must be in the *CLOSED* position (yellow indicator on *NORMAL* or *EMERGENCY*) and the Isolation Handle must be in the *CONN* position (window). See Figures 28, 29 and 30.

CAUTION

You can only bypass to the same source that the ATS is connected. Solenoid interlock prevents incorrect operation.

1. Observe which Bypass Switch Position indicator is yellow (*NORMAL* or *EMERGENCY*) at the Bypass Switch Handle. This indicates the source connected to the load.
2. Un-Bypass to same source as the Bypass Switch Position as follows (select Normal or Emergency).

To Un-Bypass Normal Source*

(Load connected to Normal Source)

The *Transfer Switch Connected To Normal* light is on and *Transfer Switch Connected To Emergency* light is off.

Turn the handle clockwise.*



Turn* the Bypass Handle clockwise until the *Bypass Switch Position* shows OPEN (green window indicator). The *Bypassed to Normal* light should go off and the *Not In Automatic* light should go off.




Figure 29. Un-Bypass Normal diagram.




Figure 28. Bypass Handle and window indicators.

To Un-Bypass Emergency Source*

(Load connected to Emergency Source)

The *Transfer Switch Connected To Emergency* light is on and *Transfer Switch Connected To Normal* light is off.

Turn the handle counterclockwise.*



Turn* the Bypass Handle counterclockwise until the *Bypass Switch Position* shows OPEN (green window indicator). The *Bypassed to Emergency* light should go off and the *Not In Automatic* light should go off.




Figure 30. Un-Bypass Emergency diagram.

The Automatic Transfer & Bypass–Isolation Switch should be left in this position.

* **NOTE:** When Accessory 40*B (reversed Normal & Emergency connections) is specified, the handle push-pull operation is reversed. Follow instructions on the door.

INDEX

A

auxiliary circuits, 6

B

barriers, interphase, 15, 16
bypassing the ATS, 12, 13

C

catalog number, 4
cleaning, 9
closed transition bypass, 8, 9
connections
 power, 5
contact inspection, 15, 16
controller
 disconnecting, 9
 see *Controller User's Guide*

E

electrical operation, 8
Emergency Source Accepted light, 7
engine starting contacts, 6
extended parallel time, 10

F

foundation, 5
frequency, generator, 10
functional test, 6, 7, 8

H

harness, 6
disconnect plugs, 9
help
customercare@ascopower.com
800-800-ASCO (2726)

I

inspection, 12
installation, 5
interphase barriers, 15, 16
isolating the ATS, 14, 15

L

lifting device, transfer switch, 15
lights, 6, 7, 12, 13, 14
load connected to emergency, 7
load connected to normal, 7
lubrication, 9

M

maintenance, preventive, 9
maintenance handle, 11
 warning, 11
manual load transfer, 11
 warning, 11

N

nameplate, 4
Normal Source Accepted light, 7

O

operation
 electrical, 8
 manual, 11
 warning, 11

P

parts, 9
phase rotation, 7
preventive maintenance, 9
problem, 10

R

rating label, 1
replacement parts, 9
return to service, 16, 17, 18

S

service
 ASCO Power Services, Inc., 9
settings
 see *Controller User's Guide*

T

test, functional, 6, 7, 8
testing power cables, 5
time delays, 9
 see *Controller User's Guide*
Transfer Control selector switch
 Retransfer Delay Bypass, 7
 Transfer Test, 7
Transfer Switch Connected To Emergency light, 7
Transfer Switch Connected To Normal light, 7
transfer test, 8, 9
transfer to emergency, 8, 9
transfer to normal, 8, 9
troubleshooting, 10
TS locked out, 10

V

voltage checks, 7
voltage, pickup and dropout settings
 see *Controller User's Guide*

Printed in U.S.A.

ASCO Power Technologies
160 Park Avenue
Florham Park, NJ 07932-1591 USA
Phone: 1 800 800-2726 (ASCO) for sales or service
www.ascopower.com

©2016 ASCO Power Technologies. All Rights Reserved