

## **SECTION 4 INSTALLATION**

Installation of the 584L Programmable Control System depends largely on the user's application requirements. This section provides instructions for installing each of the 584L's system components. A cold start-up procedure is also described in order to prepare the 584L Controller for programming.

### **4.1 INSTALLATION PLANNING**

Prior to connecting and installing the 584L system, it is helpful to plan ahead as to the system's requirements. These requirements obviously change from one application to another. Based upon the user's application a system layout plan and specification can be outlined. The following steps suggest a general procedure in designing your 584L Programmable Control System:

1. Clearly define the control objective.
2. Identify the specific inputs and outputs required to meet your objectives. This is probably the most important task in planning for your system.
3. Develop a system hardware design showing types, quantities, and locations of the units required.
4. Determine the I/O elements specific to application's program.
5. Configure the system.
6. Design the program.

### **4.2 PREPARING FOR INSTALLATION**

The various parts of the 584L control system are packaged in separate containers as follows:

<b>Container</b>	<b>Contents</b>
584L	584L Controller including internal modules, register access panel, and power supply
J200	I/O Expander
J478	Modbus Modem
B240/241	Input/Output Housings (up to three housings per box)
P421/1XX or P451/X22	Auxiliary Power Supply (with cable or interface installed as an option)
B2XX	Input/Output Modules (up to six per box)
425/I427	Remote Channel Driver (with cable attached)

## INSTALLATION

B545/546	Discrete I/O Housings (up to four housings per box)
5540/5541	Input/Output Duct with bus cable (one per box)
B5XX	Input/Output Modules (up to four modules per box: 4, 8, or 12 boxes per carton)
J540	200 to 500 Series I/O Adapter (one per box)

### NOTE

Mounting hardware is not provided with the controller. A machine bolt size of 5/16 x 1-1/2 inches is recommended for use with panel mounted units.

#### 4.2.1 Initial Check-out

The 584L Controller should be checked or powered-up prior to actual installation. As a preliminary step, make a note of the controller's serial number. The number is located on a tag positioned on the top right side of the unit. In all correspondence with Modicon concerning the controller, always specify the unit's type and serial number.



Figure 4-1. 584L Serial Number

## INSTALLATION

The following step by step procedure lists instructions for testing the 584L Controller prior to the unit's installation:

1. Unpack the controller from its carton, and place the unit on a table or floor in an upright position.
2. Connect a three-wire AC power cord to terminals 1, 2, and 3 on the controller's lower right side. For 115 V operation, connect a jumper between terminals 4 and 5. For 220 VAC operation no jumper is required. See Figure 4-2.

### NOTE

The controller is delivered from the factory with a jumper connected between terminals 4 and 5. This sets the power supply for 115 VAC.





Figure 4-2. Power Cord Connection to 584L

3. Plug the cord into an AC power source. Open the front panel and switch the controller's ON/OFF switch to ON. This switch is shown in Figure 4-3.

## INSTALLATION



*Figure 4-3. 584L Power Supply and Battery Pack*

4. Check that the POWER indicator on the front panel is ON. Install the battery pack underneath the controller's power supply as follows:
  - Slide the pack with the securing hole facing down and ribbon cable facing up into the space below the power supply. Ensure that any foreign matter is not being forced into the lip at the rear of the space.
  - Secure battery pack by centering the mounting hole over the stud and pressing down.
  - Insert battery pack cable into connector on the memory board (see Figure 4-3). The red strips on the cable should be facing towards the top.

**NOTE**

The battery pack cable may be connected or disconnected with AC power applied to the mainframe and the ON/OFF switch ON.

5. Ensure that BATTERY OK is ON.
6. If the RUN light does not energize when the POWER OK indicator is ON, or if the batteries were not installed for CMOS memories, the controller should be initialized by one of the following procedures using Modbus Port 2.
  - a. Call the Modicon Service Center and use a telephone interface to enter a new configuration table or a previously stored program.
  - b. Use the P190 Programmer and 584L Configurator Tape to design and load a new configuration table. See P190 Programmer User's Manual for details.
  - c. Use the P190 Programmer and Tape Loader Tape to load a previously recorded program. See P190 Programmer User's Manual for details.
7. With the RUN light ON, verify the operation of the register access panel. Examine and/or change a register's content; examine a discrete input's state and/or disable and enable it. Refer to Section 3.2.1 in this manual.
8. Turn power switch OFF and disconnect power cord.
9. If the controller fails to operate, call your local Modicon Sales Office. Ensure that the controller's serial number, Modicon's job order, and invoice number are available for reference.

**4.3 INSTALLING THE 584L CONTROLLER**

The 584L PC can be installed on any vertical surface capable of supporting its weight. The 584L can also be mounted in a 19 inch rack configuration without adding special hardware or specifying a different packaging option. It is recommended that the controller be mounted relatively high for easy access to the controller's display panel. The unit, however, can be placed anywhere in a cabinet or rack as long as sufficient air flow is possible and the unit is oriented in an upright position.

Mounting hardware for the controller is not provided; 5/16 x 1-1/2 inch machine bolts are suggested for use with panel mounted units. It is further recommended that two workers be assigned when mounting the controller. The controller's mounting dimensions are displayed in Figure 4-4.

**NOTE**

Leave a six inch clearance below the controller for I/O cables.

## INSTALLATION




Figure 4-4. 584L Mounting Dimensions

Instructions for panel mounting the controller are as follows:

1. Start two upper mounting bolts. Rest the controller on the bolts using its rear keyhole slots. Start two lower mounting bolts and tighten all bolts.
2. Install AC power connection to right side of controller. Allow sufficient slack in the power connection in rack installations to allow for easy servicing.
3. For rack mounting, place mainframe into 19 inch rack and secure with six screws starting at the bottom of each side. Slides can be used if provided by user.

### NOTE

Do not install slides to interfere with power connections on the controller's right side.

4. If utilized, install J478 Modbus Modem (maximum two per mainframe) within 50 feet (15.24 meters) of the controller. Cable W192 is used to connect the modem to the controller. Port 1 is next to rear connector on controller's bottom, and Port 2 is on front adjacent to the register access panel. See Figure 4-5.




Figure 4-5. 584L Port's 1 and 2


#### 4.4 200 SERIES I/O INSTALLATION

##### 4.4.1 I/O Housing Installation

The following instructions describe installation procedures for the 200 Series I/O housings. Planning the quantity and locations for the housings should occur prior to installation.

1. Select one B240 or B241 I/O housing and remove the protective tape from its lower right side. See Figure 4-6.

## INSTALLATION



*Figure 4-6. B240 I/O Housing with Protective Tape*

2. Mark the housing's support surface. Loosely bolt the housing into place at the right-most location for that channel. Mounting dimensions for the 200 Series I/O are displayed in Figure 4-7.

### NOTE


If the housing is to attach directly to an auxiliary power supply, the mounting location of the power supply should be marked at this time.

3. Select the next housing and remove the protective tape from both the housing's left and right side.
4. Position the housing to the left of the previous housing and loosely bolt into place.
5. Connectors at the lower left of each housing rotate to mate the housings. This cam connector is shown in Figure 4-8. Rotate the connector of the right-most housing clockwise 180° to engage the mating connectors. Use extreme caution when rotating the cam to avoid damage to the connector.
6. Repeat steps 3-5 until all housings are in place. Securely tighten all mounting bolts. Additional channels are installed accordingly.
7. If no auxiliary power supply is required for the channel being installed (typically Channels I and II), install W600 type cable to left-most I/O housing. Slide box end of cable onto left side of housing as shown in Figure 4-9, until the box almost touches the metal stop. Carefully rotate cam connector to mate housing to cable. It may be necessary to pull box slightly down from the stop to obtain proper position to prevent damage to connectors. Tighten hex head lock screw.

8. Set the address index pins on the housings.

**CAUTION**

Failure to remove protective tape on the left and right side of each I/O housing cammed into another housing could result in faulty operation of the I/O modules within that channel.



INSTALLATION DIMENSIONS

**NOTE:**

IF AUXILIARY POWER SUPPLY IS NOT REQUIRED, 2.5 INCH (64 mm) CLEARANCE TO THE LEFT OF THE B240/B241/J540 IS REQUIRED FOR CABLE CONNECTION.




Figure 4-7. 200 Series I/O Mounting Dimensions

INSTALLATION




Figure 4-8. I/O Housing Cam Connector




Figure 4-9. Attaching W600 Cable

Each channel of 200 Series I/O can accept up to 128 input and 128 output points, which can be configured as eight input and eight output modules (See Figure 4-10). These 16 modules can be mounted four per B240 or B242-004 housing or two per B241 or B242-002. They must all be addressed for the 584L PC by the address index pin. As you can see in Figure 4-10, each input module must have a different number, 1 through 8, and each output module must also have a different number, 1 through 8.




Figure 4-10. Typical Address Scheme for 200 Series I/O

User field wiring can be connected before the I/O modules are installed. It is recommended for user convenience that field wiring be installed prior to the I/O modules. Wiring is routed through the conduit to the terminals from either the top or bottom of the housing. Each terminal is capable of receiving one AWG No. 12 or two AWG No. 14 wires. The smallest recommended wire is AWG No. 24.

#### 4.4.2 I/O Module Insertion


Before installing any I/O modules, the protective metal tape must be removed from the backplane of the housing. To prevent foreign matter from entering the housing and to improve the signal to noise ratio, leave this tape on all locations where a module will not be installed.

## INSTALLATION

### CAUTION

Inserting I/O modules into slots from which the protective metal tape has not been removed may result in improper operation of that module, as well as other modules on that I/O channel.

Insert each module so that its connector pins, both at the rear and front of the module, are mating with the pins of the housing. Then press the module into the housing until the module is fully seated. Tap the module with the hand using moderate force. Extreme pressure is not necessary. Tighten the two captive screws on the front of the module. Refer to Figure 4-11.



*Figure 4-11. Inserting 200 Series I/O Module*

A plastic plate is located on the front of each module. This plate can be engraved by the user to indicate the function of the input or output signal. The plate is also reversible; both sides can be engraved if a change is necessary. A colored terminal identification strip may also be installed to match the color coding of the modules. Refer to Table 3-8.

4.4.3 Inductive Load Protection

If an inductive load, such as a large relay or motor starter, is connected in parallel with an input as shown in Figure 4-12, an inductive spike could be generated when the input opens. This spike could damage the I/O module's input circuitry. To prevent this, an RC network or thyrector can be installed in parallel with the load to absorb inductive energy.




Figure 4-12. Inductive Load Protection on AC Inputs

There can also be occasions when inductive loads must be operated by both contacts and an output from the controller. Figure 4-13 illustrates how this may be done with contact both in series and in parallel with the controller's output. When an output is in series with the contact, the contact must always be wired between the controller output and the load. External pulse suppression is not required if the load is controlled only by the controller's output.

**NOTE**

The RC or thyrector may not be required if the inductive load is less than one Henry since thyrectors are incorporated at the output module.

## INSTALLATION




Figure 4-13. Inductive Load Protection on AC Outputs

### 4.4.4 Cables

I/O cables are connected at the controller's bottom left side. Cable ports on the 584L are assigned the following functions (front to rear):

- Channel I
- Channel II
- Channel III & IV
- Modbus Port I
- J200 I/O Expander

### CAUTION

Do not connect the J200 with the 584L running. Internal circuit board damage to the 584L may result.

If a cable is inserted in a wrong position, it will not damage the controller.

**CAUTION**

Plugging a W600 type cable (typically for either Channel I or II) into the expander's rear most connector will cause the controller to stop (RUN and POWER OK LED's are OFF). Removing the cable will restart the controller automatically.

**4.5 500 SERIES I/O INSTALLATION**

Installation of the 500 Series I/O is similar to that of the 200 Series. However, the inclusion of a J540 adapter is required. As with the 200 Series, prior planning as to quantity and location of I/O is necessary before installation is attempted.

**4.5.1 I/O Housing Installation with J540 Adapter**

Installation procedures are as follows: Details for the J450 Adapter are in the J540 Adapter/Nowbus Monitor, Installation and Operation Guide (PI-J540-001) which is shipped with the J540.

1. Mark the housing's support surface before drilling holes for mounting bolts. Mounting dimensions for 500 Series I/O are shown in Figure 4-14.

**NOTE**

If the J540 adapter is to attach directly to an auxiliary power supply, the mounting location of the power supply must be marked at this time.

2. Drill mounting holes. Bolt the J540 I/O duct in place. Do not install cover.
3. Set the J540's input and output switches prior to mounting. The 584L PC communicates with the J540 by sending or receiving 16 I/O points of information. Each J540 output switch enables a group of four output modules, each input switch enables a group of four input modules. Figure 4-15 illustrates typical switch settings for the J540 adapter.
4. Replace the J540's front cover.
5. Insert J540 PC board and mounting screws through the left most set of cutouts in the duct. Ensure that the mounting screws on the top of the J540 are backed out at least  $\frac{1}{4}$  inch.
6. Place the J540 against the mounting surface and tighten its mounting screws.
7. Install mounting bolts in the bottom bracket of the J540 and tighten.
8. Insert 500 Series I/O housing and mounting screws through cutouts in the duct adjacent to the J540.

# INSTALLATION




Figure 4-14. 500 Series I/O Mounting Dimensions




Figure 4-15. J540 Switch Settings




Figure 4-16. Inserting J540

## INSTALLATION

### NOTE

Ensure that the mounting screws in the top of the housing are out at least ¼ inch before installing the housing into the duct.

9. Place housing against mounting surface and tighten screws.
10. Bolt I/O housing in place.

### CAUTION

The keyhole slots are only capable of supporting empty I/O housings; not when they are filled with modules and field wiring. Secure housing prior to field wiring and module insertion.

11. Repeat steps 8 through 10, installing housings from left to right until the entire I/O channel is installed. Securely tighten mounting bolts in place.

#### 4.5.2 Field Wiring

User field wiring can be connected before or after the I/O modules are inserted. It is recommended that for user convenience the field wiring be connected prior to the module's installation. Wiring is routed through the conduit to the terminals from either the top or bottom of the housing. Each terminal is capable of receiving one AWG No. 10 or two AWG No. 12 wires. The smallest recommended wire is AWG No. 24. For each module position, terminal 1 is at the top and terminal 8 is at the bottom.


#### 4.5.3 I/O Module Addressing

Prior to installing modules into each B545 housing, the housing's address must be determined. A single channel can support up to 128 input and 128 output points, which can be configured as 32 input and 32 output Series 500 modules. These 64 modules can be inserted into eight B545 housings — eight modules to a housing. Each housing has a set of four STRIP SELECT switches, shown in Figure 4-17, which can be set to select any housing address, one through four. Since there can be up to eight B545 housings per I/O channel, a pair of housings may share the same address if one housing contains only input and the other only output modules.

### NOTES

For proper channel operation only one switch must be pressed. If two switches are pressed, all the housings in that channel with either of these two addresses will respond in parallel.

Up to two housings in one channel can have the same address. Between two housings with the same address, I/O modules must be installed (from top to bottom) with exact opposites, inputs versus outputs.



*Figure 4-17. Strip Select Switches for B545/B546 I/O Housings*


The B546 half size housings are used in locations in which four or fewer I/O modules will be installed. Each housing has a set of four STRIP SELECT switches identical to those described for the B545 housing. Since there can be up to sixteen B546 housings present on one I/O channel, up to four housings may share the same address, one pair of housings containing eight input modules and the other pair of housings containing eight output modules.

In each housing, an UPPER BYTE SELECT switch provides an address for the top two modules, a LOWER BYTE SELECT switch addresses the lower two modules.

## INSTALLATION

### 4.5.4 Module Insertion and Cable Connection

1. Connect the I/O housings and J540 across their tops with the I/O bus cable, the red strip oriented toward the back. The bus cable snaps onto the connectors on the tops of the housings and the J540 (Figure 4-18.).




*Figure 4-18. Bus Cable Connection to J540 and Housings*

2. Install covers on duct. End plate is fastened with three screws.
3. Insert I/O modules. Modules are inserted into the housing using large guide pins to align module into rear connector. Once engaged, the module is rotated toward the wiring conduit to engage field terminals. See Figure 4-19.

#### **NOTE**

The red slide lock must be down to allow module insertion and removal. It must be up to lock the module in place.

4. After all the modules are installed, the housing identification strip can be inserted. This plastic strip covers the field terminals along the entire length of the housing. Space is provided on this strip for color coded labels to identify various I/O modules, as well as user identification of field circuitry.



*Figure 4-19. Inserting 500 Series I/O Modules*

5. The connector at the lower left of the J540 rotates to mate the J540 with either its neighboring auxiliary power supply or a W600 cable. When first mounting the J540, ensure that the connector is rotated inside to prevent damage.
6. If no auxiliary power supply is required for the channel being installed (typically Channels I and II) install W600 type cable to J540. Slide the box end of the cable onto left side of J540 until box almost touches metal stop. Carefully rotate cam connector to mate J540 to cable. It may be necessary to pull box slightly down from the stop to prevent damage to the connectors. Tighten hex head lock screw.

#### 4.6 REMOTE I/O

The 584L's remote I/O will normally require custom configuration for each installation. The following guidelines should be kept in mind:

1. The J200 Remote I/O driver can support up to 14 I/O locations (drops), each with up to two I/O channels.
2. Each drop requires a P451 or P453 auxiliary power supply. The P451 drives one channel of I/O and provides switching for a second channel. The P453 drives two channels of I/O and interfaces with ASCII devices.
3. If a P451 is used at the drop and a second channel is required at the location, a P421 auxiliary power supply is required at the second channel.

## INSTALLATION

4. A single CAC-6 or CATV cable run is used to connect all I/O locations to the J200. This cable is configured as a multi-drop connection; a main cable is installed and a splitter is used next to the J200 to create a branch in the system. Taps are used to connect each I/O location to the main cable. The requirements for this cabling are:
  - (1) Maximum length of any drop is 100 feet (30 meters) from the main cable.
  - (2) Total cable length should not exceed 5,000 feet (1.8 km) for CAC-6 or 15,000 feet (4.5 km) for CATV.
  - (3) The maximum allowable dB loss between the J200 and any drop is 35 dB. This loss should be taken into consideration before configuring the system.
  - (4) The dB loss for the cabling is:  
  
CAC-6 = 7.0 dB/1000 ft. (305 m)  
CATV = 0.8 dB/1000 ft. (305 m)
  - (5) The dB loss for the connectors are:  
  
Tap (MA-0185) = 1 dB through, 12 dB down  
drop  
Splitter (MA-0186) = 3 dB from center to both  
sides
  - (6) If signal loss is becoming critical due to distance of the I/O channel from the controller, a splitter can be used at a drop in place of a tap to reduce the dB loss.
  - (7) The cable can be terminated in two ways: either at a channel of I/O or with a 75 ohm cable terminator.

Installation procedures for the J200, auxiliary power supplies, and I/O drivers can be found in the 584L Programmable Controller Remote I/O Processing Manual.

### 4.7 INSTALLATION PRECAUTIONS FOR AC GROUNDS

AC circuit faults in heavy equipment controlled by the 584L Controller can cause large surge currents in the I/O ground system. The shield on the W600 cable is connected to ground and will provide a current path, momentarily raising the voltage on the frame of the 584L.

The following precautions are provided for the system's installation:

- Avoid power sources with an ungrounded or open delta transformer in three phase systems.
- Avoid using ground systems that use reactance or resistance grounds.

- Use direct ground wire systems where there is an adequate earth ground at the power source.
- Avoid creating ground loops. A common ground reference will minimize the effect of surge transients.
- At a site where the P190 is located some distance from the 584L, check the ground system for breaks in the ground conductor (green/yellow wire), ancillary extension cords, etc. before connecting the P190.

#### 4.8 584L COLD START-UP

The following procedure describes the preparation of the 584L Controller for operation from a cold start.

##### 4.8.1 Unit Assembly

1. After assembling the battery pack, attach the pack to the controller panel.
2. Wire the 120 VAC circuit to the controller's right panel marked appropriately at the panel's bottom.
3. Check baud rate switch settings on the back of the P190. Each DIP switch should be preset at 9600 baud. Use the metal tag on the rear of the machine to verify each port's baud rate. DIP switch setting should be: 9600 baud, even parity, 1 stop bit, 8 data bits.
4. Apply power to the programmer and controller. Place the power switches on the back panel of the P190 and within the inner door of the 584L to ON.
5. Observe the P190. LOAD PROGRAM TAPE should be displayed on the screen. For a more readable picture, adjust contrast and brightness from the rear panel.
6. Observe the 584L display panel. SAFE 84 should be displayed and the battery and power LED's should be energized.
7. Change the baud rate by pressing the following keys on the front panel of the 584L.
  - (a) 620002
  - (b) REF
  - (c) 9600
  - (d) ENTER

This will set the front port of the 584L Controller to operate at 9600 baud.

8. Connect the W190 cable to the port on the 584L's front panel.
9. Attach the 25 pin male connector of the cable to Port 1 on the rear access panel of the P190.

## INSTALLATION

### 4.8.2 Tape Duplication

A master tape cannot be used to enable the system. All tapes must be duplicated, then the duplicates are used to program/configure the 584L. A blank tape is needed for each copy. A duplicate tape cannot be copied.

To make a copy of the 584L Configurator Master Tape follow steps 1-7.

1. Turn on the P190.
2. Press the red INIT and the red INIT LOCK key at the same time. When the P190 is ready the screen will display the message INSERT P190 PROGRAM TAPE.
3. Insert the master T584-004 Configurator Tape into the tape drive on the P190. After the tape has run, it automatically rewinds and stops. The P190 screen then displays the message REMOVE TAPE.
4. Remove the tape from the P190 tape drive. Be sure it is clearly labeled. Now the P190 screen displays the message LOAD WRITE ENABLED SCRATCH TAPE.
5. Insert a blank tape. Be sure the record tab is in the RECORD position. The P190 automatically begins to duplicate the master tape. The screen displays the message DUPLICATING. After the tape has run, it automatically rewinds and the P190 screen displays the message REMOVE TAPE. Remove the tape and label it. The screen then displays LOAD WRITE ENABLED SCRATCH TAPE.
6. To produce more copies, insert another blank tape in the tape drive and repeat Step 5. After the last copy has been made, remove the tape and press the red INIT and the INIT LOCK key at the same time.
7. To duplicate another master tape begin again at Step 2.
8. Store all master tapes in a clean, dry, secure place for future use.

### 4.8.3 Configuration

The following steps using the P190 Programmer will configure the controller:

#### NOTES

The baud rate switches on the P190 are preset at the factory. The DIP switch on the left side sets the baud rate with the first three switches up and the fourth switch down.

To set a compatible baud rate for the front programming port on the 584L, enter code No. 620002 and press the REF key. Then enter 9600 and press the ENTER key. This will set the baud rate for the front port at 9600 baud. To set the baud rate for the bottom programming port, enter code No. 610002.

1. Insert duplicate configurator tape. Wait for tape to load. The display will change listing several labels.

2. Enter 1 and press 584L CONFIG. Wait for CONFIG to load.
3. After display has changed:
  - (a) Press SET SIZE and enter number of coils, inputs, input and holding registers, and I/O channels.
  - (b) Press 584L CONFIG.
  - (c) Press Port 1, set 9600 baud rate, press 584L CONFIG.
  - (d) Press Port 2, set 9600 baud rate, press 584L CONFIG.
4. Press WRITE CONFIG. 584L CONFIG and ATTACH keys will be displayed.
5. Enter unit No. 1 and press ATTACH. The 584L Controller's configuration will be displayed.
6. Press EXIT.
7. Press CONTROLLER OPERATION.
8. Press START 584L.
9. Press PROCEED. Controller run light should be ON.
10. Insert duplicate 584L Program Tape. Press INIT and INIT/LOCK on the programmer. Wait for tape to load and display to change.
11. Press 1, then ATTACH. Configuration Table should be displayed.
  - (a) If you are going to use ASCII messages, press the ASCII key and set the appropriate ASCII parameters. Press 584L CONFIG when all the ASCII information is entered.
  - (b) Press the special key to set the battery OK coil (any coil in the system may be selected). Press 584L CONFIG.
12. Press EXIT. Screen will appear blank with the exception of a SELECT SEGMENT.
13. Press START NEXT.

The 584L PC is now ready to program.