

# TeSys DFB Offer for Unity Pro

a SoCollaborative library  
User manual

10/2008



---

© 2008 Schneider Electric. All rights reserved.

---

# Table of Contents




	<b>Safety Information</b> .....	<b>5</b>
	<b>About the Book</b> .....	<b>9</b>
<b>Chapter 1</b>	<b>Introduction</b> .....	<b>11</b>
	Presentation .....	12
	TeSys DFB Offer Overview .....	14
	TeSys DFB Sequencing .....	20
<b>Chapter 2</b>	<b>Modbus SL DFB</b> .....	<b>25</b>
	Ctrl_cmd_mdb_u_xxxx: TeSys U Control/Command for Modbus SL .....	26
	Comm_manager_u: TeSys U Communication Management for Modbus SL .....	33
	Ctrl_cmd_mdb_t_xxxx: TeSys T Control/Command for Modbus SL .....	38
	Comm_manager_t: TeSys T Communication Management for Modbus SL .....	45
<b>Chapter 3</b>	<b>Modbus SL and Modbus ® \ TCP DFB</b> .....	<b>51</b>
	Special_mdb_u_xxxx: TeSys U DFB for Modbus SL and Modbus ® \ TCP .....	52
	Special_mdb_t_xxxx: TeSys T DFB for Modbus SL and Modbus ® \ TCP .....	62
	Custom_mdb_xxxx: Custom Read DFB for Modbus SL and Modbus ® \ TCP .....	77
<b>Chapter 4</b>	<b>Profibus DFB</b> .....	<b>81</b>
	Ctrl_pfb_u_ms: TeSys U Control/Command for Profibus DP MS .....	82
	Ctrl_pfb_u_mms: TeSys U Control/Command for Profibus DP MMS .....	85
	Ctrl_pfb_t_mms: TeSys T Control/Command for Profibus DP MMS .....	88
<b>Chapter 5</b>	<b>Cyclic Control/Command DFB</b> .....	<b>93</b>
	Ctrl_cmd_u: TeSys U Cyclic Control/Command .....	94
	Ctrl_cmd_t: TeSys T Cyclic Control/Command .....	97
<b>Chapter 6</b>	<b>PKW Exchanges DFB</b> .....	<b>101</b>
	Special_pkw_u: TeSys U DFB for PKW Exchanges .....	102
	Special_pkw_t: TeSys T DFB for PKW Exchanges .....	112
	Custom_pkw: Custom Read DFB for PKW Exchanges .....	127

---

<b>Chapter 7 Treatment DFB</b> .....	<b>133</b>
Scale: TeSys U DFB for Measurement Unit Conversion .....	134
Timestamp: TeSys U DFB for Data Time-Stamping .....	138
<b>Index</b> .....	<b>141</b>

---

## Safety Information



---

### Important Information

#### NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

### **DANGER**

**DANGER** indicates an imminently hazardous situation which, if not avoided, **will result in** death or serious injury.

### **WARNING**

**WARNING** indicates a potentially hazardous situation which, if not avoided, **can result in** death or serious injury.

---

** CAUTION**

**CAUTION** indicates a potentially hazardous situation which, if not avoided, **can result in** minor or moderate injury.

**CAUTION**

**CAUTION**, used without the safety alert symbol, indicates a potentially hazardous situation which, if not avoided, **can result in** equipment damage.

**PLEASE NOTE**

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

**BEFORE YOU BEGIN**

Do not use this product on machinery lacking effective point-of-operation guarding. Lack of effective point-of-operation guarding on a machine can result in serious injury to the operator of that machine.

** WARNING**

**UNGUARDED MACHINERY CAN CAUSE SERIOUS INJURY**

- Do not use this software and related automation equipment on packaging equipment which does not have point-of-operation protection.
- Do not reach into machinery during operation.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

This automation equipment and related software is used to control a variety of industrial processes. The type or model of automation equipment suitable for each application will vary depending on factors such as the control function required, degree of protection required, production methods, unusual conditions, government regulations, etc. In some applications, more than one processor may be required, as when backup redundancy is needed.

---

Only the user can be aware of all the conditions and factors present during setup, operation and maintenance of the machine; therefore, only the user can determine the automation equipment and the related safeties and interlocks which can be properly used. When selecting automation and control equipment and related software for a particular application, the user should refer to the applicable local and national standards and regulations. The Accident Prevention Manual (nationally recognized in the United States of America) also provides much useful information.

In some applications, such as packaging machinery, additional operator protection such as point-of-operation guarding must be provided. This is necessary if the operator's hands and other parts of the body are free to enter the pinch point area and serious injury can occur. Software products cannot protect an operator from injury. For this reason the software cannot be substituted for or take the place of point-of-operation protection.

Ensure that appropriate safeties and interlocks related to point-of-operation protection have been installed and are operational before placing the equipment into service. All interlocks and safeties related to point-of-operation protection must be coordinated with the related automation equipment and software programming.

**NOTE:** Coordination of safeties and interlocks for point-of-operation is outside the scope of this Defined Function Block (DFB).

## START UP AND TEST

Before using electrical control and automation equipment for regular operation after installation, the system should be given a start up test by qualified personnel to verify correct operation of the equipment. It is important that arrangements for such a check be made and that enough time is allowed to perform complete and satisfactory testing.

### CAUTION

#### EQUIPMENT OPERATION HAZARD

- Verify that all installation and set up procedures have been completed.
- Before operational tests are performed, remove all blocks or other temporary holding means used for shipment from all component devices.
- Remove tools, meters and debris from equipment.

**Failure to follow these instructions can result in injury or equipment damage.**

Follow all start up tests recommended in the equipment documentation. Store all equipment documentation for future references.

**Software testing must be done in both simulated and real environments.**

---

Verify that the completed system is free from all short circuits and grounds, except those grounds installed according to local regulations (according to the National Electrical Code in the U.S.A, for instance). If high-potential voltage testing is necessary, follow recommendations in equipment documentation to prevent accidental equipment damage.

Before energizing equipment:

- Remove tools, meters and debris from equipment.
- Close the equipment enclosure door.
- Remove ground from incoming power lines.
- Perform all start-up tests recommended by the manufacturer.

## **OPERATION AND ADJUSTMENTS**


The following precautions are from the NEMA Standards Publication ICS 7.1-1995 (English version prevails):

- Regardless of the care exercised in the design and manufacture of equipment or in the selection and ratings of components, there are hazards that can be encountered if such equipment is improperly operated.
- It is sometimes possible to misadjust the equipment and thus produce unsatisfactory or unsafe operation. Always use the manufacturer's instructions as a guide for functional adjustments. Personnel who have access to these adjustments should be familiar with the equipment manufacturer's instructions and the machinery used with the electrical equipment.
- Only those operational adjustments actually required by the operator should be accessible to the operator. Access to other controls should be restricted to prevent unauthorized changes in operating characteristics.



---

# About the Book



---

## At a Glance

### Document Scope

This manual describes the DFB (Derived Function Block) offer dedicated to TeSys U starter-controllers and TeSys T motor management systems. It is intended for design engineers and system integrators who have a good knowledge of the Unity Pro PLC programming platform. The purposes of this manual are:

- to describe the scope of the DFB offer and platform compatibility,
- to describe the DFB characteristics,
- to explain how to implement the DFB in the PLC application.

### Validity Note

Schneider Electric assumes no responsibility for any errors that may appear in this document. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

The data and illustrations found in this documentation are not binding. We reserve the right to modify our products in line with our policy of continuous product development. The information in this document is subject to change without notice and should not be construed as a commitment by Schneider Electric.

---

## Related Documents

You can download these technical publications and other technical information from our website at [www.schneider-electric.com](http://www.schneider-electric.com).

<b>Title of Documentation</b>	<b>Reference Number</b>
LULC032-033 Modbus Communication Module User manual	1743234
LUCM and LUCMT Multifunction Control Unit User manual	1743237
TeSys U Communication Variables User manual	1744082
LULC15 Advantys STB Communication Module User manual	1744083
LULC08 CANopen Communication Module User manual	1744084
LULC07 Profibus DP Communication Module User manual	33003287
TeSys T LTM R Modbus Motor Management Controller User manual	1639501
TeSys T LTM R Profibus Motor Management Controller User manual	1639502
TeSys T LTM R CANopen Motor Management Controller User manual	1639503

You can download these technical publications and other technical information from our website at [www.schneider-electric.com](http://www.schneider-electric.com).

## Product Related Information

All relevant local safety regulations must be followed when installing and using this product. For safety reasons, and to ensure conformity with the documented system data, only the manufacturer is authorized to repair the components.

## User Comments

We welcome your comments about this document. You can reach us by e-mail at [techcomm@schneider-electric.com](mailto:techcomm@schneider-electric.com).

---

# Introduction



---

## Introduction

This chapter gives an overview of the TeSys U and TeSys T DFB (Derived Function Block) offer and describes the sequencing system used to synchronize the treatment between DFBs.

## What's in this Chapter?

This chapter contains the following topics:

<b>Topic</b>	<b>Page</b>
Presentation	12
TeSys DFB Offer Overview	14
TeSys DFB Sequencing	20

## Presentation

### Aim of the TeSys DFB Offer

The TeSys DFB offer has been developed to simplify and optimize the integration of TeSys U starter-controllers and TeSys T motor management systems in PLC applications, for both PLC programmers and end users.

### Advantages for the PLC Programmer

The TeSys DFB offer enables the PLC programmer to:

- simplify the program design: the program is splitted by functions (control, command, data treatment,...),
- optimize the programming time: the DFB is tested and can be re-used for different applications,
- increase the program understanding: the applications are coded in the same way using the common DFB,
- optimize the program size: the same code is used for each DFB instantiation,
- simplify the TeSys U and TeSys T integration: the data mapping management is masked.

### Advantages for the End User

The TeSys DFB offer enables the end user to:

- optimize the communication response time:
  - the Modbus requests management is optimized,
  - the data exchange management is optimized,
  - the product performance is taken into account,
- have a functional view of the motor-starter by providing direct access to common functions (Ready, Fault, Alarm, Run, Stop,...),
- group data related to a specific application (diagnostic, maintenance, measurement,...) through a program number,
- facilitate debugging: all variables used by the DFB are identified on its interface.

### PLC Platform Compliance

The TeSys DFB offer can be integrated in the following programming platform:

- the Unity Pro programming platform with Premium PLC platforms and M340 PLC platforms.

### TeSys Compliance

The TeSys DFB offer is compliant with:

- TeSys U starter-controllers (up to 32 A/15 kW),
- TeSys T LTM R•P•• / LTM R•M•• / LTM R•E•• / LTM R•C•• controllers.

## Communication Protocol Compliance

The following table describes the TeSys DFB offer compliance with communication protocols and the corresponding TeSys U and TeSys T assemblies:

Protocol	TeSys U	TeSys T
Modbus SL (Serial Line)	Starter-controller (up to 32 A/15 kW) with LULC032-033 Modbus communication module	LTMR••M•• Modbus SL controller with or without the LTM E expansion module
Modbus ® \ TCP	Starter-controller (up to 32 A/15 kW) with LULC032-033 Modbus communication module and Ethernet gateway (TeSysPort, TSXETG100, TSXETG1000,...)	LTMR••E•• Modbus ® \ TCP controller with or without the LTM E expansion module
Profibus DP	Starter-controller (up to 32 A/15 kW) with LULC07 Profibus DP communication module	LTMR••P•• Profibus DP controller with or without the LTM E expansion module
CANopen	Starter-controller (up to 32 A/15 kW) with LULC08 CANopen communication module	LTMR••C•• CANopen controller with or without the LTM E expansion module
Advantys STB	Starter-controller (up to 32 A/15 kW) with LULC15 Advantys STB communication module	–

## TeSys DFB Offer Overview

### TeSys DFB Offer Organization

The following table lists the TeSys DFB offer according to the communication protocol and service and their availability according to the TeSys model:

Communication Protocol / Service	DFB Name	TeSys U	TeSys T
Modbus SL	Ctrl_cmd_mdb_u_****	√	
	Comm_manager_u	√	
	Ctrl_cmd_mdb_t_****		√
	Comm_manager_t		√
Modbus SL and Modbus ® \ TCP	Custom_mdb_****	√	√
	Special_mdb_u_****	√	
	Special_mdb_t_****		√
Profibus DP	Ctrl_pfb_u_ms	√	
	Ctrl_pfb_u_mms	√	
	Ctrl_pfb_t_mms		√
Cyclic control/command (Modbus ® \ TCP (IO scanning), CANopen, and Advantys STB)	Ctrl_cmd_u (Modbus ® \ TCP (IO scanning), CANopen, and Advantys STB)	√	
	Ctrl_cmd_t (Modbus ® \ TCP (IO scanning) and CANopen)		√
PKW	Special_pkw_u	√	
	Special_pkw_t		√
	Custom_pkw	√	√
Treatment	Timestamp	√	
	Scale	√	

## Modbus SL DFB Offer

The following table describes the Modbus SL (Serial Line) DFB offer:

DFB	Description	For More Information
Ctrl_cmd_mdb_u_addr Ctrl_cmd_mdb_u_addm	<p>These DFBs are dedicated to the control and command of a single TeSys U starter-controller (up to 32 A/15 kW) with any control unit and a LULC032-033 Modbus communication module.</p> <p>They enable the user to:</p> <ul style="list-style-type: none"> <li>● read status register 455</li> <li>● write command register 704</li> <li>● reset communication loss warning (register 703, bit 3)</li> </ul> <p>The program number enables the user to select bit or word control.</p>	<p><i>Ctrl_cmd_mdb_u_xxxx:</i> <i>TeSys U Control/Command for Modbus SL,</i> <i>page 26</i></p>
Comm_manager_u	<p>This DFB is dedicated to the control and command of up to 31 TeSys U starter-controllers (up to 32 A/15 kW) with any control unit and a LULC032-033 Modbus communication module.</p> <p>It must be associated with the Ctrl_cmd_mdb_u_**** DFBs to manage the Modbus requests sequencing.</p> <p>It enables the user to:</p> <ul style="list-style-type: none"> <li>● optimize the response time by taking into account the response time of the devices</li> <li>● send write requests only when necessary</li> <li>● manage the disconnection and reconnection of a TeSys U Modbus slave</li> </ul> <p>The program number enables the user to select different Modbus requests sequences.</p>	<p><i>Comm_manager_u:</i> <i>TeSys U Communication Management for Modbus SL,</i> <i>page 33</i></p>

DFB	Description	For More Information
Ctrl_cmd_mdb_t_addr Ctrl_cmd_mdb_t_addm	<p>These DFBs are dedicated to the control and command of a single TeSys T LTMR••M•• Modbus SL controller with or without the LTM E expansion module.</p> <p>They enable the user to:</p> <ul style="list-style-type: none"> <li>● read status registers 455 and 456</li> <li>● write command register 704</li> </ul> <p>The program number enables the user to select bit or word control.</p>	<p><i>Ctrl_cmd_mdb_t_xxxx: TeSys T Control/Command for Modbus SL, page 38</i></p>
Comm_manager_t	<p>This DFB is dedicated to the control and command of several TeSys T LTMR••M•• Modbus SL controllers with or without the LTM E expansion module. It must be associated with the Ctrl_cmd_mdb_t_•••• DFB to manage the Modbus requests sequencing.</p> <p>It enables the user to:</p> <ul style="list-style-type: none"> <li>● optimize the response time by taking into account the response time of the devices</li> <li>● send write requests only when necessary</li> <li>● manage the disconnection and reconnection of a TeSys U Modbus slave</li> </ul> <p>The program number enables the user to select different Modbus requests sequences.</p>	<p><i>Comm_manager_t: TeSys T Communication Management for Modbus SL, page 45</i></p>



## Modbus ® \ TCP DFB Offer

The following table describes the Modbus ® \ TCP DFB offer:

DFB	Description	For More Information
Special_mdb_u_addr Special_mdb_u_addm	These DFBs are dedicated to the reading of up to 16 pre-defined registers (diagnostic, maintenance, measurement,...) of a TeSys U starter-controller (up to 32 A/15 kW) with a multifunction control unit and a LULC032-033 Modbus communication module. They can be used with a TeSys U starter-controller connected to a Modbus Serial Line or to a Modbus ® \ TCP gateway. The program number enables the user to select the pre-defined registers.	<i>Special_mdb_u_xxxx: TeSys U DFB for Modbus SL and Modbus ® \ TCP, page 52</i>
Special_mdb_t_addr Special_mdb_t_addm	These DFBs are dedicated to the reading of up to 16 pre-defined registers (diagnostic, maintenance, measurement,...) of a TeSys T LTMR**M** Modbus SL controller with or without the LTM E expansion module. They can be used with a TeSys T controller connected to a Modbus Serial Line or to a Modbus ® \ TCP gateway. The program number enables the user to select the pre-defined registers.	<i>Special_mdb_t_xxxx: TeSys T DFB for Modbus SL and Modbus ® \ TCP, page 62</i>
Custom_mdb_addr Custom_mdb_addm	These DFBs are dedicated to the reading of up to 5 sets of registers in one single TeSys device. A set of registers is defined by the address of the first register to read and the length of the set (up to 16 registers per set).	<i>Custom_mdb_xxxx: Custom Read DFB for Modbus SL and Modbus ® \ TCP, page 77</i>

## Profibus DP DFB Offer

The following table describes the Profibus DP DFB offer:

DFB	Description	For More Information
Ctrl_pfb_u_ms	This DFB is dedicated to the control and command of a single TeSys U starter-controller (up to 32 A/15 kW) with any control unit and a LULC07 Profibus communication module using the Motor Starter profile.	<i>Ctrl_pfb_u_ms: TeSys U Control/Command for Profibus DP MS, page 82</i>
Ctrl_pfb_u_mms	This DFB is dedicated to the control and command of a single TeSys U starter-controller (up to 32 A/15 kW) with a LUCM multifunction control unit and a LULC07 Profibus DP communication module using the Motor Management Starter profile.	<i>Ctrl_pfb_u_mms: TeSys U Control/Command for Profibus DP MMS, page 85</i>
Ctrl_pfb_t_ms	This DFB is dedicated to the control and command of a single TeSys T LTMR**P** Profibus controller with or without the LTM E expansion module.	<i>Ctrl_pfb_t_mms: TeSys T Control/Command for Profibus DP MMS, page 88</i>

## Cyclic Control/Command DFB Offer

The following table describes the cyclic control/command (Modbus® \ TCP (IO scanning), CANopen, and Advantys STB) DFB offer:

DFB	Description	For More Information
Ctrl_cmd_u	This DFB is dedicated to the control and command of a single TeSys U starter-controller (up to 32 A/15 kW) with any control unit and a LULC08 CANopen, a LULC15 STB communication module, or a LULC032-033 Modbus communication module with an Ethernet gateway.	<i>Ctrl_cmd_u: TeSys U Cyclic Control/Command, page 94</i>
Ctrl_cmd_t	This DFB is dedicated to the control and command of a single TeSys T LTMR••C•• CANopen controller or a TeSys T LTMR••E•• Modbus® \ TCP controller, with or without the LTM E expansion module.	<i>Ctrl_cmd_t: TeSys T Cyclic Control/Command, page 97</i>

## PKW DFB Offer

The following table describes the PKW DFB offer:

DFB	Description	For More Information
Special_pkw_u	This DFB is dedicated to the reading of up to 16 predefined registers (diagnostic, maintenance, measurement,...) of a single TeSys U starter-controller (up to 32 A/15 kW) with a multi-function control unit and one of the following communication modules that support PKW exchanges: <ul style="list-style-type: none"> <li>● LULC07 (Profibus)</li> <li>● LULC08 (CANopen)</li> <li>● LULC15 (Advantys STB)</li> </ul> The program number enables the user to select the predefined registers.	<i>Special_pkw_u: TeSys U DFB for PKW Exchanges, page 102</i>
Special_pkw_t	This DFB is dedicated to the reading of up to 16 predefined registers (diagnostic, maintenance, measurement,...) of a single TeSys T LTMR••P•• Profibus controller or a LTMR••C•• CANopen controller with or without the LTM E expansion module. <p>The program number enables the user to select the predefined registers.</p>	<i>Special_pkw_t: TeSys T DFB for PKW Exchanges, page 112</i>
Custom_pkw	This DFB is dedicated to the reading of up to 5 sets of registers of a single TeSys device supporting PKW exchanges. A set of registers is defined by the address of the first register to read and the length of the set (up to 16 registers per set).	<i>Custom_pkw: Custom Read DFB for PKW Exchanges, page 127</i>

## Treatment DFB Offer

The following table describes the treatment DFB offer:

DFB	Description	For More Information
Scale	This DFB is dedicated to the conversion of current measurement unit from relative value (% FLC) to Amps for a TeSys U starter-controller (up to 32 A/15 kW) with a multifunction control unit. It also enables the user to select another unit in the A...mA range.	<i>Scale: TeSys U DFB for Measurement Unit Conversion, page 134</i>
Timestamp	This DFB is dedicated to the time-stamping of up to 8 input registers of a TeSys U starter-controller (up to 32 A/15 kW) with a multifunction control unit. It provides an output table of the 8 time-stamped registers and 4 date and time registers. See <i>DT_DateTime</i> , page 126.	<i>Timestamp: TeSys U DFB for Data Time-Stamping, page 138</i>

## TeSys DFB Sequencing

### Introduction


Some of the TeSys DFBs use a sequencing system using dedicated inputs and outputs that enable the sequencing and the synchronization of the treatment between DFBs.

The following derived function blocks use a sequencing system:

- Ctrl\_cmd\_mdb\_u\_\*\*\*\*
- Ctrl\_cmd\_mdb\_t\_\*\*\*\*
- Special\_mdb\_u\_\*\*\*\*
- Special\_mdb\_t\_\*\*\*\*
- Custom\_mdb\_\*\*\*\*
- Special\_pkw\_u
- Special\_pkw\_t
- Custom\_pkw
- Timestamp

### Sequencing System Principle

The sequencer has 2 boolean inputs and 3 boolean outputs:




- The **\_cmd** suffix indicates a command dedicated to the DFB sequencer function.
- The **\_st** suffix indicates a status information concerning the DFB sequencer function.

The following table describes the sequencer inputs and outputs:

Input/Output	Description
Rst_cmd	This command resets the DFB and/or restarts the DFB treatment if Strt_cmd is set to 1.
Strt_cmd	This command starts the DFB treatment.
Fault_st	This status bit indicates: <ul style="list-style-type: none"> <li>● a parameterization fault (value out of range),</li> <li>● a communication fault.</li> </ul> If a fault occurs, the applicative boolean outputs are reset to 0, and the output words are forced to -1.
Rst_st	This status bit indicates: <ul style="list-style-type: none"> <li>● a reset in progress,</li> <li>● a treatment in progress.</li> </ul>
End_st	This status bit indicates the end of the DFB treatment.


### Stand-Alone with Manual Restart

In the stand-alone with manual restart configuration, the DFB is not linked to another DFB and it is activated each time %M0 is set to 1:




### Stand-Alone with Automatic Restart

In the stand-alone with automatic restart configuration, the DFB is not linked to another DFB and it is activated continuously when %M0 is set to 1:




### DFB Chaining with Manual Restart

In the DFB chaining with manual restart configuration, the DFB is linked to other DFBs and it is activated each time %M0 is set to 1:



## DFB Chaining with Automatic Restart

In the DFB chaining with automatic restart configuration, the DFB is linked to other DFBs and it is activated continuously when %MO is set to 1:







---

# Modbus SL DFB

# 2

---

## Introduction

This chapter describes the TeSys U and TeSys T Modbus SL (Serial Line) DFBs.

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Ctrl_cmd_mdb_u_xxxx: TeSys U Control/Command for Modbus SL	26
Comm_manager_u: TeSys U Communication Management for Modbus SL	33
Ctrl_cmd_mdb_t_xxxx: TeSys T Control/Command for Modbus SL	38
Comm_manager_t: TeSys T Communication Management for Modbus SL	45

## Ctrl\_cmd\_mdb\_u\_xxxx: TeSys U Control/Command for Modbus SL

### Presentation

The Ctrl\_cmd\_mdb\_u\_\*\*\*\* derived function blocks (DFBs) are dedicated to the control and command of a single TeSys U starter-controller (up to 32 A/15 kW) with any control unit and a LULC032-033 Modbus communication module through the Modbus SL (Serial Line) network.


- Ctrl\_cmd\_mdb\_u\_addr uses XWAY addressing and is dedicated to Premium PLCs.
- Ctrl\_cmd\_mdb\_u\_addm uses an addressing method dedicated to M340 PLCs.

For more information, see the *LULC032-033 Modbus Communication Module User manual*.

### Characteristics

Characteristic	Value	
Name	Ctrl_cmd_mdb_u_addr	Ctrl_cmd_mdb_u_addm
Version	1.00	1.00
Input	11	11
Output	13	13
Input/Output	0	0
Public Variable	6	8

## Graphical Representation



## TeSys U Compliance

The Ctrl\_cmd\_mdb\_u\_\*\*\* DFBs are compliant with the following TeSys U sub-assemblies:

<b>Power base</b>	<ul style="list-style-type: none"> <li>● LUB** non-reversing power base (up to 32 A/15 kW)</li> <li>● LU2B** reversing power base (up to 32 A/15 kW)</li> </ul>
<b>Control unit</b>	<ul style="list-style-type: none"> <li>● LUCA standard control unit</li> <li>● LUCB, LUCC, and LUCD advanced control units</li> <li>● LUCL magnetic control unit</li> <li>● LUCM multifunction control unit</li> </ul>
<b>Communication module</b>	<ul style="list-style-type: none"> <li>● LULC032-033 Modbus communication module</li> </ul>

## Software Implementation

The parameters and the inputs can only be changed if the End\_st output variable is set to 1.

The output data is only valid if the End\_st output variable is set to 1 and if there is no fault state (Fault\_st = 0).

## Input Characteristics

The following table describes the DFB inputs and their availability according to the control unit:

Input	Type	Range	De- fault Value	Description	LOCAL	LOCAL	LOCAL
Slav_num	INT	1...31	1	Modbus slave number	√	√	√
Prog_num	INT	1...30	–	See <i>Program Number, page 29</i>	√	√	√
Rst_cmd	EBOOL	0...1	0	Reset command	√	√	√
Strt_cmd	EBOOL	0...1	0	Start command	√	√	√
Run_fwd	EBOOL	0...1	0	Motor run forward command	√	√	√
Run_rev	EBOOL	0...1	0	Motor run reverse command	√	√	√
Rstflt	EBOOL	0...1	0	Reset fault (if register 451 = 102 or 104, fault acknowledgment causes a return to communication module factory settings)	√	√	√
Rstwarn	EBOOL	0...1	0	Reset warning (for example, communication loss)	√	√	√
Ther_ov	EBOOL	0...1	0	Automatic thermal overload fault test			√
Trip_tst	EBOOL	0...1	0	Overcurrent trip test via communication bus			√
In_word	INT	–	–	This input is only used when program number is 10, 20, or 30. See next table and program number description.			

The following table describes the In\_word input:

Input	Type	Bit	Description	LUCALUCL	LUCERUD	LUCOR
In_word	INT	0	Motor run forward command	√	√	√
		1	Motor run reverse command	√	√	√
		2	Reserved			
		3	Reset fault (if register 451 = 102 or 104, fault acknowledgment causes a return to communication module factory settings)	√	√	√
		4	Reserved			
		5	Automatic thermal overload fault test			√
		6	Overcurrent trip test via communication bus			√
		7	Reserved			
		8	Reset warning (for example, communication loss)	√	√	√
		9...15	Reserved			

## Program Number

The program number enables the user to select bit or word control.

The following table describes the programs of the DFB:

Program Number	Description
1	Read registers 455 and 456, then write register 704 (systematic)
2	Read registers 455 and 456, then write register 704 (conditional)
3	Write register 704
10	Same as program 1 but using the In_word input and the Out_word output
20	Same as program 2 but using the In_word input and the Out_word output
30	Same as program 3 but using the In_word input and the Out_word output

## Output Characteristics

The following table describes the DFB outputs and their availability according to the control unit:

Output	Type	Range	De- fault Value	Description	LOCKOUT	COAST	MON
Fault_st	EBOOL	0...1	0	Fault state	√	√	√
Rst_st	EBOOL	0...1	0	Reset state	√	√	√
End_st	EBOOL	0...1	0	End state	√	√	√
Ready	EBOOL	0...1	0	System ready: the rotary handle is turned to On position and there is no fault	√	√	√
Closed	EBOOL	0...1	0	Pole status: closed	√	√	√
Fault	EBOOL	0...1	0	All faults	√	√	√
Alarm	EBOOL	0...1	0	All warnings	√	√	√
Tripped	EBOOL	0...1	0	System tripped: the rotary handle is turned to Trip position	√	√	√
Rst_auth	EBOOL	0...1	0	Fault reset authorized		√	√
Starting	EBOOL	0...1	0	Start in progress: 0 = descending current is lower than 150% FLA 1 = ascending current is greater than 10% FLA		√	√
Running	EBOOL	0...1	0	Motor running with detection of current, if greater than 10% FLA		√	√
Avg_curr	INT	0...200	0	Average motor current (x 1% FLA)		√	√
Out_word	INT	–	–	This output is only used when program number is 10, 20, or 30. See next table and program number description.			

The following table describes the Out\_word output:

Output	Type	Bit	Description	LUCALUCI	LUCEREP	LUCM
Out_word	INT	0	System ready: the rotary handle is turned to On position and there is no fault	√	√	√
		1	Pole status: closed	√	√	√
		2	All faults	√	√	√
		3	All warnings	√	√	√
		4	System tripped: the rotary handle is turned to Trip position	√	√	√
		5	Fault reset authorized		√	√
		6	Reserved			
		7	Motor running with detection of current, if greater than 10% FLA		√	√
		8...13	Average motor current (% FLA) 32 = 100% FLA 63 = 200% FLA		√	√
		14	Reserved			
		15	Start in progress: 0 = descending current is lower than 150% FLA 1 = ascending current is greater than 10% FLA		√	√

## Public Variables Characteristics

The following table describes the Ctrl\_cmd\_mdb\_u\_addr and the Ctrl\_cmd\_mdb\_u DFBs public variables (using XWAY addressing) and their availability according to the control unit:

Public Variable	Type	Range	De- fault Value	Description	LUCALUC	LUCBUC	LUCM
Net_num	INT	100...255	100	Network address	√	√	√
Stat_num	INT	0...255	0	Station address	√	√	√
Rack_num	INT	0...7	0	Destination rack address	√	√	√
Slot_num	INT	0...10	0	Destination slot address	√	√	√
Chan_num	INT	0...1	0	Destination channel address	√	√	√
Sq_princ	INT	0...7	0	Reserved for support	√	√	√

The following table describes the Ctrl\_cmd\_mdb\_u\_addm DFB public variables (using M340 addressing) and their availability according to the control unit:

Public Variable	Type	Range	De- fault Value	Description	LUCALUC	LUCBUC	LUCM
Rack_num	INT	0...7	0	Destination rack address	√	√	√
Slot_num	INT	0...10	0	Destination slot address	√	√	√
Chan_num	INT	0...1	0	Destination channel address	√	√	√
IP_addr1	INT	0...255	0	First byte of IP address	√	√	√
IP_addr2	INT	0...255	0	Second byte of IP address	√	√	√
IP_addr3	INT	0...255	0	Third byte of IP address	√	√	√
IP_addr4	INT	0...255	0	Fourth byte of IP address	√	√	√
Sq_princ	INT	0...7	0	Reserved for support	√	√	√



## Comm\_manager\_u: TeSys U Communication Management for Modbus SL

### Presentation

The Comm\_manager\_u derived function block (DFB) is dedicated to the control and command of up to 31 TeSys U starter-controllers (up to 32 A/15 kW) with any control unit and a LULC032-033 Modbus communication module through the Modbus SL (Serial Line) network. It must be associated with the Ctrl\_cmd\_mdb\_u\_\*\*\* DFBs to manage the Modbus requests sequencing.


The number of TeSys U Modbus slaves is defined in the Slav\_num variable (Slav\_num = 1...31).

For more information, see the *LULC032-033 Modbus Communication Module User manual*.

### Characteristics

Characteristic	Value
Name	Comm_manager_u
Version	1.00
Input	4
Output	4
Input/Output	0
Public Variable	3

### Graphical Representation




### TeSys U Compliance

The Comm\_manager\_u DFB is compliant with the following TeSys U sub-assemblies:

<b>Power base</b>	<ul style="list-style-type: none"> <li>● LUB** non-reversing power base (up to 32 A/15 kW)</li> <li>● LU2B** reversing power base (up to 32 A/15 kW)</li> </ul>
<b>Control unit</b>	<ul style="list-style-type: none"> <li>● LUCA standard control unit</li> <li>● LUCB, LUCC, and LUCD advanced control units</li> <li>● LUCL magnetic control unit</li> <li>● LUCM multifunction control unit</li> </ul>
<b>Communication module</b>	<ul style="list-style-type: none"> <li>● LULC032-033 Modbus communication module</li> </ul>

### Software Implementation

The following figure shows a Unity Pro program extract in FBD language showing how to interconnect the Ctrl\_cmd\_mdb\_u and the Comm\_manager\_u DFBs:



## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	Default Value	Description
Slav_num	INT	1...31	1	Modbus slave number
Flt_cmd	EBOOL	0...1	0	Reset command
Strt_cmd	EBOOL	0...1	0	Start command
In_word	INT	–	–	To connect to the Out_word output of the Ctrl_cmd_mdb_u_**** DFB

## Output Characteristics

The following table describes the DFB outputs:

Output	Type	Range	Default Value	Description
Slav_st	INT	1...31	1	Modbus slave number
Prog_st	INT	20 or 30	–	Program number of the Ctrl_cmd_mdb_u_**** DFB
End_st	EBOOL	0...1	0	End state
Out_word	INT	–	–	To connect to the In_word input of the Ctrl_cmd_mdb_u_**** DFB

## Public Variables Characteristics

The following table describes the DFB public variables:

Public Variable	Type	Range	Default Value	Description
In_cmd[0]...[31]	ARRAY [0...31] of INT	–	–	See <i>In_cmd[0]...[31] Public Variable, page 36</i>
Out_urg	INT	–	–	Priority level Bit 0 = Pulling Bit 1 = Writing priority Bit 2 = Reading priority Bit 3 = Fault priority
Out_st[0]...[31]	ARRAY [0...31] of INT	–	–	See <i>Out_st[0]...[31] Public Variable, page 37</i>

**In\_cmd[0]...[31] Public Variable**

The In\_cmd[0]...[31] public variable is a table of 32 words corresponding to the TeSys U Modbus slave address. The following table describes the In\_cmd[0]...[31] public variable:

Public Variable	Type	Bit	Description Corresponding to the TeSys U Slave 1...31	LUCA/UEL	LUCE/UD	LUOM
In_cmd[0]	INT	–	Not significant			
In_cmd[1]...[31]	INT	0	Motor run forward command	√	√	√
		1	Motor run reverse command	√	√	√
		2	Reserved			
		3	Reset fault (if register 451 = 102 or 104, fault acknowledgment causes a return to communication module factory settings)	√	√	√
		4	Reserved			
		5	Automatic thermal overload fault test			√
		6	Overcurrent trip test via communication bus			√
		7	Reserved			
		8	Reset warning (for example, communication loss)	√	√	√
		9...15	Reserved			

**Out\_st[0]...[31] Public Variable**

The Out\_st[0]...[31] public variable is a table of 32 words corresponding to the TeSys U Modbus slave address. The following table describes the Out\_st[0]...[31] public variable:

Public Variable	Type	Bit	Description Corresponding to the TeSys U Slave 1...31	LUCAIUCI	LUCEBO	LUCEM
Out_st[0]	INT	–	Not significant			
Out_st[1]...[31]	INT	0	System ready: the rotary handle is turned to On position and there is no fault	√	√	√
		1	Pole status: closed	√	√	√
		2	All faults	√	√	√
		3	All warnings	√	√	√
		4	System tripped: the rotary handle is turned to Trip position	√	√	√
		5	Fault reset is authorized		√	√
		6	Reserved			
		7	Motor running with detection of current, if greater than 10% FLA		√	√
		8...13	Average motor current (% FLA) 32 = 100% FLA 63 = 200% FLA		√	√
		14	Reserved			
15	Start in progress: 1 = ascending current is greater than 10% FLA 0 = descending current is lower than 150% FLA		√	√		

## Ctrl\_cmd\_mdb\_t\_xxxx: TeSys T Control/Command for Modbus SL

### Presentation

The Ctrl\_cmd\_mdb\_t\_\*\*\* derived function blocks (DFBs) are dedicated to the control and command of a single TeSys T LTM R\*\*M\*\* Modbus SL controller with or without the LTM E expansion module through the Modbus SL network.


- Ctrl\_cmd\_mdb\_t\_addr uses XWAY addressing and is dedicated to Premium PLCs.
- Ctrl\_cmd\_mdb\_t\_addm uses an addressing method dedicated to M340 PLCs.

For more information, see the *TeSys T LTM R Modbus Motor Management Controller User manual*.

### Characteristics

Characteristic	Value	
Name	Ctrl_cmd_mdb_t_addr	Ctrl_cmd_mdb_t_addm
Version	1.00	1.00
Input	10	10
Output	24	24
Input/Output	0	0
Public Variable	6	8

Graphical Representation



## TeSys T Compliance

The Ctrl\_cmd\_mdb\_t\_\*\*\* DFBs are compliant with all the TeSys T LTM R\*\*M\*\* controller versions, with or without the LTM E expansion module.

## Software Implementation

The parameters and the inputs can only be changed if the End\_st output variable is set to 1.

The output data is only valid if the End\_st output variable is set to 1 and if there is no fault state (Fault\_st = 0).

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	De- fault Value	Description
Slav_num	INT	1...31	1	Modbus slave number
Prog_num	INT	1...30	–	See <i>Program Number</i> , page 41
Rst_cmd	EBOOL	0...1	0	Reset command
Strt_cmd	EBOOL	0...1	0	Start command
Run_fwd	EBOOL	0...1	0	Motor run forward command
Run_rev	EBOOL	0...1	0	Motor run reverse command
Rstflt	EBOOL	0...1	0	Fault reset command
Autotest	EBOOL	0...1	0	Self test command
Lo_speed	EBOOL	0...1	0	Motor low speed command
In_word	INT	–	–	This input is only used when program number is 10, 20, or 30. See next table and program number description.



The following table describes the In\_word input:

Input	Type	Bit	Description
In_word	INT	0	Motor run forward command
		1	Motor run reverse command
		2	Reserved
		3	Fault reset command
		4	Reserved
		5	Self test command
		6	Motor low speed command
		7...15	Reserved

### Program Number

The program number enables the user to select bit or word control.

The following table describes the programs of the DFB:

Program Number	Description
1	Read registers 455 and 456, then write register 704 (systematic)
2	Read registers 455 and 456, then write register 704 (conditional)
3	Write register 704
10	Same as program 1 but using the In_word input and the Out_word output
20	Same as program 2 but using the In_word input and the Out_word output
30	Same as program 3 but using the In_word input and the Out_word output

## Output Characteristics

The following table describes the DFB outputs:

Output	Type	Range	Default Value	Description
Fault_st	EBOOL	0...1	0	Fault state
Rst_st	EBOOL	0...1	0	Reset state
End_st	EBOOL	0...1	0	End state
Ready	EBOOL	0...1	0	System ready
Syst_on	EBOOL	0...1	0	System On
Fault	EBOOL	0...1	0	System fault
Alarm	EBOOL	0...1	0	System warning
Tripped	EBOOL	0...1	0	System tripped
Rst_auth	EBOOL	0...1	0	Fault reset authorized
Ctrl_pwr	EBOOL	0...1	0	Controller power
Running	EBOOL	0...1	0	Motor running (with detection of a current, if greater than 10% FLC)
Avg_curr	INT	0...200	0	Motor average current ratio (x 1% FLC)
Starting	EBOOL	0...1	0	Motor starting (start in progress) 0 = descending current is less than 150% FLC 1 = ascending current is greater than 10% FLC
Hi_speed	EBOOL	0...1	0	Motor high speed
Hmi_ctrl	EBOOL	0...1	0	Control through HMI
Auto_rst	EBOOL	0...1	0	Auto-reset active
Pwr_rqst	EBOOL	0...1	0	Fault power cycle requested
Rst_Time	EBOOL	0...1	0	Motor restart time undefined
Rpd_cycl	EBOOL	0...1	0	Rapid cycle lockout
Load_shd	EBOOL	0...1	0	Load shedding
Hmi_loss	EBOOL	0...1	0	HMI port communication loss
Net_loss	EBOOL	0...1	0	Network port communication loss
Motor_tr	EBOOL	0...1	0	Motor transition lockout
Out_word	DINT	–	–	This output is only used when program number is 10, 20, or 30. See next table and program number description.

The following table describes the Out\_word output:

Output	Type	Bit	Description
Out_word	DINT	0	System ready
		1	System On
		2	System fault
		3	System warning
		4	System tripped
		5	Fault reset authorized
		6	Controller power
		7	Motor running (with detection of a current, if greater than 10% FLC)
		8...13	Motor average current ratio 32 = 100% FLC 63 = 200% FLC
		14	Control through HMI
		15	Motor starting (start in progress) 0 = descending current is less than 150% FLC 1 = ascending current is greater than 10% FLC
		16	Auto-reset active
		17	Not significant
		18	Fault power cycle requested
		19	Motor restart time undefined
		20	Rapid cycle lockout
		21	Load shedding
		22	Motor speed 0 = FLC1 setting is used 1 = FLC2 setting is used
		23	HMI port communication loss
		24	Network port communication loss
		25	Motor transition lockout
		26...31	Not significant

### Public Variables Characteristics

The following table describes the Ctrl\_cmd\_mdb\_t\_addr and the Ctrl\_cmd\_mdb\_t DFBs public variables (using XWAY addressing):

Public Variable	Type	Range	De- fault Value	Description
Net_num	INT	100...255	100	Network address
Stat_num	INT	0...255	0	Station address
Rack_num	INT	0...7	0	Destination rack address
Slot_num	INT	0...10	0	Destination slot address
Chan_num	INT	0...1	0	Destination channel address
Sq_princ	INT	0...7	0	Reserved for support

The following table describes the Ctrl\_cmd\_mdb\_t\_addm DFB public variables (using M340 addressing):

Public Variable	Type	Range	De- fault Value	Description
Rack_num	INT	0...7	0	Destination rack address
Slot_num	INT	0...10	0	Destination slot address
Chan_num	INT	0...1	0	Destination channel address
IP_addr1	INT	0...255	0	First byte of IP address
IP_addr2	INT	0...255	0	Second byte of IP address
IP_addr3	INT	0...255	0	Third byte of IP address
IP_addr4	INT	0...255	0	Fourth byte of IP address
Sq_princ	INT	0...7	0	Reserved for support

## Comm\_manager\_t: TeSys T Communication Management for Modbus SL

### Presentation

The Comm\_manager\_t derived function block (DFB) is dedicated to the control and command of up to 31 TeSys T LTMR••M•• Modbus SL controllers with or without the LTM E expansion module through the Modbus SL network. It must be associated with the Ctrl\_cmd\_mdb\_t•••• DFB to manage the Modbus requests sequencing.


The number of TeSys T Modbus slaves is define din the Slav\_num variable (Slav\_num = 1...31).

For more information, see the *TeSys T LTM R Modbus Motor Management Controller User manual*.

### Characteristics

Characteristic	Value
Name	Comm_manager_t
Version	1.00
Input	4
Output	4
Input/Output	0
Public Variable	3

### Graphical Representation




### TeSys T Compliance

The Comm\_manager\_t DFB is compliant with all the TeSys T LTM R••M•• controller versions, with or without the LTM E expansion module.

### Software Implementation

The following figure shows a Unity Pro program extract in FBD language showing how to interconnect the Ctrl\_cmd\_mdb\_t and the Comm\_manager\_t DFBs:



The Comm\_manager\_t DFB can be used in case both TeSys U starter-controllers and TeSys T motor management systems are present on the same Modbus SL network.

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	Default Value	Description
Slav_num	INT	1...31	1	Modbus slave number
Flt_cmd	EBOOL	0...1	0	Reset command
Strt_cmd	EBOOL	0...1	0	Start command
In_word	DINT	–	–	To connect to the Out_word output of the Ctrl_cmd_mdb_t_*** DFB

## Output Characteristics

The following table describes the DFB outputs:

Output	Type	Range	Default Value	Description
Slav_st	INT	1...31	1	Modbus slave number
Prog_st	INT	20 or 30	–	Program number of the Ctrl_cmd_mdb_t_*** DFB
End_st	EBOOL	0...1	0	End state
Out_word	INT	–	–	To connect to the In_word input of the Ctrl_cmd_mdb_t_*** DFB

## Public Variables Characteristics

The following table describes the DFB public variables:

Public Variable	Type	Range	Default Value	Description
In_cmd[0]...[31]	ARRAY [0...31] of INT	–	–	See <i>In_cmd[0]...[31] Public Variable</i> , page 48
Out_urg	INT	–	–	Priority level Bit 0 = Pulling Bit 1 = Writing priority Bit 2 = Reading priority Bit 3 = Fault priority
Out_st[0]...[31]	ARRAY [0...31] of DINT	–	–	See <i>Out_st[0]...[31] Public Variable</i> , page 49

**In\_cmd[0]...[31] Public Variable**

The In\_cmd[0]...[31] public variable is a table of 32 words corresponding to the TeSys T Modbus slave address. The following table describes the In\_cmd[0]...[31] public variable:

Public Variable	Type	Bit	Description Corresponding to the TeSys T Slave 1...31
In_cmd[0]	INT	–	Not significant
In_cmd[1]...[31]	INT	0	Motor run forward command
		1	Motor run reverse command
		2	Reserved
		3	Fault reset command
		4	Reserved
		5	Self test command
		6	Motor low speed command
		7...31	Reserved



**Out\_st[0]...[31] Public Variable**

The Out\_st[0]...[31] public variable is a table of 32 words corresponding to the TeSys T Modbus slave address. The following table describes the Out\_st[0]...[31] public variable:

Public Variable	Type	Bit	Description Corresponding to the TeSys T Slave 1...31
Out_st[0]	DINT	–	Not significant
Out_st[1]...[31]	DINT	0	System ready
		1	System On
		2	System fault
		3	System warning
		4	System tripped
		5	Fault reset authorized
		6	Controller power
		7	Motor running (with detection of a current, if greater than 10% FLC)
		8...13	Motor average current ratio 32 = 100% FLC 63 = 200% FLC
		14	Control through HMI
		15	Motor starting (start in progress) 0 = descending current is less than 150% FLC 1 = ascending current is greater than 10% FLC
		16	Auto-reset active
		17	Not significant
		18	Fault power cycle requested
		19	Motor restart time undefined
		20	Rapid cycle lockout
		21	Load shedding
		22	Motor speed 0 = FLC1 setting is used 1 = FLC2 setting is used
		23	HMI port communication loss
		24	Network port communication loss
25	Motor transition lockout		
26...31	Not significant		



---

# Modbus SL and Modbus ® \ TCP DFB

# 3

---

## Introduction

This chapter describes the TeSys U and TeSys T Modbus SL and Modbus ® \ TCP DFBs.

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Special_mdb_u_xxxx: TeSys U DFB for Modbus SL and Modbus ® \ TCP	52
Special_mdb_t_xxxx: TeSys T DFB for Modbus SL and Modbus ® \ TCP	62
Custom_mdb_xxxx: Custom Read DFB for Modbus SL and Modbus ® \ TCP	77

## Special\_mdb\_u\_xxxx: TeSys U DFB for Modbus SL and Modbus ® \ TCP

### Presentation

The Special\_mdb\_u\_\*\*\*\* derived function blocks (DFBs) are dedicated to the reading of up to 16 predefined registers of a TeSys U starter-controller (up to 32 A/15 kW) equipped with a LUCM multifunction control unit and a LULC032-033 Modbus communication module directly through a Modbus SL network or through an Ethernet gateway with a Modbus ® \ TCP network.


- Special\_mdb\_u\_addr uses XWAY addressing and is dedicated to Premium PLCs.
- Special\_mdb\_u\_addm uses an addressing method dedicated to M340 PLCs.

For more information, see the *LULC032-033 Modbus Communication Module User Manual*.

### Characteristics

Characteristic	Value	
Name	Special_mdb_u_addr	Special_mdb_u_addm
Version	1.00	1.00
Input	4	4
Output	3	3
Input/Output	0	0
Public Variable	7	9

### Graphical Representation



## TeSys U Compliance

The Special\_mdb\_u\_\*\*\* DFBs are compliant with the following TeSys U sub-assemblies:

<b>Power base</b>	<ul style="list-style-type: none"> <li>● LUB** non-reversing power base (up to 32 A/15 kW)</li> <li>● LU2B** reversing power base (up to 32 A/15 kW)</li> </ul>
<b>Control unit</b>	<ul style="list-style-type: none"> <li>● LUCM multifunction control unit</li> </ul>
<b>Communication module</b>	<ul style="list-style-type: none"> <li>● LULC032-033 Modbus communication module</li> </ul>

## Software Implementation

The parameters and the inputs can only be changed if the End\_st output variable is set to 1.

The output data is only valid if the End\_st output variable is set to 1 and if there is no fault state (Fault\_st = 0).

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	Default Value	Description
Slav_num	INT	1...31	1	Modbus slave number
Prog_num	INT	0..6	0	Program number <i>See Program Number, page 54</i>
Rst_cmd	EBOOL	0...1	0	Reset command
Strt_cmd	EBOOL	0...1	0	Start command

## Output Characteristics

The following table describes the DFB outputs:

Output	Type	Range	Default Value	Description
Fault_st	EBOOL	0...1	0	Fault state
Rst_st	EBOOL	0...1	0	Reset state
End_st	EBOOL	0...1	0	End state

## Program Number

The Prog\_num input variable enables the user to define the public variables data depending on the application type. Each program uses variables related to one application (diagnostic, maintenance, measurement,...). The following table describes the programs of the DFB:

Program Number	Description
0	Bypass: no action
1	Diagnostic: faults monitoring variables, warnings monitoring variables, and communication monitoring variables
2	Maintenance: global statistics variables
3	Measurements: measurements monitoring variables
4	Statistics: last trip statistics and trip N-1 statistics
5	Statistics: trip N-2 statistics and trip N-3 statistics
6	Statistics: trip N-4 statistics

## Public Variables Characteristics

The following table describes the Special\_mdb\_u\_addr and the Special\_mdb\_u DFBs public variables (using XWAY addressing):

Public Variable	Type	Range	De- fault Value	Description
Net_num	INT	100...255	100	Network address
Stat_num	INT	0...255	0	Station address
Rack_num	INT	0...7	0	Destination rack address
Slot_num	INT	0...10	0	Destination slot address
Chan_num	INT	0...1	0	Destination channel address
Sq_princ	INT	0...7	0	Reserved for support
Out_data[0]...[15]	ARRAY [0...15] of INT	0...65535	0	The output data depends on the program number. See <i>Out_data[0]...[15] Public Variable (Program 1)</i> , page 56... <i>Out_data[0]...[15] Public Variable (Program 6)</i> , page 61

The following table describes the Special\_mdb\_u\_adm DFB public variables (using M340 addressing):

Public Variable	Type	Range	De- fault Value	Description
Rack_num	INT	0...7	0	Destination rack address
Slot_num	INT	0...10	0	Destination slot address
Chan_num	INT	0...1	0	Destination channel address
IP_addr1	INT	0...255	0	First byte of IP address
IP_addr2	INT	0...255	0	Second byte of IP address
IP_addr3	INT	0...255	0	Third byte of IP address
IP_addr4	INT	0...255	0	Fourth byte of IP address
Sq_princ	INT	0...7	0	Reserved for support
Out_data[0]...[15]	ARRAY [0...15] of INT	0...65535	0	The output data depends on the program number. See <i>Out_data[0]...[15] Public Variable (Program 1)</i> , page 56... <i>Out_data[0]...[15] Public Variable (Program 6)</i> , page 61

**Out\_data[0]...[15] Public Variable (Program 1)**

The following table describes the Out\_data[0]...[15] public variable in the case of the diagnostic program (program number 1):

Public Variable	Type	Register	Bit	Description
Out_data[0]	INT	452	0	Short-circuit fault
			1	Magnetic fault
			2	Ground fault
			3	Thermal fault
			4	Long start fault
			5	Jam fault
			6	Phase imbalance fault
			7	Underload fault
			8	Shunt trip fault
			9	Test trip fault
			10	Communication loss fault on LUCM Modbus port
			11	Control unit internal fault
			12	Module identification or internal communication fault
			13	Module internal fault
			14	Module trip fault
15	Module drop-out fault			
Out_data[1]	INT	461	0...1	Not significant
			2	Ground fault warning
			3	Thermal warning
			4	Long start warning
			5	Jam warning
			6	Phase imbalance warning
			7	Under-current warning
			8...9	Not significant
			10	Communication loss fault on LUCM Modbus port
			11	Internal temperature warning
			12	Module identification or internal communication warning
			13...14	Not significant
			15	Module warning



Public Variable	Type	Register	Bit	Description
Out_data[2]	INT	457	0	Button position On (0 = Off)
			1	Button position Trip (0 = Not tripped)
			2	Contactator state On
			3	24 Vdc power supply present on outputs
			4...15	Not significant
Out_data[3]	INT	450	–	Time to automatic reset on a thermal fault (s)
Out_data[4] ...Out_data[15]	–	–	–	Not significant

### Out\_data[0]...[15] Public Variable (Program 2)

The following table describes the Out\_data[0]...[15] public variable in the case of the maintenance program (program number 2):

Public Variable	Type	Register	Description
Out_data[0]	INT	100	Short-circuit faults count
Out_data[1]	INT	101	Magnetic faults count
Out_data[2]	INT	102	Ground faults count
Out_data[3]	INT	103	Thermal faults count
Out_data[4]	INT	104	Long start faults count
Out_data[5]	INT	105	Jam faults count
Out_data[6]	INT	106	Phase imbalance faults count
Out_data[7]	INT	108	Shunt trip faults count
Out_data[8]	INT	115	Auto-resets count
Out_data[9]	INT	116	Thermal warnings count
Out_data[10]	INT	117	Starts count (LSB)
Out_data[11]	INT	118	Starts count (MSB)
Out_data[12]	INT	119	Operating time (LSB)
Out_data[13]	INT	120	Operating time (MSB)
Out_data[14]	INT	121	Maximum internal temperature (°C)
Out_data[15]	–	–	Not significant

**Out\_data[0]...[15] Public Variable (Program 3)**

The following table describes the Out\_data[0]...[15] public variable in the case of the measurements program (program number 3):

Public Variable	Type	Register	Description
Out_data[0]	–	–	Not significant
Out_data[1]	INT	465	Thermal capacity level (%)
Out_data[2]	INT	466	Average motor current (x 0.1 % FLA)
Out_data[3]	INT	467	L1 current (% FLA)
Out_data[4]	INT	468	L2 current (% FLA)
Out_data[5]	INT	469	L3 current (% FLA)
Out_data[6]	INT	470	Ground current (% FLA min)
Out_data[7]	INT	471	Current imbalance coefficient
Out_data[8]	INT	472	Control unit internal temperature (°C)
Out_data[9] ...Out_data[13]	–	–	Not significant
Out_data[14]	INT	79	Control unit sensor maximum current (x 0.1 A): <ul style="list-style-type: none"> <li>● 6 = adjustment range 0.15 to 0.6 A</li> <li>● 14 = adjustment range 0.35 to 1.4 A</li> <li>● 50 = adjustment range 1.25 to 5 A</li> <li>● 120 = adjustment range 3 to 12 A</li> <li>● 180 = adjustment range 4.5 to 18 A</li> <li>● 320 = adjustment range 8 to 32 A</li> </ul>
Out_data[15]	INT	652	Full load amps setting (% FLA max): <ul style="list-style-type: none"> <li>● minimum = 25 (default value)</li> <li>● maximum = 100</li> </ul>

**Out\_data[0]...[15] Public Variable (Program 4)**

The following table describes the Out\_data[0]...[15] public variable in the case of the statistics program (program number 4):

Public Variable	Type	Register	Description
Out_data[0]	INT	150	Last trip fault number
Out_data[1]	INT	152	Last trip thermal capacity level (% trip level)
Out_data[2]	INT	153	Last trip average current (% FLA)
Out_data[3]	INT	154	Last trip L1 current (% FLA)
Out_data[4]	INT	155	Last trip L2 current (% FLA)
Out_data[5]	INT	156	Last trip L3 current (% FLA)
Out_data[6]	INT	157	Last trip ground current (% FLA min)
Out_data[7]	INT	180	N-1 trip fault number
Out_data[8]	INT	182	N-1 trip thermal capacity level (% trip level)
Out_data[9]	INT	183	N-1 trip average current (% FLA)
Out_data[10]	INT	184	N-1 trip L1 current (% FLA)
Out_data[11]	INT	185	N-1 trip L2 current (%FLA)
Out_data[12]	INT	186	N-1 trip L3 current (% FLA)
Out_data[13]	INT	187	N-1 trip ground current (% FLA min)
Out_data[14]	INT	79	Control unit sensor maximum current (x 0.1 A): <ul style="list-style-type: none"> <li>● 6 = adjustment range 0.15 to 0.6 A</li> <li>● 14 = adjustment range 0.35 to 1.4 A</li> <li>● 50 = adjustment range 1.25 to 5 A</li> <li>● 120 = adjustment range 3 to 12 A</li> <li>● 180 = adjustment range 4.5 to 18 A</li> <li>● 320 = adjustment range 8 to 32 A</li> </ul>
Out_data[15]	INT	652	Full load amps setting (% FLA max): <ul style="list-style-type: none"> <li>● minimum = 25 (default value)</li> <li>● maximum = 100</li> </ul>

**Out\_data[0]...[15] Public Variable (Program 5)**

The following table describes the Out\_data[0]...[15] public variable in the case of the statistics program (program number 5):

Public Variable	Type	Register	Description
Out_data[0]	INT	210	N-2 trip fault number
Out_data[1]	INT	212	N-2 trip thermal capacity level (% trip level)
Out_data[2]	INT	213	N-2 trip average current (% FLA)
Out_data[3]	INT	214	N-2 trip L1 current (% FLA)
Out_data[4]	INT	215	N-2 trip L2 current (% FLA)
Out_data[5]	INT	216	N-2 trip L3 current (% FLA)
Out_data[6]	INT	217	N-2 trip ground current (% FLA min)
Out_data[7]	INT	240	N-3 trip fault number
Out_data[8]	INT	242	N-3 trip thermal capacity level (% trip level)
Out_data[9]	INT	243	N-3 trip average current (% FLA)
Out_data[10]	INT	244	N-3 trip L1 current (% FLA)
Out_data[11]	INT	245	N-3 trip L2 current (%FLA)
Out_data[12]	INT	246	N-3 trip L3 current (% FLA)
Out_data[13]	INT	247	N-3 trip ground current (% FLA min)
Out_data[14]	INT	79	Control unit sensor maximum current (x 0.1 A): <ul style="list-style-type: none"> <li>● 6 = adjustment range 0.15 to 0.6 A</li> <li>● 14 = adjustment range 0.35 to 1.4 A</li> <li>● 50 = adjustment range 1.25 to 5 A</li> <li>● 120 = adjustment range 3 to 12 A</li> <li>● 180 = adjustment range 4.5 to 18 A</li> <li>● 320 = adjustment range 8 to 32 A</li> </ul>
Out_data[15]	INT	652	Full load amps setting (% FLA max): <ul style="list-style-type: none"> <li>● minimum = 25 (default value)</li> <li>● maximum = 100</li> </ul>

**Out\_data[0]...[15] Public Variable (Program 6)**

The following table describes the Out\_data[0]...[15] public variable in the case of the statistics program (program number 6):

Public Variable	Type	Register	Description
Out_data[0]	INT	270	N-4 trip fault number
Out_data[1]	INT	272	N-4 trip thermal capacity level (% trip level)
Out_data[2]	INT	273	N-4 trip average current (% FLA)
Out_data[3]	INT	274	N-4 trip L1 current (% FLA)
Out_data[4]	INT	275	N-4 trip L2 current (% FLA)
Out_data[5]	INT	276	N-4 trip L3 current (% FLA)
Out_data[6]	INT	277	N-4 trip ground current (% FLA min)
Out_data[7] ...Out_data[13]	–	–	Reserved
Out_data[14]	INT	79	Control unit sensor maximum current (x 0.1 A): <ul style="list-style-type: none"> <li>● 6 = adjustment range 0.15 to 0.6 A</li> <li>● 14 = adjustment range 0.35 to 1.4 A</li> <li>● 50 = adjustment range 1.25 to 5 A</li> <li>● 120 = adjustment range 3 to 12 A</li> <li>● 180 = adjustment range 4.5 to 18 A</li> <li>● 320 = adjustment range 8 to 32 A</li> </ul>
Out_data[15]	INT	652	Full load amps setting (% FLA max): <ul style="list-style-type: none"> <li>● minimum = 25 (default value)</li> <li>● maximum = 100</li> </ul>

## Special\_mdb\_t\_xxxx: TeSys T DFB for Modbus SL and Modbus ® \ TCP

### Presentation

The Special\_mdb\_t\_xxxx derived function blocks (DFBs) are dedicated to the reading of up to 16 predefined registers of a TeSys T LTM R•M•• controller through the Modbus SL network or a TeSys T LTM R•E•• controller through the Modbus ® \ TCP network.


- Special\_mdb\_t\_addr uses XWAY addressing and is dedicated to Premium PLCs.
- Special\_mdb\_t\_addm uses an addressing method dedicated to M340 PLCs.

For more information, see the *TeSys T LTM R Modbus SL Motor Management Controller User manual* and the *TeSys T LTM R Modbus ® \ TCP Motor Management Controller User manual*.

### Characteristics

Characteristic	Value	
Name	Special_mdb_t_addr	Special_mdb_t_addm
Version	1.00	1.00
Input	4	4
Output	3	3
Input/Output	0	0
Public Variable	7	9

### Graphical Representation



### TeSys T Compliance

The Special\_mdb\_t\_xxxx DFBs are compliant with all the TeSys T LTM R•M•• and LTM R•E•• controller versions, with or without the LTM E expansion module.

## Software Implementation

The parameters and the inputs can only be changed if the End\_st output variable is set to 1.

The output data is only valid if the End\_st output variable is set to 1 and if there is no fault state (Fault\_st = 0).

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	Default Value	Description
Slav_num	INT	1...31	1	Modbus slave number
Prog_num	INT	0...6	0	Program number See <i>Program Number, page 64</i>
Rst_cmd	EBOOL	0...1	0	Reset command
Strt_cmd	EBOOL	0...1	0	Start command

## Output Characteristics

The following table describes the DFB outputs:

Output	Type	Range	Default Value	Description
Fault_st	EBOOL	0...1	0	Fault state
Rst_st	EBOOL	0...1	0	Reset state
End_st	EBOOL	0...1	0	End state

## Program Number

The Prog\_num input variable enables the user to define the public variables data depending on the application type. Each program holds variables related to one application (diagnostic, maintenance, measurement,...). The following table describes the programs of the DFB:

Program Number	Description
0	Bypass: no action
10	Diagnostic: faults monitoring variables, warnings monitoring variables, and communication monitoring variables
20	Maintenance: global statistics variables
30	Measurements 1
31	Measurements 2
32	Measurements 3
40	Statistics: last fault statistics (N-0)
41	Statistics: last fault statistics with expansion module (N-0)
50	Statistics: N-1 fault statistics
51	Statistics: N-1 fault statistics (with expansion module)
60	Statistics: N-2 fault statistics
61	Statistics: N-2 fault statistics (with expansion module)
70	Statistics: N-3 fault statistics
71	Statistics: N-3 fault statistics (with expansion module)
80	Statistics: N-4 fault statistics
81	Statistics: N-4 fault statistics (with expansion module)



## Public Variables Characteristics

The following table describes the Special\_mdb\_t\_addr and the Special\_mdb\_t DFBs public variables (using XWAY addressing):

Public Variable	Type	Range	De- fault Value	Description
Net_num	INT	100...255	100	Network address
Stat_num	INT	0...255	0	Station address
Rack_num	INT	0...7	0	Destination rack address
Slot_num	INT	0...10	0	Destination slot address
Chan_num	INT	0...1	0	Destination channel address
Sq_princ	INT	0...7	0	Reserved for support
Out_data[0]...[15]	ARRAY [0...15] of INT	0...65535	0	The output data depends on the program number. See <i>Out_data[0]...[15] Public Variable (Program 1)</i> , page 56... <i>Out_data[0]...[15] Public Variable (Program 6)</i> , page 61

The following table describes the Special\_mdb\_t\_addm DFB public variables (using M340 addressing):

Public Variable	Type	Range	De- fault Value	Description
Rack_num	INT	0...7	0	Destination rack address
Slot_num	INT	0...10	0	Destination slot address
Chan_num	INT	0...1	0	Destination channel address
IP_addr1	INT	0...255	0	First byte of IP address
IP_addr2	INT	0...255	0	Second byte of IP address
IP_addr3	INT	0...255	0	Third byte of IP address
IP_addr4	INT	0...255	0	Fourth byte of IP address
Sq_princ	INT	0...7	0	Reserved for support
Out_data[0]...[15]	ARRAY [0...15] of INT	0...65535	0	The output data depends on the program number. See <i>Out_data[0]...[15] Public Variable (Program 1)</i> , page 56... <i>Out_data[0]...[15] Public Variable (Program 6)</i> , page 61

**Out\_data[0]...[15] Public Variable (Program 10)**

The following table describes the Out\_data[0]...[15] public variable in the case of the diagnostic program (program number 10):

Public Variable	Type	Register	Bit	Description
Out_data[0]	INT	452	0...1	Reserved
			2	Ground current fault
			3	Thermal overload fault
			4	Long start fault
			5	Jam fault
			6	Current phase imbalance fault
			7	Undercurrent fault
			8	Reserved
			9	Test fault
			10	HMI port fault
			11	Controller internal fault
			12	Internal port fault
			13	Not significant
			14	Network port config fault
			15	Network port fault
Out_data[1]	INT	453	0	External system fault
			1	Diagnostic fault
			2	Wiring fault
			3	Overcurrent fault
			4	Current phase loss fault
			5	Current phase reversal fault
			6	Motor temperature sensor fault (1)
			7	Voltage phase imbalance fault (1)
			8	Voltage phase loss fault (1)
			9	Voltage phase reversal fault (1)
			10	Undervoltage fault (1)
			11	Overvoltage fault (1)
			12	Underpower fault (1)
			13	Overpower fault (1)
			14	Under power factor fault (1)
15	Over power factor fault (1)			
(1) The variable is available for the LTM R controller and the LTM EV40 expansion module combination.				

Public Variable	Type	Register	Bit	Description
Out_data[2]	INT	461	0...1	Not significant
			2	Ground current warning
			3	Thermal overload warning
			4	Not significant
			5	Jam warning
			6	Current phase imbalance warning
			7	Undercurrent warning
			8...9	Not significant
			10	HMI port warning
			11	Controller internal temperature warning
			12...14	Not significant
			15	Network port warning
Out_data[3]	INT	462	0	Not significant
			1	Diagnostic warning
			2	Reserved
			3	Overcurrent warning
			4	Current phase loss warning
			5	Current phase reversal warning
			6	Motor temperature sensor warning
			7	Voltage phase imbalance warning (1)
			8	Voltage phase loss warning (1)
			9	Not significant
			10	Undervoltage warning (1)
			11	Overvoltage warning (1)
			12	Underpower warning (1)
			13	Overpower warning (1)
			14	Under power factor warning (1)
15	Over power factor warning (1)			
(1) The variable is available for the LTM R controller and the LTM EV40 expansion module combination.				

Public Variable	Type	Register	Bit	Description
Out_data[4]	INT	457	0	Logic input 1
			1	Logic input 2
			2	Logic input 3
			3	Logic input 4
			4	Logic input 5
			5	Logic input 6
			6	Logic input 7
			7	Logic input 8 (1)
			8	Logic input 9 (1)
			9	Logic input 10 (1)
			10	Logic input 11 (1)
			11	Logic input 12 (1)
			12	Logic input 13 (1)
			13	Logic input 14 (1)
			14	Logic input 15 (1)
			15	Logic input 16 (1)
Out_data[5]	INT	458	0	Logic output 1
			1	Logic output 2
			2	Logic output 3
			3	Logic output 4
			4	Logic output 5 (1)
			5	Logic output 6 (1)
			6	Logic output 7 (1)
			7	Logic output 8 (1)
8...15	Reserved			
Out_data[6]	INT	450	–	Minimum wait time (s)
Out_data[7] ...Out_data[15]	–	–	–	Reserved
(1) The variable is available for the LTM R controller and the LTM EV40 expansion module combination.				

**Out\_data[0]...[15] Public Variable (Program 20)**

The following table describes the Out\_data[0]...[15] public variable in the case of the maintenance program (program number 20):

Public Variable	Type	Register	Description
Out_data[0]	INT	102	Ground current faults count
Out_data[1]	INT	103	Thermal overload faults count
Out_data[2]	INT	104	Long start faults count
Out_data[3]	INT	105	Jam faults count
Out_data[4]	INT	106	Current phase imbalance faults count
Out_data[5]	INT	107	Undercurrent faults count
Out_data[6]	–	–	Reserved
Out_data[7]	INT	114	Network port faults count
Out_data[8]	INT	115	Auto-resets count
Out_data[9]	INT	116	Thermal overload warnings count
Out_data[10]	INT	117	Motor starts count (LSB)
Out_data[11]	INT	118	Motor starts count (MSB)
Out_data[12]	INT	119	Operating time (s) (LSB)
Out_data[13]	INT	120	Operating time (MSB)
Out_data[14]	INT	121	Maximum controller internal temperature (°C)
Out_data[15]	–	–	Reserved

**Out\_data[0]...[15] Public Variable (Program 30)**

The following table describes the Out\_data[0]...[15] public variable in the case of the first measurements program (program number 30):

Public Variable	Type	Register	Description
Out_data[0]	–	–	Reserved
Out_data[1]	INT	465	Thermal capacity level (% trip level)
Out_data[2]	INT	466	Average current ratio (% FLC)
Out_data[3]	INT	467	L1 current ratio (% FLC)
Out_data[4]	INT	468	L2 current ratio (% FLC)
Out_data[5]	INT	469	L3 current ratio (% FLC)
Out_data[6]	INT	470	Ground current ratio (x 0.1 % FLC min)
Out_data[7]	INT	471	Current phase imbalance (%)
Out_data[8]	INT	472	Controller internal temperature (°C)
Out_data[9]	INT	474	Frequency (x 0.01 Hz)
Out_data[10]	INT	475	Motor temperature sensor (x 0.1 Ω)
Out_data[11] ...Out_data[13]	–	–	Reserved
Out_data[14]	INT	96	Full load current (FLC) max (x 0.1 A)
Out_data[15]	INT	652	Motor full load current ratio

**Out\_data[0]...[15] Public Variable (Program 31)**

The following table describes the Out\_data[0]...[15] public variable in the case of the second measurements program (program number 31):

Public Variable	Type	Register	Description
Out_data[0]	INT	500	Average current (x 0.01 A) MSB
Out_data[1]	INT	501	Average current (x 0.01 A) LSB
Out_data[2]	INT	502	L1 current (x 0.01 A) MSB
Out_data[3]	INT	503	L1 current (x0.01 A) LSB
Out_data[4]	INT	504	L2 current (x 0.01 A) MSB
Out_data[5]	INT	505	L2 current (x0.01 A) LSB
Out_data[6]	INT	506	L3 current (x 0.01 A) MSB
Out_data[7]	INT	507	L3 current (x0.01 A) LSB
Out_data[8]	INT	508	Ground current (x 0.001 A) MSB
Out_data[9]	INT	509	Ground current (x 0.001 A) LSB
Out_data[10]	INT	511	Time to trip (x 1 s)
Out_data[11]	INT	512	Motor last start current ratio (% FLC)
Out_data[12]	INT	513	Motor last start duration (s)
Out_data[13]	INT	514	Motor starts per hour count
Out_data[14] ...Out_data[15]	–	–	–

**Out\_data[0]...[15] Public Variable (Program 32)**

The following table describes the Out\_data[0]...[15] public variable in the case of the third measurements program (program number 32):

Public Variable	Type	Register	Description
Out_data[0]	INT	476	Average voltage (V)
Out_data[1]	INT	477	L3-L1 voltage (V)
Out_data[2]	INT	478	L1-L2 voltage (V)
Out_data[3]	INT	479	L2-L3 voltage (V)
Out_data[4]	INT	480	Voltage phase imbalance (%)
Out_data[5]	INT	481	Power factor (x 0.01)
Out_data[6]	INT	482	Active power (x 0.1 kW)
Out_data[7]	INT	483	Reactive power (x 0.1 kVAr)
Out_data[8] ...Out_data[15]	–	–	Reserved

**Out\_data[0]...[15] Public Variable (Program 40)**

The following table describes the Out\_data[0]...[15] public variable in the case of the last fault statistics program (program number 40):

Public Variable	Type	Register	Description
Out_data[0]	INT	150	Fault code N-0
Out_data[1]	INT	151	Motor full load current ratio N-0 (% FLC max)
Out_data[2]	INT	152	Thermal capacity level N-0 (% trip level)
Out_data[3]	INT	153	Average current ratio N-0 (% FLC)
Out_data[4]	INT	154	L1 current ratio N-0 (% FLC)
Out_data[5]	INT	155	L2 current ratio N-0 (% FLC)
Out_data[6]	INT	156	L3 current ratio N-0 (% FLC)
Out_data[7]	INT	157	Ground current ratio N-0 (x 0.1 % FLC min)
Out_data[8]	INT	158	Full load current max N-0 (x 0.1 A)
Out_data[9]	INT	159	Current phase imbalance N-0 (%)
Out_data[10]	INT	160	Frequency N-0 (x 0.1 Hz)
Out_data[11]	INT	161	Motor temperature sensor N-0 (x 0.1 Ω)
Out_data[12]	WORD[4]	162	Date and time N-0
Out_data[13]		163	See <i>DT_DateTime</i> , page 126
Out_data[14]		164	
Out_data[15]		165	

**Out\_data[0]...[15] Public Variable (Program 41)**

The following table describes the Out\_data[0]...[15] public variable in the case of the last fault statistics with expansion module program (program number 41):

Public Variable	Type	Register	Description
Out_data[0]	INT	166	Average voltage N-0 (V)
Out_data[1]	INT	167	L3-L1 voltage N-0 (V)
Out_data[2]	INT	168	L1-L2 voltage N-0 (V)
Out_data[3]	INT	169	L2-L3 voltage N-0 (V)
Out_data[4]	INT	170	Voltage phase imbalance N-0 (%)
Out_data[5]	INT	171	Active power N-0 (kW)
Out_data[6]	INT	172	Power factor N-0 (x 0.01)
Out_data[7] ...Out_data[15]	–	–	Reserved



**Out\_data[0]...[15] Public Variable (Program 50)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-1 fault statistics program (program number 50):

Public Variable	Type	Register	Description
Out_data[0]	INT	180	Fault code N-1
Out_data[1]	INT	181	Motor full load current ratio N-1 (% FLC max)
Out_data[2]	INT	182	Thermal capacity level N-1 (% trip level)
Out_data[3]	INT	183	Average current ratio N-1 (% FLC)
Out_data[4]	INT	184	L1 current ratio N-1 (% FLC)
Out_data[5]	INT	185	L2 current ratio N-1 (% FLC)
Out_data[6]	INT	186	L3 current ratio N-1 (% FLC)
Out_data[7]	INT	187	Ground current ratio N-1 (x 0.1 % FLC min)
Out_data[8]	INT	188	Full load current max N-1 (x 0.1 A)
Out_data[9]	INT	189	Current phase imbalance N-1 (%)
Out_data[10]	INT	190	Frequency N-1 (x 0.1 Hz)
Out_data[11]	INT	191	Motor temperature sensor N-1 (x 0.1 Ω)
Out_data[12]	WORD[4]	192	Date and time N-1
Out_data[13]		193	See <i>DT_DateTime</i> , page 126
Out_data[14]		194	
Out_data[15]		195	

**Out\_data[0]...[15] Public Variable (Program 51)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-1 fault statistics with expansion module program (program number 51):

Public Variable	Type	Register	Description
Out_data[0]	INT	196	Average voltage N-1 (V)
Out_data[1]	INT	197	L3-L1 voltage N-1 (V)
Out_data[2]	INT	198	L1-L2 voltage N-1 (V)
Out_data[3]	INT	199	L2-L3 voltage N-1 (V)
Out_data[4]	INT	200	Voltage phase imbalance N-1 (%)
Out_data[5]	INT	201	Active power N-1 (kW)
Out_data[6]	INT	202	Power factor N-1 (x 0.01)
Out_data[7] ...Out_data[15]	–	–	Reserved

**Out\_data[0]...[15] Public Variable (Program 60)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-2 fault statistics program (program number 60):

Public Variable	Type	Register	Description
Out_data[0]	INT	210	Fault code N-2
Out_data[1]	INT	211	Motor full load current ratio N-2 (% FLC max)
Out_data[2]	INT	212	Thermal capacity level N-2 (% trip level)
Out_data[3]	INT	213	Average current ratio N-2 (% FLC)
Out_data[4]	INT	214	L1 current ratio N-2 (% FLC)
Out_data[5]	INT	215	L2 current ratio N-2 (% FLC)
Out_data[6]	INT	216	L3 current ratio N-2 (% FLC)
Out_data[7]	INT	217	Ground current ratio N-2 (x 0.1 % FLC min)
Out_data[8]	INT	218	Full load current max N-2 (x 0.1 A)
Out_data[9]	INT	219	Current phase imbalance N-2 (%)
Out_data[10]	INT	220	Frequency N-2 (x 0.1 Hz)
Out_data[11]	INT	221	Motor temperature sensor N-2 (x 0.1 Ω)
Out_data[12]	WORD[4]	222	Date and time N-2
Out_data[13]		223	See <i>DT_DateTime</i> , page 126
Out_data[14]		224	
Out_data[15]		225	

**Out\_data[0]...[15] Public Variable (Program 61)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-2 fault statistics with expansion module program (program number 61):

Public Variable	Type	Register	Description
Out_data[0]	INT	226	Average voltage N-2 (V)
Out_data[1]	INT	227	L3-L1 voltage N-2 (V)
Out_data[2]	INT	228	L1-L2 voltage N-2 (V)
Out_data[3]	INT	229	L2-L3 voltage N-2 (V)
Out_data[4]	INT	230	Voltage phase imbalance N-2 (%)
Out_data[5]	INT	231	Active power N-2 (kW)
Out_data[6]	INT	232	Power factor N-2 (x 0.01)
Out_data[7] ...Out_data[15]	–	–	Reserved

**Out\_data[0]...[15] Public Variable (Program 70)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-3 fault statistics program (program number 70):

Public Variable	Type	Register	Description
Out_data[0]	INT	240	Fault code N-3
Out_data[1]	INT	241	Motor full load current ratio N-3 (% FLC max)
Out_data[2]	INT	242	Thermal capacity level N-3 (% trip level)
Out_data[3]	INT	243	Average current ratio N-3 (% FLC)
Out_data[4]	INT	244	L1 current ratio N-3 (% FLC)
Out_data[5]	INT	245	L2 current ratio N-3 (% FLC)
Out_data[6]	INT	246	L3 current ratio N-3 (% FLC)
Out_data[7]	INT	247	Ground current ratio N-3 (x 0.1 % FLC min)
Out_data[8]	INT	248	Full load current max N-3 (x 0.1 A)
Out_data[9]	INT	249	Current phase imbalance N-3 (%)
Out_data[10]	INT	250	Frequency N-3 (x 0.1 Hz)
Out_data[11]	INT	251	Motor temperature sensor N-3 (x 0.1 $\Omega$ )
Out_data[12]	WORD[4]	252	Date and time N-3 See <i>DT_DateTime</i> , page 126
Out_data[13]		253	
Out_data[14]		254	
Out_data[15]		255	

**Out\_data[0]...[15] Public Variable (Program 71)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-3 fault statistics with expansion module program (program number 71):

Public Variable	Type	Register	Description
Out_data[0]	INT	256	Average voltage N-3 (V)
Out_data[1]	INT	257	L3-L1 voltage N-3 (V)
Out_data[2]	INT	258	L1-L2 voltage N-3 (V)
Out_data[3]	INT	259	L2-L3 voltage N-3 (V)
Out_data[4]	INT	260	Voltage phase imbalance N-3 (%)
Out_data[5]	INT	261	Active power N-3 (kW)
Out_data[6]	INT	262	Power factor N-3 (x 0.01)
Out_data[7] ...Out_data[15]	–	–	Reserved

**Out\_data[0]...[15] Public Variable (Program 80)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-4 fault statistics program (program number 80):

Public Variable	Type	Register	Description
Out_data[0]	INT	270	Fault code N-4
Out_data[1]	INT	271	Motor full load current ratio N-4 (% FLC max)
Out_data[2]	INT	272	Thermal capacity level N-4 (% trip level)
Out_data[3]	INT	273	Average current ratio N-4 (% FLC)
Out_data[4]	INT	274	L1 current ratio N-4 (% FLC)
Out_data[5]	INT	275	L2 current ratio N-4 (% FLC)
Out_data[6]	INT	276	L3 current ratio N-4 (% FLC)
Out_data[7]	INT	277	Ground current ratio N-4 (x 0.1 % FLC min)
Out_data[8]	INT	278	Full load current max N-4 (x 0.1 A)
Out_data[9]	INT	279	Current phase imbalance N-4 (%)
Out_data[10]	INT	280	Frequency N-4 (x 0.1 Hz)
Out_data[11]	INT	281	Motor temperature sensor N-4 (x 0.1 Ω)
Out_data[12]	WORD[4]	282	Date and time N-4
Out_data[13]		283	See <i>DT_DateTime</i> , page 126
Out_data[14]		284	
Out_data[15]		285	

**Out\_data[0]...[15] Public Variable (Program 81)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-4 fault statistics with expansion module program (program number 81):

Public Variable	Type	Register	Description
Out_data[0]	INT	286	Average voltage N-4 (V)
Out_data[1]	INT	287	L3-L1 voltage N-4 (V)
Out_data[2]	INT	288	L1-L2 voltage N-4 (V)
Out_data[3]	INT	289	L2-L3 voltage N-4 (V)
Out_data[4]	INT	290	Voltage phase imbalance N-4 (%)
Out_data[5]	INT	291	Active power N-4 (kW)
Out_data[6]	INT	292	Power factor N-4 (x 0.01)
Out_data[7] ...Out_data[15]	–	–	Reserved

## Custom\_mdb\_xxxx: Custom Read DFB for Modbus SL and Modbus ® \ TCP

### Presentation

The Custom\_mdb\_\*\*\*\* derived function blocks (DFBs) are dedicated to the reading of up to 5 sets of registers in one single TeSys device through the Modbus SL or Modbus ® \ TCP networks.


- Custom\_mdb\_addr uses XWAY addressing and is dedicated to Premium PLCs.
- Custom\_mdb\_addm uses an addressing method dedicated to M340 PLCs.

The Custom\_mdb\_\*\*\*\* DFBs complete the Special\_mdb\_u\_\*\*\*\* and Special\_mdb\_t\_\*\*\*\* DFBs and enable the user to select the registers to read.

### Characteristics

Characteristic	Value	
Name	Custom_mdb_addr	Custom_mdb_addm
Version	1.00	1.00
Input	3	3
Output	3	3
Input/Output	0	0
Public Variable	13	15

### Graphical Representation



## TeSys U and TeSys T Compliance

- TeSys U: The Custom\_mdb\_\*\*\* DFBs are compliant with the following TeSys U sub-assemblies:
  - LUB\*\* non-reversing power base and LU2B\*\* reversing power base (up to 32 A/15 kW)
  - LUCM multifunction control unit
  - LULC032-033 Modbus communication module
- TeSys T: The Custom\_mdb\_\*\*\* DFBs are compliant with all the LTM R\*\*M\*\* and LTM R\*\*E\*\* controller versions, with or without the LTM E expansion module.

## Software Implementation

- The parameters and the inputs can only be changed if the End\_st output variable is set to 1.
- The output data is only valid if the End\_st output variable is set to 1 and if there is no fault state (Fault\_st = 0).
- The public variables enable the user to read up to 5 sets of registers of a maximum length of 16 registers for each set:
  - The user defines the starting point of a set of registers with the In\_reg public variable.
  - The user defines the length of the set of registers with the corresponding In\_len public variable.
  - The registers content is then returned in the corresponding Out\_dat public variable.

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	De-fault Value	Description
Slav_num	INT	1...31	1	Modbus slave number
Rst_cmd	EBOOL	0...1	0	Reset command
Strt_cmd	EBOOL	0...1	0	Start command

## Output Characteristics

The following table describes the DFB outputs:

Output	Type	Range	Default Value	Description
Fault_st	EBOOL	0...1	0	Fault state
Rst_st	EBOOL	0...1	0	Reset state
End_st	EBOOL	0...1	0	End state

## Public Variables Characteristics

The following table describes the Custom\_mdb\_addr and the Custom\_mdb DFBs public variables (using XWAY addressing):

Public Variable	Type	Range	Default Value	Description
Net_num	INT	100...255	100	Network address
Stat_num	INT	0...255	0	Station address
Rack_num	INT	0...7	0	Destination rack address
Slot_num	INT	0...10	0	Destination slot address
Chan_num	INT	0...1	0	Destination channel address
In_reg	ARRAY[0...4] of INT	0...65535	0	Array of 5 words for the 5 index registers (In_reg[0]...In_reg[4])
In_len	ARRAY[0...4] of INT	0...16	0	Array of 5 words for the length of each set of registers (In_len[0]...In_len[4])
Out_dat[0]	ARRAY[0...15] of INT	0...65535	0	Array of up to 16 words containing the In_len[0] words starting from In_reg[0]
Out_dat[1]	ARRAY[0...15] of INT	0...65535	0	Array of up to 16 words containing the In_len[1] words starting from In_reg[1]
Out_dat[2]	ARRAY[0...15] of INT	0...65535	0	Array of up to 16 words containing the In_len[2] words starting from In_reg[2]
Out_dat[3]	ARRAY[0...15] of INT	0...65535	0	Array of up to 16 words containing the In_len[3] words starting from In_reg[3]
Out_dat[4]	ARRAY[0...15] of INT	0...65535	0	Array of up to 16 words containing the In_len[4] words starting from In_reg[4]
Sq_princ	INT	0...7	0	Reserved for support

The following table describes the Custom\_mdb\_addm DFB public variables (using M340 addressing):

Public Variable	Type	Range	Default Value	Description
Rack_num	INT	0...7	0	Destination rack address
Slot_num	INT	0...10	0	Destination slot address
Chan_num	INT	0...1	0	Destination channel address
IP_addr1	INT	0...255	0	First byte of IP address
IP_addr2	INT	0...255	0	Second byte of IP address
IP_addr3	INT	0...255	0	Third byte of IP address
IP_addr4	INT	0...255	0	Fourth byte of IP address
In_reg	ARRAY[0...4] of INT	0...65535	0	Array of 5 words for the 5 index registers (In_reg[0]...In_reg[4])
In_len	ARRAY[0...4] of INT	0...16	0	Array of 5 words for the length of each set of registers (In_len[0]...In_len[4])
Out_dat[0]	ARRAY[0...15] of INT	0...255	0	Array of up to 16 words containing the In_len[0] words starting from In_reg[0]
Out_dat[1]	ARRAY[0...15] of INT	0...255	0	Array of up to 16 words containing the In_len[1] words starting from In_reg[1]
Out_dat[2]	ARRAY[0...15] of INT	0...255	0	Array of up to 16 words containing the In_len[2] words starting from In_reg[2]
Out_dat[3]	ARRAY[0...15] of INT	0...65535	0	Array of up to 16 words containing the In_len[3] words starting from In_reg[3]
Out_dat[4]	ARRAY[0...15] of INT	0...65535	0	Array of up to 16 words containing the In_len[4] words starting from In_reg[4]
Sq_princ	INT	0...7	0	Reserved for support



---

# Profibus DFB



---

## Introduction

This chapter describes the TeSys U and TeSys T Profibus DP DFBs.

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Ctrl_pfb_u_ms: TeSys U Control/Command for Profibus DP MS	82
Ctrl_pfb_u_mms: TeSys U Control/Command for Profibus DP MMS	85
Ctrl_pfb_t_mms: TeSys T Control/Command for Profibus DP MMS	88

## Ctrl\_pfb\_u\_ms: TeSys U Control/Command for Profibus DP MS

### Presentation


The Ctrl\_pfb\_u\_ms derived function block (DFB) is dedicated to the control and command of a single TeSys U starter-controller (up to 32 A/15 kW) through the Profibus DP MS (Motor Starter) network.

With the MS profile, the TeSys U starter-controller commands are managed on bit level. For more information, see the *LULC07 Profibus DP Communication Module User manual*.

### Characteristics

Characteristic	Value
Name	Ctrl_pfb_u_ms
Version	1.00
Input	7
Output	10
Input/Output	0
Public Variable	0

### Graphical Representation



## TeSys U Compliance

The Ctrl\_pfb\_u\_ms DFB is compliant with the following TeSys U sub-assemblies:

<b>Power base</b>	<ul style="list-style-type: none"> <li>● LUB** non-reversing power base (up to 32 A/15 kW)</li> <li>● LU2B** reversing power base (up to 32 A/15 kW)</li> </ul>
<b>Control unit</b>	<ul style="list-style-type: none"> <li>● LUCA standard control unit</li> <li>● LUCB, LUCC, and LUCD advanced control units</li> <li>● LUCL magnetic control unit</li> <li>● LUCM multifunction control unit</li> </ul>
<b>Communication module</b>	<ul style="list-style-type: none"> <li>● LULC07 Profibus DP communication module</li> </ul>
<b>GSD file modules</b>	<ul style="list-style-type: none"> <li>● Sc St R MS with or without PKW</li> <li>● Sc Ad R MS with or without PKW</li> <li>● Sc Mu R MS with or without PKW</li> <li>● Sc Mu L MS with or without PKW</li> </ul>

## Software Implementation

- Ms\_in1 input word must be linked to the first word of the Profibus slave input cyclic data.
- Ms\_out1 output word must be linked to the first word of the Profibus slave output cyclic data.

## Input Characteristics

The following table describes the DFB inputs and their availability according to the control unit:

Input	Type	Range	Default Value	Description	LUCALUCL	LUCBUCD	LUCM
Ms_in1	INT	–	0	Must be linked to the first word of the MS Profibus slave input cyclic data	√	√	√
Run_fwd	EBOOL	0...1	0	Motor run forward command	√	√	√
Run_rev	EBOOL	0...1	0	Motor run reverse command	√	√	√
Rstflt	EBOOL	0...1	0	Reset fault (if register 451 = 102 or 104, fault acknowledgment causes a return to communication module factory settings)	√	√	√
Rstwarn	EBOOL	0...1	0	Reset warning (for example, communication loss)	√	√	√
Em_strt	EBOOL	0...1	0	Emergency start (reset thermal memory)			√
Trip_tst	EBOOL	0...1	0	Overcurrent trip test via communication bus			√

## Output Characteristics

The following table describes the DFB outputs and their availability according to the control unit:

Output	Type	Range	Default Value	Description	LUPA/UC1	LURE/UC2	LURB/UC3
Ms_out1	INT	–	0	Must be linked to the first word of the MS Profibus slave output cyclic data	√	√	√
Ready	EBOOL	0...1	0	System ready: the rotary handle is turned to On position and there is no fault	√	√	√
Closed	EBOOL	0...1	0	Pole status: closed	√	√	√
Tripped	EBOOL	0...1	0	System tripped: the rotary handle is turned to Trip position	√	√	√
Fault	EBOOL	0...1	0	All faults	√	√	√
Alarm	EBOOL	0...1	0	All warnings	√	√	√
Rst_auth	EBOOL	0...1	0	Fault reset authorized		√	√
Starting	EBOOL	0...1	0	Start in progress: 1 = ascending current is greater than 10% FLA 0 = descending current is lower than 150% FLA		√	√
Running	EBOOL	0...1	0	Motor running with detection of current, if greater than 10% FLA		√	√
Avg_curr	INT	0...200	0	Average motor current (x 1% FLA)		√	√

## Ctrl\_pfb\_u\_mms: TeSys U Control/Command for Profibus DP MMS

### Presentation


The Ctrl\_pfb\_u\_mms derived function block (DFB) is dedicated to the control and command of a single TeSys U starter-controller (up to 32 A/15 kW) with a LUCM multifunction control unit and a LULC07 Profibus DP communication module through the Profibus DP MMS (Motor Management Starter) network.

With the MMS profile, the TeSys U starter-controller commands are managed on bit rising edges. For more information, see the *LULC07 Profibus DP Communication Module User manual*.

### Characteristics

Characteristic	Value
Name	Ctrl_pfb_u_mms
Version	1.00
Input	10
Output	13
Input/Output	0
Public Variable	0

## Graphical Representation



## TeSys U Compliance

The Ctrl\_pfb\_u\_mms DFB is compliant with the following TeSys U sub-assemblies:

<b>Power base</b>	<ul style="list-style-type: none"> <li>● LUB** non-reversing power base (up to 32 A/15 kW)</li> <li>● LU2B** reversing power base (up to 32 A/15 kW)</li> </ul>
<b>Control unit</b>	<ul style="list-style-type: none"> <li>● LUCM multifunction control unit</li> </ul>
<b>Communication module</b>	<ul style="list-style-type: none"> <li>● LULC07 Profibus DP communication module</li> </ul>
<b>GSD file modules</b>	<ul style="list-style-type: none"> <li>● Sc Mu R MMS with or without PKW</li> <li>● Sc Mu L MMS with or without PKW</li> </ul>

## Software Implementation

- Mms\_in1 and Mms\_in2 input words must be linked to the first 2 words of the Profibus slave input cyclic data.
- Mms\_out1 output word must be linked to the first word of the Profibus slave output cyclic data.

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	Default Value	Description
Mms_in1	INT	–	0	Must be linked to the first word of the MMS Profibus slave input cyclic data
Mms_in2	INT	–	0	Must be linked to the second word of the MMS Profibus slave input cyclic data
Run_rev	EBOOL	0...1	0	Motor run reverse command
Off_cmd	EBOOL	0...1	0	Off command
Run_fwd	EBOOL	0...1	0	Motor run forward command
Rstflt	EBOOL	0...1	0	Reset fault
Rstwarn	EBOOL	0...1	0	Reset warning
Em_strt	EBOOL	0...1	0	Emergency start (reset thermal memory)
Ther_ov_test	EBOOL	0...1	0	Thermal overload test
Automode_cmd	EBOOL	0...1	0	Auto mode command

## Output Characteristics

The following table describes the DFB outputs:

Output	Type	Range	Default Value	Description
Ms_out1	INT	–	0	Must be linked to the first word of the Profibus slave output cyclic data
Rev_st	EBOOL	0...1	0	Run reverse
Off_st	EBOOL	0...1	0	System Off
Fwd_st	EBOOL	0...1	0	Run forward
Th_ov_st	EBOOL	0...1	0	Thermal overload
Automode_st	EBOOL	0...1	0	Auto mode
Fault	EBOOL	0...1	0	TeSys U on fault
Alarm	EBOOL	0...1	0	TeSys U on alarm
Ready	EBOOL	0...1	0	TeSys U ready to operate
Starting	EBOOL	0...1	0	Motor starting
Running	EBOOL	0...1	0	Motor running
Tripped	EBOOL	0...1	0	Rotary knob on trip position
Avg_curr	INT	0...2000	0	Average motor current (x 0.1% FLA)

---

## Ctrl\_pfb\_t\_mms: TeSys T Control/Command for Profibus DP MMS

### Presentation

The Ctrl\_pfb\_t\_mms derived function block (DFB) is dedicated to the control and command of a single TeSys T LTM R••P•• controller through the Profibus DP MMS (Motor Management Starter) network.


With the MMS profile, the TeSys T LTM R••P•• controller commands are managed on bit rising edges. For more information, see the *TeSys T LTM R Profibus Motor Management Controller User manual*.

### Characteristics

Characteristic	Value
Name	Ctrl_pfb_t_mms
Version	1.00
Input	11
Output	22
Input/Output	0
Public Variable	0



## Graphical Representation



## TeSys T Compliance

The Ctrl\_pfb\_t\_mms DFB is compliant with all the TeSys T LTM R•P•• controller versions, with or without the LTM E expansion module.

## Software Implementation

- Mms\_in1, Mms\_in2 and Mms\_in5 input words must be linked respectively to the first, second, and fifth word of the Profibus slave input cyclic data.
- Mms\_out1 output word must be linked to the first word of the Profibus slave output cyclic data.

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	De- fault Value	Description
Mms_in1	INT	–	0	Must be linked to the first word of the MMS Profibus slave input cyclic data
Mms_in2	INT	–	0	Must be linked to the second word of the MMS Profibus slave input cyclic data
Mms_in5	INT	–	0	Must be linked to the fifth word of the MMS Profibus slave input cyclic data
Run_rev	EBOOL	0...1	0	Motor run reverse command
Off_cmd	EBOOL	0...1	0	Stop command
Run_fwd	EBOOL	0...1	0	Motor run forward command
Rstflt	EBOOL	0...1	0	Fault reset command
Em_strt	EBOOL	0...1	0	Emergency start (reset thermal memory)
Autotest	EBOOL	0...1	0	Self test command
Automode_cmd	EBOOL	0...1	0	Auto mode command
Lo_speed	EBOOL	0...1	0	Motor low speed command

## Output Characteristics

The following table describes the DFB outputs.

Output	Type	Range	Default Value	Description
Ms_out1	INT	–	0	Must be linked to the first word of the Profibus slave output cyclic data
Rev_st	EBOOL	0...1	0	Run reverse
Off_st	EBOOL	0...1	0	System Off
Fwd_st	EBOOL	0...1	0	Run forward
Th_ov_st	EBOOL	0...1	0	Thermal overload
Automode_st	EBOOL	0...1	0	Auto mode
Fault	EBOOL	0...1	0	System fault
Alarm	EBOOL	0...1	0	System warning
Ready	EBOOL	0...1	0	System ready
Starting	EBOOL	0...1	0	Motor starting
Running	EBOOL	0...1	0	Motor running (with detection of a current, if greater than 10% FLC)
Tripped	EBOOL	0...1	0	System tripped
Auto_rst	EBOOL	0...1	0	Auto-reset active
Pwr_rqst	EBOOL	0...1	0	Fault power cycle requested
Rst_time	EBOOL	0...1	0	Motor restart time undefined
Rpd_cycl	EBOOL	0...1	0	Rapid cycle lockout
Load_shd	EBOOL	0...1	0	Voltage load shedding
Hi_speed	EBOOL	0...1	0	Motor high speed
Hmi_loss	EBOOL	0...1	0	HMI port communication loss
Net_loss	EBOOL	0...1	0	Network port communication loss
Motor_tr	EBOOL	0...1	0	Motor transition lockout
Avg_curr	INT	0...2000	0	Average motor current (x 0.1 % FLA)



---

# Cyclic Control/Command DFB

# 5

---

## Introduction

This chapter describes the TeSys U and TeSys T cyclic control/command DFBs.

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Ctrl_cmd_u: TeSys U Cyclic Control/Command	94
Ctrl_cmd_t: TeSys T Cyclic Control/Command	97

## Ctrl\_cmd\_u: TeSys U Cyclic Control/Command

### Presentation


The Ctrl\_cmd\_u derived function block (DFB) is dedicated to the control and command of a single TeSys U starter-controller (up to 32 A/15 kW) through cyclic data exchanges on Modbus® \ TCP (IO scanning), CANopen, and Advantys STB networks.

For more information, see the *LULC032-033 Modbus Communication Module User manual*, the *LULC08 CANopen Communication Module User manual*, and the *LULC15 Advantys STB Communication Module User manual*.

### Characteristics

Characteristic	Value
Name	Ctrl_cmd_u
Version	1.00
Input	7
Output	11
Input/Output	0
Public Variable	0

### Graphical Representation



## TeSys U Compliance

The Ctrl\_cmd\_u DFB is compliant with the following TeSys U sub-assemblies:

<b>Power base</b>	<ul style="list-style-type: none"> <li>● LUB** non-reversing power base (up to 32 A/15 kW)</li> <li>● LU2B** reversing power base (up to 32 A/15 kW)</li> </ul>
<b>Control unit</b>	<ul style="list-style-type: none"> <li>● LUCA standard control unit</li> <li>● LUCB, LUCC, and LUCD advanced control units</li> <li>● LUCL magnetic control unit</li> <li>● LUCM multifunction control unit</li> </ul>
<b>Communication module</b>	<ul style="list-style-type: none"> <li>● LULC08 CANopen communication module</li> <li>● LULC15 Advantys STB communication module</li> <li>● LULC032-033 Modbus communication module with an Ethernet gateway.</li> </ul>

## Input Characteristics

The following table describes the DFB inputs and their availability according to the control unit:

Input	Type	Range	Default Value	Description	LUCALUC	LUCBUCD	LUCM
Reg_455	INT	0...65535	0	To link to register 455 of cyclic data inputs	√	√	√
Run_fwd	EBOOL	0...1	0	Motor run forward command	√	√	√
Run_rev	EBOOL	0...1	0	Motor run reverse command	√	√	√
Rst_ftt	EBOOL	0...1	0	Reset fault (if register 451 = 102 or 104, fault acknowledgment causes a return to communication module factory settings)	√	√	√
Rst_warn	EBOOL	0...1	0	Reset warning (for example, communication loss)	√	√	√
Ther_ov_test	EBOOL	0...1	0	Automatic thermal overload fault test			√
Trip_tst	EBOOL	0...1	0	Overcurrent trip test via communication bus			√

**Output Characteristics**

The following table describes the DFB outputs and their availability according to the control unit:

Output	Type	Range	Default Value	Description	LUCAUCL	LUCEPO	LUCEB
Reg_704	INT	0...65535	0	To link to register 704 of cyclic data outputs	√	√	√
Reg_703	INT	0...65535	0	To link to register 703 of cyclic data outputs	√	√	√
Ready	EBOOL	0...1	0	System ready: the rotary handle is turned to On position and there is no fault	√	√	√
Closed	EBOOL	0...1	0	Pole status: closed	√	√	√
Tripped	EBOOL	0...1	0	System tripped: the rotary handle is turned to Trip position	√	√	√
Fault	EBOOL	0...1	0	All faults	√	√	√
Alarm	EBOOL	0...1	0	All warnings	√	√	√
Rst_auth	EBOOL	0...1	0	Fault reset authorized		√	√
Starting	EBOOL	0...1	0	Start in progress: 0 = descending current is lower than 150% FLA 1 = ascending current is greater than 10% FLA		√	√
Running	EBOOL	0...1	0	Motor running with detection of current, if greater than 10% FLA		√	√
Avg_curr	INT	0...200	0	Average motor current (x 1% FLA)		√	√



## Ctrl\_cmd\_t: TeSys T Cyclic Control/Command

### Presentation


The Ctrl\_cmd\_t derived function block is dedicated to the control and command of a single TeSys T LTM R••C•• CANopen or a TeSys T LTMR••E•• Modbus® \ TCP controller through cyclic data exchanges on Modbus® \ TCP (IO scanning) and CANopen networks.

For more information, see the *TeSys T LTM R Modbus® \ TCP Motor Management Controller User manual* and the *TeSys T LTM R CANopen Motor Management Controller User manual*.

### Characteristics

Characteristic	Value
Name	Ctrl_cmd_t
Version	1.00
Input	7
Output	21
Input/Output	0
Public Variable	0

### Graphical Representation



## TeSys T Compliance

The Ctrl\_cmd\_t DFB is compliant with the TeSys T LTM R••C•• CANopen and with the TeSys T LTM R••E•• Modbus ® \ TCP controller versions, with or without the LTM E expansion module.

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	Default Value	Description
Reg_455	INT	0...65535	0	To link to register 455 of cyclic data inputs
Reg_456	INT	0...65535	0	To link to register 456 of cyclic data inputs
Run_fwd	EBOOL	0...1	0	Motor run forward command
Run_rev	EBOOL	0...1	0	Motor run reverse command
Lo_speed	EBOOL	0...1	0	Motor low speed command
Rst_fit	EBOOL	0...1	0	Fault reset command
Autotest	EBOOL	0...1	0	Self test command

## Output Characteristics

The following table describes the DFB outputs:

Output	Type	Range	Default Value	Description
Reg_704	INT	0...65535	0	To link to register 704 of cyclic data outputs
Ready	EBOOL	0...1	0	System ready
Syst_on	EBOOL	0...1	0	System On
Fault	EBOOL	0...1	0	System fault
Alarm	EBOOL	0...1	0	System warning
Tripped	EBOOL	0...1	0	System tripped
Rst_auth	EBOOL	0...1	0	Fault reset authorized
Ctrl_pwr	EBOOL	0...1	0	Controller power
Running	EBOOL	0...1	0	Motor running (with detection of a current, if greater than 10% FLC)
Hmi_ctrl	EBOOL	0...1	0	Control through HMI
Starting	EBOOL	0...1	0	Motor starting (start in progress) 0 = descending current is less than 150% FLC 1 = ascending current is greater than 10% FLC
Auto_rst	EBOOL	0...1	0	Auto-reset active
Load_shd	EBOOL	0...1	0	Load shedding
Hi_speed	EBOOL	0...1	0	Motor speed 0 = FLC1 setting is used 1 = FLC2 setting is used
Hmi_loss	EBOOL	0...1	0	HMI port communication loss
Net_loss	EBOOL	0...1	0	Network port communication loss
Motor_tr	EBOOL	0...1	0	Motor transition lockout
Avg_curr	INT	0...200	0	Average motor current (x 1% FLA)

---

# PKW Exchanges DFB



---

## Introduction

This chapter describes the TeSys U and TeSys T DFBs for PKW exchanges.

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Special_pkw_u: TeSys U DFB for PKW Exchanges	102
Special_pkw_t: TeSys T DFB for PKW Exchanges	112
Custom_pkw: Custom Read DFB for PKW Exchanges	127

## Special\_pkw\_u: TeSys U DFB for PKW Exchanges

### Presentation

The Special\_pkw\_u derived function block (DFB) is dedicated to the reading of up to 16 predefined registers of a TeSys U starter-controller (up to 32 A/15 kW) with a LUCM multifunction control unit and one of the following communication modules that support PKW (Periodically Kept in Acyclic Words) exchanges:


- LULC07 (Profibus)
- LULC08 (CANopen)
- LULC15 (Advantys STB)

For more information, see the *LULC07 Profibus Communication Module User manual*, the *LULC08 CANopen Communication Module User manual*, and the *LULC15 Advantys STB Communication Module User manual*.

### Characteristics

Characteristic	Value
Name	Special_pkw_u
Version	1.00
Input	7
Output	3
Input/Output	2
Public Variable	2

### Graphical Representation



## TeSys U Compliance

The Special\_pkw\_u DFB is compliant with the following TeSys U sub-assemblies:

<b>Power base</b>	<ul style="list-style-type: none"> <li>● LUB** non-reversing power base (up to 32 A/15 kW)</li> <li>● LU2B** reversing power base (up to 32 A/15 kW)</li> </ul>
<b>Control unit</b>	<ul style="list-style-type: none"> <li>● LUCM multifunction control unit</li> </ul>
<b>Communication module</b>	<ul style="list-style-type: none"> <li>● LULC07 Profibus DP communication module</li> <li>● LULC08 CANopen communication module</li> <li>● LULC15 Advantys STB communication module</li> </ul>
<b>GSD file modules</b>	Profibus: <ul style="list-style-type: none"> <li>● Sc Mu R MS PKW</li> <li>● Sc Mu L MS PKW</li> <li>● Sc Mu R MMS PKW</li> <li>● Sc Mu L MMS PKW</li> </ul>

## Software Implementation

- Pkw\_in1, Pkw\_in2, Pkw\_in3, and Pkw\_in4 input words must be linked to the first 4 words of the PKW slave input cyclic data.
- Pkw\_out1 and Pkw\_out2 input/output words must be linked to the first 2 words of the PKW slave output cyclic data.
- The output data is only valid if the End\_st output variable is set to 1 and if there is no fault state (Fault\_st = 0).
- When using TSXPBY100 Premium Profibus coupler it is mandatory to set %QWxy.0.242:X0 to 1 to guarantee the data consistency.

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	Default Value	Description
Pkw_in1	INT	–	0	Must be linked to the first word of the PKW slave input cyclic data
Pkw_in2	INT	–	0	Must be linked to the second word of the PKW slave input cyclic data
Pkw_in3	INT	–	0	Must be linked to the third word of the PKW slave input cyclic data
Pkw_in4	INT	–	0	Must be linked to the fourth word of the PKW slave input cyclic data
Prog_num	INT	0...6	0	Program number See <i>Program Number, page 104</i>
Rst_cmd	EBOOL	0...1	0	Reset command
Strt_cmd	EBOOL	0...1	0	Start command

### Output Characteristics

The following table describes the DFB outputs:

Output	Type	Range	Default Value	Description
Fault_st	EBOOL	0...1	0	Fault state
Rst_st	EBOOL	0...1	0	Reset state
End_st	EBOOL	0...1	0	End state

### Input/Output Characteristics

The following table describes the DFB input/outputs:

Input/Output	Type	Range	Default Value	Description
Pkw_out1	INT	–	0	Must be linked to the first word of the PKW slave output cyclic data
Pkw_out2	INT	–	0	Must be linked to the second word of the PKW slave output cyclic data

### Program Number

The Prog\_num input variable enables the user to define the public variables data depending on the application type. Each program uses variables related to one application (diagnostic, maintenance, measurement,...). The following table describes the programs of the DFB:

Program Number	Description
0	Bypass: no action
1	Diagnostic: faults monitoring variables, warnings monitoring variables, and communication monitoring variables
2	Maintenance: global statistics variables
3	Measurements: measurements monitoring variables
4	Statistics: last trip statistics and trip N-1 statistics
5	Statistics: N-2 and N-3 trip statistics
6	Statistics: N-4 trip statistics



**Public Variables Characteristics**

The following table describes the DFB public variables:

Public Variable	Type	Range	Default Value	Description
Sq_princ	INT	0...7	0	Reserved for support
Out_data[0]...[15]	AR-RAY[0...15] of INT	0...65535	0	The output data depends on the program number

**Out\_data[0]...[15] Public Variable (Program 1)**

The following table describes the Out\_data[0]...[15] public variable in the case of the diagnostic program (program number 1):

Public Variable	Type	Register	Bit	Description
Out_data[0]	INT	452	0	Short-circuit fault
			1	Magnetic fault
			2	Ground fault
			3	Thermal fault
			4	Long start fault
			5	Jam fault
			6	Phase imbalance fault
			7	Underload fault
			8	Shunt trip fault
			9	Test trip fault
			10	Communication loss fault on LUCM Modbus port
			11	Control unit internal fault
			12	Module identification or internal communication fault
			13	Module internal fault
			14	Module trip fault
			15	Module drop-out fault

Public Variable	Type	Register	Bit	Description
Out_data[1]	INT	461	0...1	Not significant
			2	Ground fault warning
			3	Thermal warning
			4	Long start warning
			5	Jam warning
			6	Phase imbalance warning
			7	Under-current warning
			8...9	Not significant
			10	Communication loss fault on LUCM Modbus port
			11	Internal temperature warning
			12	Module identification or internal communication warning
			13...14	Not significant
			15	Module warning
Out_data[2]	INT	457	0	Button position On (0 = Off)
			1	Button position Trip (0 = Not tripped)
			2	Contactator state On
			3	24 Vdc power supply present on outputs
			4...15	Not significant
Out_data[3]	INT	450	–	Time to automatic reset on a thermal fault (s)
Out_data[4] ...Out_data[15]	–	–	–	Not significant

**Out\_data[0]...[15] Public Variable (Program 2)**

The following table describes the Out\_data[0]...[15] public variable in the case of the maintenance program (program number 2):

Public Variable	Type	Register	Description
Out_data[0]	INT	100	Short-circuit faults count
Out_data[1]	INT	101	Magnetic faults count
Out_data[2]	INT	102	Ground faults count
Out_data[3]	INT	103	Thermal faults count
Out_data[4]	INT	104	Long start faults count
Out_data[5]	INT	105	Jam faults count
Out_data[6]	INT	106	Phase imbalance faults count
Out_data[7]	INT	108	Shunt trip faults count
Out_data[8]	INT	115	Auto-resets count
Out_data[9]	INT	116	Thermal warnings count
Out_data[10]	INT	117	Starts count (LSB)
Out_data[11]	INT	118	Starts count (MSB)
Out_data[12]	INT	119	Operating time (LSB)
Out_data[13]	INT	120	Operating time (MSB)
Out_data[14]	INT	121	Maximum internal temperature (°C)
Out_data[15]	–	–	Not significant

**Out\_data[0]...[15] Public Variable (Program 3)**

The following table describes the Out\_data[0]...[15] public variable in the case of the measurements program (program number 3):

Public Variable	Type	Register	Description
Out_data[0]	–	–	Not significant
Out_data[1]	INT	465	Thermal capacity level (%)
Out_data[2]	INT	466	Average motor current (x 0.1 % FLA)
Out_data[3]	INT	467	L1 current (% FLA)
Out_data[4]	INT	468	L2 current (% FLA)
Out_data[5]	INT	469	L3 current (% FLA)
Out_data[6]	INT	470	Ground current (% FLA min)
Out_data[7]	INT	471	Current imbalance coefficient
Out_data[8]	INT	472	Control unit internal temperature (°C)
Out_data[9] ...Out_data[13]	–	–	Not significant
Out_data[14]	INT	79	Control unit sensor maximum current (x 0.1 A): <ul style="list-style-type: none"> <li>● 6 = adjustment range 0.15 to 0.6 A</li> <li>● 14 = adjustment range 0.35 to 1.4 A</li> <li>● 50 = adjustment range 1.25 to 5 A</li> <li>● 120 = adjustment range 3 to 12 A</li> <li>● 180 = adjustment range 4.5 to 18 A</li> <li>● 320 = adjustment range 8 to 32 A</li> </ul>
Out_data[15]	INT	652	Full load amps setting (% FLA max): <ul style="list-style-type: none"> <li>● minimum = 25 (default value)</li> <li>● maximum = 100</li> </ul>

**Out\_data[0]...[15] Public Variable (Program 4)**

The following table describes the Out\_data[0]...[15] public variable in the case of the statistics program (program number 4):

Public Variable	Type	Register	Description
Out_data[0]	INT	150	Last trip fault number
Out_data[1]	INT	152	Last trip thermal capacity level (% trip level)
Out_data[2]	INT	153	Last trip average current (% FLA)
Out_data[3]	INT	154	Last trip L1 current (% FLA)
Out_data[4]	INT	155	Last trip L2 current (% FLA)
Out_data[5]	INT	156	Last trip L3 current (% FLA)
Out_data[6]	INT	157	Last trip ground current (% FLA min)
Out_data[7]	INT	180	N-1 trip fault number
Out_data[8]	INT	182	N-1 trip thermal capacity level (% trip level)
Out_data[9]	INT	183	N-1 trip average current (% FLA)
Out_data[10]	INT	184	N-1 trip L1 current (% FLA)
Out_data[11]	INT	185	N-1 trip L2 current (%FLA)
Out_data[12]	INT	186	N-1 trip L3 current (% FLA)
Out_data[13]	INT	187	N-1 trip ground current (% FLA min)
Out_data[14]	INT	79	Control unit sensor maximum current (x 0.1 A): <ul style="list-style-type: none"> <li>● 6 = adjustment range 0.15 to 0.6 A</li> <li>● 14 = adjustment range 0.35 to 1.4 A</li> <li>● 50 = adjustment range 1.25 to 5 A</li> <li>● 120 = adjustment range 3 to 12 A</li> <li>● 180 = adjustment range 4.5 to 18 A</li> <li>● 320 = adjustment range 8 to 32 A</li> </ul>
Out_data[15]	INT	652	Full load amps setting (% FLA max): <ul style="list-style-type: none"> <li>● minimum = 25 (default value)</li> <li>● maximum = 100</li> </ul>

**Out\_data[0]...[15] Public Variable (Program 5)**

The following table describes the Out\_data[0]...[15] public variable in the case of the statistics program (program number 5):

Public Variable	Type	Register	Description
Out_data[0]	INT	210	N-2 trip fault number
Out_data[1]	INT	212	N-2 trip thermal capacity level (% trip level)
Out_data[2]	INT	213	N-2 trip average current (% FLA)
Out_data[3]	INT	214	N-2 trip L1 current (% FLA)
Out_data[4]	INT	215	N-2 trip L2 current (% FLA)
Out_data[5]	INT	216	N-2 trip L3 current (% FLA)
Out_data[6]	INT	217	N-2 trip ground current (% FLA min)
Out_data[7]	INT	240	N-3 trip fault number
Out_data[8]	INT	242	N-3 trip thermal capacity level (% trip level)
Out_data[9]	INT	243	N-3 trip average current (% FLA)
Out_data[10]	INT	244	N-3 trip L1 current (% FLA)
Out_data[11]	INT	245	N-3 trip L2 current (%FLA)
Out_data[12]	INT	246	N-3 trip L3 current (% FLA)
Out_data[13]	INT	247	N-3 trip ground current (% FLA min)
Out_data[14]	INT	79	Control unit sensor maximum current (x 0.1 A): <ul style="list-style-type: none"> <li>● 6 = adjustment range 0.15 to 0.6 A</li> <li>● 14 = adjustment range 0.35 to 1.4 A</li> <li>● 50 = adjustment range 1.25 to 5 A</li> <li>● 120 = adjustment range 3 to 12 A</li> <li>● 180 = adjustment range 4.5 to 18 A</li> <li>● 320 = adjustment range 8 to 32 A</li> </ul>
Out_data[15]	INT	652	Full load amps setting (% FLA max): <ul style="list-style-type: none"> <li>● minimum = 25 (default value)</li> <li>● maximum = 100</li> </ul>

**Out\_data[0]...[15] Public Variable (Program 6)**

The following table describes the Out\_data[0]...[15] public variable in the case of the statistics program (program number 6):

Public Variable	Type	Register	Description
Out_data[0]	INT	270	N-4 trip fault number
Out_data[1]	INT	272	N-4 trip thermal capacity level (% trip level)
Out_data[2]	INT	273	N-4 trip average current (% FLA)
Out_data[3]	INT	274	N-4 trip L1 current (% FLA)
Out_data[4]	INT	275	N-4 trip L2 current (% FLA)
Out_data[5]	INT	276	N-4 trip L3 current (% FLA)
Out_data[6]	INT	277	N-4 trip ground current (% FLA min)
Out_data[7] ...Out_data[13]	–	–	Reserved
Out_data[14]	INT	79	Control unit sensor maximum current (x 0.1 A): <ul style="list-style-type: none"> <li>● 6 = adjustment range 0.15 to 0.6 A</li> <li>● 14 = adjustment range 0.35 to 1.4 A</li> <li>● 50 = adjustment range 1.25 to 5 A</li> <li>● 120 = adjustment range 3 to 12 A</li> <li>● 180 = adjustment range 4.5 to 18 A</li> <li>● 320 = adjustment range 8 to 32 A</li> </ul>
Out_data[15]	INT	652	Full load amps setting (% FLA max): <ul style="list-style-type: none"> <li>● minimum = 25 (default value)</li> <li>● maximum = 100</li> </ul>

## Special\_pkw\_t: TeSys T DFB for PKW Exchanges


### Presentation

The Special\_pkw\_t derived function block (DFB) is dedicated to the reading of up to 16 predefined registers of a single TeSys T LTM R••P•• Profibus controller through the Profibus (MS and MMS) network, and a TeSys T LTM R••C•• CANopen controller through the CANopen network, and supporting PKW (Periodically Kept in Acyclic Words) exchanges.

### Characteristics

Characteristic	Value
Name	Special_pkw_t
Version	1.00
Input	7
Output	3
Input/Output	2
Public Variable	2

### Graphical Representation



### TeSys T Compliance

The Special\_pkw\_t DFB is compliant with all the TeSys T LTM R••P•• controller versions, with or without the LTM E expansion module.



## Software Implementation

- Pkw\_in1, Pkw\_in2, Pkw\_in3, and Pkw\_in4 input words must be linked to the first 4 words of the PKW slave input cyclic data.
- Pkw\_out1 and Pkw\_out2 input/output words must be linked to the first 2 words of the PKW slave output cyclic data.
- The output data is only valid if the End\_st output variable is set to 1 and if there is no fault state (Fault\_st = 0).
- When using TSXPBY100 Premium Profibus coupler it is mandatory to set %QWxy.0.242:X0 to 1 to guarantee the data consistency.

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	Default Value	Description
Pkw_in1	INT	–	0	Must be linked to the first word of the PKW slave input cyclic data
Pkw_in2	INT	–	0	Must be linked to the second word of the PKW slave input cyclic data
Pkw_in3	INT	–	0	Must be linked to the third word of the PKW slave input cyclic data
Pkw_in4	INT	–	0	Must be linked to the fourth word of the PKW slave input cyclic data
Prog_num	INT	0..81	0	Program number See <i>Program Number, page 114</i>
Rst_cmd	EBOOL	0..1	0	Reset command
Strt_cmd	EBOOL	0..1	0	Start command

## Output Characteristics

The following table describes the DFB outputs:

Output	Type	Range	Default Value	Description
Fault_st	EBOOL	0..1	0	Fault state
Rst_st	EBOOL	0..1	0	Reset state
End_st	EBOOL	0..1	0	End state

### Input/Output Characteristics

The following table describes the DFB input/outputs:

Input/Output	Type	Range	De- fault Value	Description
Pkw_out1	INT	–	0	Must be linked to the first word of the PKW slave output cyclic data
Pkw_out2	INT	–	0	Must be linked to the second word of the PKW slave output cyclic data

### Program Number

The Prog\_num input variable enables the user to define the public variables data depending on the application type. Each program holds variables related to one application (diagnostic, maintenance, measurement,...). The following table describes the programs of the DFB:

Program Number	Description
0	Bypass: no action
10	Diagnostic: faults monitoring variables, warnings monitoring variables, and communication monitoring variables
20	Maintenance: global statistics variables
30	Measurements 1
31	Measurements 2
32	Measurements 3
40	Statistics: last fault statistics (N-0)
41	Statistics: last fault statistics (with expansion module) (N-0)
50	Statistics: N-1 fault statistics
51	Statistics: N-1 fault statistics (with expansion module)
60	Statistics: N-2 fault statistics
61	Statistics: N-2 fault statistics (with expansion module)
70	Statistics: N-3 fault statistics
71	Statistics: N-3 fault statistics (with expansion module)
80	Statistics: N-4 fault statistics
81	Statistics: N-4 fault statistics (with expansion module)

## Public Variables Characteristics

The following table describes the DFB public variables:

Public Variable	Type	Range	Default Value	Description
Sq_princ	INT	0...7	0	Reserved for support
Out_data[0]...[15]	AR-RAY[0...15] of INT	0...65535	0	The output data depends on the program number

### Out\_data[0]...[15] Public Variable (Program 10)

The following table describes the Out\_data[0]...[15] public variable in the case of the diagnostic program (program number 10):

Public Variable	Type	Register	Bit	Description
Out_data[0]	INT	452	0...1	Reserved
			2	Ground current fault
			3	Thermal overload fault
			4	Long start fault
			5	Jam fault
			6	Current phase imbalance fault
			7	Undercurrent fault
			8	Reserved
			9	Test fault
			10	HMI port fault
			11	Controller internal fault
			12	Internal port fault
			13	Not significant
			14	Network port config fault
			15	Network port fault

Public Variable	Type	Register	Bit	Description
Out_data[1]	INT	453	0	External system fault
			1	Diagnostic fault
			2	Wiring fault
			3	Overcurrent fault
			4	Current phase loss fault
			5	Current phase reversal fault
			6	Motor temperature sensor fault (1)
			7	Voltage phase imbalance fault (1)
			8	Voltage phase loss fault (1)
			9	Voltage phase reversal fault (1)
			10	Undervoltage fault (1)
			11	Overvoltage fault (1)
			12	Underpower fault (1)
			13	Overpower fault (1)
			14	Under power factor fault (1)
15	Over power factor fault (1)			
(1) The variable is available for the LTM R controller and the LTM EV40 expansion module combination.				
Out_data[2]	INT	461	0...1	Not significant
			2	Ground current warning
			3	Thermal overload warning
			4	Not significant
			5	Jam warning
			6	Current phase imbalance warning
			7	Undercurrent warning
			8...9	Not significant
			10	HMI port warning
			11	Controller internal temperature warning
			12...14	Not significant
15	Network port warning			

Public Variable	Type	Register	Bit	Description
Out_data[3]	INT	462	0	Not significant
			1	Diagnostic warning
			2	Reserved
			3	Overcurrent warning
			4	Current phase loss warning
			5	Current phase reversal warning
			6	Motor temperature sensor warning
			7	Voltage phase imbalance warning (1)
			8	Voltage phase loss warning (1)
			9	Not significant
			10	Undervoltage warning (1)
			11	Overvoltage warning (1)
			12	Underpower warning (1)
			13	Overpower warning (1)
			14	Under power factor warning (1)
			15	Over power factor warning (1)
(1) The variable is available for the LTM R controller and the LTM EV40 expansion module combination.				
Out_data[4]	INT	457	0	Logic input 1
			1	Logic input 2
			2	Logic input 3
			3	Logic input 4
			4	Logic input 5
			5	Logic input 6
			6	Logic input 7
			7	Logic input 8 (1)
			8	Logic input 9 (1)
			9	Logic input 10 (1)
			10	Logic input 11 (1)
			11	Logic input 12 (1)
			12	Logic input 13 (1)
			13	Logic input 14 (1)
			14	Logic input 15 (1)
			15	Logic input 16 (1)

Public Variable	Type	Register	Bit	Description
Out_data[5]	INT	458	0	Logic output 1
			1	Logic output 2
			2	Logic output 3
			3	Logic output 4
			4	Logic output 5 (1)
			5	Logic output 6 (1)
			6	Logic output 7 (1)
			7	Logic output 8 (1)
			8...15	Reserved
Out_data[6]	INT	450	–	Minimum wait time (s)
Out_data[7] ...Out_data[15]	–	–	–	Reserved
(1) The variable is available for the LTM R controller and the LTM EV40 expansion module combination.				

**Out\_data[0]...[15] Public Variable (Program 20)**

The following table describes the Out\_data[0]...[15] public variable in the case of the maintenance program (program number 20):

Public Variable	Type	Register	Description
Out_data[0]	INT	102	Ground current faults count
Out_data[1]	INT	103	Thermal overload faults count
Out_data[2]	INT	104	Long start faults count
Out_data[3]	INT	105	Jam faults count
Out_data[4]	INT	106	Current phase imbalance faults count
Out_data[5]	INT	107	Undercurrent faults count
Out_data[6]	–	–	Reserved
Out_data[7]	INT	114	Network port faults count
Out_data[8]	INT	115	Auto-resets count
Out_data[9]	INT	116	Thermal overload warnings count
Out_data[10]	INT	117	Motor starts count (LSB)
Out_data[11]	INT	118	Motor starts count (MSB)
Out_data[12]	INT	119	Operating time (s) (LSB)
Out_data[13]	INT	120	Operating time (MSB)
Out_data[14]	INT	121	Maximum controller internal temperature (°C)
Out_data[15]	–	–	Reserved

**Out\_data[0]...[15] Public Variable (Program 30)**

The following table describes the Out\_data[0]...[15] public variable in the case of the first measurements program (program number 30):

Public Variable	Type	Register	Description
Out_data[0]	–	–	Reserved
Out_data[1]	INT	465	Thermal capacity level (% trip level)
Out_data[2]	INT	466	Average current ratio (% FLC)
Out_data[3]	INT	467	L1 current ratio (% FLC)
Out_data[4]	INT	468	L2 current ratio (% FLC)
Out_data[5]	INT	469	L3 current ratio (% FLC)
Out_data[6]	INT	470	Ground current ratio (x 0.1 % FLC min)
Out_data[7]	INT	471	Current phase imbalance (%)
Out_data[8]	INT	472	Controller internal temperature (°C)
Out_data[9]	INT	474	Frequency (x 0.01 Hz)
Out_data[10]	INT	475	Motor temperature sensor (x 0.1 Ω)
Out_data[11] ...Out_data[13]	–	–	Reserved
Out_data[14]	INT	96	Full load current (FLC) max (x 0.1 A)
Out_data[15]	INT	652	Motor full load current (FLC) ratio

**Out\_data[0]...[15] Public Variable (Program 31)**

The following table describes the Out\_data[0]...[15] public variable in the case of the second measurements program (program number 31):

Public Variable	Type	Register	Description
Out_data[0]	INT	500	Average current (x 0.01 A) MSB
Out_data[1]	INT	501	Average current (x 0.01 A) LSB
Out_data[2]	INT	502	L1 current (x 0.01 A) MSB
Out_data[3]	INT	503	L1 current (x0.01 A) LSB
Out_data[4]	INT	504	L2 current (x 0.01 A) MSB
Out_data[5]	INT	505	L2 current (x0.01 A) LSB
Out_data[6]	INT	506	L3 current (x 0.01 A) MSB
Out_data[7]	INT	507	L3 current (x0.01 A) LSB
Out_data[8]	INT	508	Ground current (x 0.001 A) MSB
Out_data[9]	INT	509	Ground current (x 0.001 A) LSB
Out_data[10]	INT	511	Time to trip (x 1 s)
Out_data[11]	INT	512	Motor last start current ratio (% FLC)
Out_data[12]	INT	513	Motor last start duration (s)
Out_data[13]	INT	514	Motor starts per hour count
Out_data[14] ...Out_data[15]	–	–	–

**Out\_data[0]...[15] Public Variable (Program 32)**

The following table describes the Out\_data[0]...[15] public variable in the case of the third measurements program (program number 32):

Public Variable	Type	Register	Description
Out_data[0]	INT	476	Average voltage (V)
Out_data[1]	INT	477	L3-L1 voltage (V)
Out_data[2]	INT	478	L1-L2 voltage (V)
Out_data[3]	INT	479	L2-L3 voltage (V)
Out_data[4]	INT	480	Voltage phase imbalance (%)
Out_data[5]	INT	481	Power factor (x 0.01)
Out_data[6]	INT	482	Active power (x 0.1 kW)
Out_data[7]	INT	483	Reactive power (x 0.1 kVAr)
Out_data[8] ...Out_data[15]	–	–	Reserved



**Out\_data[0]...[15] Public Variable (Program 40)**

The following table describes the Out\_data[0]...[15] public variable in the case of the last fault statistics program (program number 40):

Public Variable	Type	Register	Description
Out_data[0]	INT	150	Fault code N-0
Out_data[1]	INT	151	Motor full load current ratio N-0 (% FLC max)
Out_data[2]	INT	152	Thermal capacity level N-0 (% trip level)
Out_data[3]	INT	153	Average current ratio N-0 (% FLC)
Out_data[4]	INT	154	L1 current ratio N-0 (% FLC)
Out_data[5]	INT	155	L2 current ratio N-0 (% FLC)
Out_data[6]	INT	156	L3 current ratio N-0 (% FLC)
Out_data[7]	INT	157	Ground current ratio N-0 (x 0.1 % FLC min)
Out_data[8]	INT	158	Full load current max N-0 (x 0.1 A)
Out_data[9]	INT	159	Current phase imbalance N-0 (%)
Out_data[10]	INT	160	Frequency N-0 (x 0.1 Hz)
Out_data[11]	INT	161	Motor temperature sensor N-0 (x 0.1 $\Omega$ )
Out_data[12]	WORD[4]	162	Date and time N-0
Out_data[13]		163	See <i>DT_DateTime</i> , page 126
Out_data[14]		164	
Out_data[15]		165	

**Out\_data[0]...[15] Public Variable (Program 41)**

The following table describes the Out\_data[0]...[15] public variable in the case of the last fault statistics with expansion module program (program number 41):

Public Variable	Type	Register	Description
Out_data[0]	INT	166	Average voltage N-0 (V)
Out_data[1]	INT	167	L3-L1 voltage N-0 (V)
Out_data[2]	INT	168	L1-L2 voltage N-0 (V)
Out_data[3]	INT	169	L2-L3 voltage N-0 (V)
Out_data[4]	INT	170	Voltage phase imbalance N-0 (%)
Out_data[5]	INT	171	Active power N-0 (kW)
Out_data[6]	INT	172	Power factor N-0 (x 0.01)
Out_data[7] ...Out_data[15]	–	–	Reserved

**Out\_data[0]...[15] Public Variable (Program 50)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-1 fault statistics program (program number 50):

Public Variable	Type	Register	Description
Out_data[0]	INT	180	Fault code N-1
Out_data[1]	INT	181	Motor full load current ratio N-1 (% FLC max)
Out_data[2]	INT	182	Thermal capacity level N-1 (% trip level)
Out_data[3]	INT	183	Average current ratio N-1 (% FLC)
Out_data[4]	INT	184	L1 current ratio N-1 (% FLC)
Out_data[5]	INT	185	L2 current ratio N-1 (% FLC)
Out_data[6]	INT	186	L3 current ratio N-1 (% FLC)
Out_data[7]	INT	187	Ground current ratio N-1 (x 0.1 % FLC min)
Out_data[8]	INT	188	Full load current max N-1 (x 0.1 A)
Out_data[9]	INT	189	Current phase imbalance N-1 (%)
Out_data[10]	INT	190	Frequency N-1 (x 0.1 Hz)
Out_data[11]	INT	191	Motor temperature sensor N-1 (x 0.1 Ω)
Out_data[12]	WORD[4]	192	Date and time N-1
Out_data[13]		193	See <i>DT_DateTime</i> , page 126
Out_data[14]		194	
Out_data[15]		195	

**Out\_data[0]...[15] Public Variable (Program 51)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-1 fault statistics with expansion module program (program number 51):

Public Variable	Type	Register	Description
Out_data[0]	INT	196	Average voltage N-1 (V)
Out_data[1]	INT	197	L3-L1 voltage N-1 (V)
Out_data[2]	INT	198	L1-L2 voltage N-1 (V)
Out_data[3]	INT	199	L2-L3 voltage N-1 (V)
Out_data[4]	INT	200	Voltage phase imbalance N-1 (%)
Out_data[5]	INT	201	Active power N-1 (kW)
Out_data[6]	INT	202	Power factor N-1 (x 0.01)
Out_data[7] ...Out_data[15]	-	-	Reserved

**Out\_data[0]...[15] Public Variable (Program 60)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-2 fault statistics program (program number 60):

Public Variable	Type	Register	Description
Out_data[0]	INT	210	Fault code N-2
Out_data[1]	INT	211	Motor full load current ratio N-2 (% FLC max)
Out_data[2]	INT	212	Thermal capacity level N-2 (% trip level)
Out_data[3]	INT	213	Average current ratio N-2 (% FLC)
Out_data[4]	INT	214	L1 current ratio N-2 (% FLC)
Out_data[5]	INT	215	L2 current ratio N-2 (% FLC)
Out_data[6]	INT	216	L3 current ratio N-2 (% FLC)
Out_data[7]	INT	217	Ground current ratio N-2 (x 0.1 % FLC min)
Out_data[8]	INT	218	Full load current max N-2 (x 0.1 A)
Out_data[9]	INT	219	Current phase imbalance N-2 (%)
Out_data[10]	INT	220	Frequency N-2 (x 0.1 Hz)
Out_data[11]	INT	221	Motor temperature sensor N-2 (x 0.1 $\Omega$ )
Out_data[12]	WORD[4]	222	Date and time N-2
Out_data[13]		223	See <i>DT_DateTime</i> , page 126
Out_data[14]		224	
Out_data[15]		225	

**Out\_data[0]...[15] Public Variable (Program 61)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-2 fault statistics with expansion module program (program number 61):

Public Variable	Type	Register	Description
Out_data[0]	INT	226	Average voltage N-2 (V)
Out_data[1]	INT	227	L3-L1 voltage N-2 (V)
Out_data[2]	INT	228	L1-L2 voltage N-2 (V)
Out_data[3]	INT	229	L2-L3 voltage N-2 (V)
Out_data[4]	INT	230	Voltage phase imbalance N-2 (%)
Out_data[5]	INT	231	Active power N-2 (kW)
Out_data[6]	INT	232	Power factor N-2 (x 0.01)
Out_data[7] ...Out_data[15]	–	–	Reserved

**Out\_data[0]...[15] Public Variable (Program 70)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-3 fault statistics program (program number 70):

Public Variable	Type	Register	Description
Out_data[0]	INT	240	Fault code N-3
Out_data[1]	INT	241	Motor full load current ratio N-3 (% FLC max)
Out_data[2]	INT	242	Thermal capacity level N-3 (% trip level)
Out_data[3]	INT	243	Average current ratio N-3 (% FLC)
Out_data[4]	INT	244	L1 current ratio N-3 (% FLC)
Out_data[5]	INT	245	L2 current ratio N-3 (% FLC)
Out_data[6]	INT	246	L3 current ratio N-3 (% FLC)
Out_data[7]	INT	247	Ground current ratio N-3 (x 0.1 % FLC min)
Out_data[8]	INT	248	Full load current max N-3 (x 0.1 A)
Out_data[9]	INT	249	Current phase imbalance N-3 (%)
Out_data[10]	INT	250	Frequency N-3 (x 0.1 Hz)
Out_data[11]	INT	251	Motor temperature sensor N-3 (x 0.1 $\Omega$ )
Out_data[12]	WORD[4]	252	Date and time N-3
Out_data[13]		253	See <i>DT_DateTime</i> , page 126
Out_data[14]		254	
Out_data[15]		255	

**Out\_data[0]...[15] Public Variable (Program 71)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-3 fault statistics with expansion module program (program number 71):

Public Variable	Type	Register	Description
Out_data[0]	INT	256	Average voltage N-3 (V)
Out_data[1]	INT	257	L3-L1 voltage N-3 (V)
Out_data[2]	INT	258	L1-L2 voltage N-3 (V)
Out_data[3]	INT	259	L2-L3 voltage N-3 (V)
Out_data[4]	INT	260	Voltage phase imbalance N-3 (%)
Out_data[5]	INT	261	Active power N-3 (kW)
Out_data[6]	INT	262	Power factor N-3 (x 0.01)
Out_data[7] ...Out_data[15]	–	–	Reserved

**Out\_data[0]...[15] Public Variable (Program 80)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-4 fault statistics program (program number 80):

Public Variable	Type	Register	Description
Out_data[0]	INT	270	Fault code N-4
Out_data[1]	INT	271	Motor full load current ratio N-4 (% FLC max)
Out_data[2]	INT	272	Thermal capacity level N-4 (% trip level)
Out_data[3]	INT	273	Average current ratio N-4 (% FLC)
Out_data[4]	INT	274	L1 current ratio N-4 (% FLC)
Out_data[5]	INT	275	L2 current ratio N-4 (% FLC)
Out_data[6]	INT	276	L3 current ratio N-4 (% FLC)
Out_data[7]	INT	277	Ground current ratio N-4 (x 0.1 % FLC min)
Out_data[8]	INT	278	Full load current max N-4 (x 0.1 A)
Out_data[9]	INT	279	Current phase imbalance N-4 (%)
Out_data[10]	INT	280	Frequency N-4 (x 0.1 Hz)
Out_data[11]	INT	281	Motor temperature sensor N-4 (x 0.1 $\Omega$ )
Out_data[12]	WORD[4]	282	Date and time N-4
Out_data[13]		283	See <i>DT_DateTime</i> , page 126
Out_data[14]		284	
Out_data[15]		285	

**Out\_data[0]...[15] Public Variable (Program 81)**

The following table describes the Out\_data[0]...[15] public variable in the case of the N-4 fault statistics with expansion module program (program number 81):

Public Variable	Type	Register	Description
Out_data[0]	INT	286	Average voltage N-4 (V)
Out_data[1]	INT	287	L3-L1 voltage N-4 (V)
Out_data[2]	INT	288	L1-L2 voltage N-4 (V)
Out_data[3]	INT	289	L2-L3 voltage N-4 (V)
Out_data[4]	INT	290	Voltage phase imbalance N-4 (%)
Out_data[5]	INT	291	Active power N-4 (kW)
Out_data[6]	INT	292	Power factor N-4 (x 0.01)
Out_data[7] ...Out_data[15]	–	–	Reserved

**DT\_DateTime**

DT\_DateTime is WORD[4] type and indicates date and time:

Register	Bits 15...12	Bits 11...8	Bits 7...4	Bits 3...0
Register N	s	s	0	0
Register N+1	H	H	m	m
Register N+2	M	M	D	D
Register N+3	Y	Y	Y	Y

Where:

- 0 = unused
- s = second  
The format is 2 binary coded decimal (BCD) digits.  
The value range is 00...59 in BCD.
- m = minute  
The format is 2 binary coded decimal (BCD) digits.  
The value range is 00...59 in BCD.
- H = hour  
The format is 2 binary coded decimal (BCD) digits.  
The value range is 00...23 in BCD.
- D = day  
The format is 2 binary coded decimal (BCD) digits.  
The value range is (in BCD):
  - 01...31 for months 01, 03, 05, 07, 08, 10, 12,
  - 01...30 for months 04, 06, 09, 11,
  - 01...29 for month 02 in a leap year,
  - 01...28 for month 02 in a non-leap year.
- M = month  
The format is 2 binary coded decimal (BCD) digits.  
The value range is 01...12 in BCD.
- Y = year  
The format is 4 binary coded decimal (BCD) digits.  
The value range is 2006...2099 in BCD.

Data entry format and value range are:

Data entry format	DT#YYYY-MM-DD-HH:mm:ss	
Minimum value	DT#2006-01-01-00:00:00	January 1, 2006
Maximum value	DT#2099-12-31-23:59:59	December 31, 2099

**NOTE:** If the user enters values outside the defined range, the system will return an error.

## Custom\_pkw: Custom Read DFB for PKW Exchanges

### Presentation

The Custom\_pkw derived function block (DFB) is dedicated to the reading of up to 5 sets of registers of a single TeSys device supporting PKW (Periodically Kept in Acyclic Words) exchanges.


A set of registers is defined by the address of the first register to read and the length of the set (up to 16 registers per set).

The Custom\_pkw DFB completes the Special\_pkw\_u and Special\_pkw\_t DFBs and enables the user to select the registers to read.

### Characteristics

Characteristic	Value
Name	Custom_pkw
Version	1.00
Input	6
Output	3
Input/Output	2
Public Variable	7

### Graphical Representation



## TeSys U and TeSys T Compliance

- TeSys U: The Custom\_pkw DFB is compliant with the following TeSys U sub-assemblies:
  - LUB•• non-reversing power base and LU2B•• reversing power base (up to 32 A/15 kW)
  - LUCM multifunction control unit
  - PKW compliant communication module
- TeSys T: The Custom\_pkw DFB is compliant with all the LTM R controller versions, with or without the LTM E expansion module.
- When using TSXPBY100 Premium Profibus coupler it is mandatory to set %QWxy.0.242:X0 to 1 to guarantee the data consistency.

## Software Implementation

- Pkw\_in1, Pkw\_in2, Pkw\_in3 and Pkw\_in4 input words must be linked to the first 4 words of the PKW slave input cyclic data.
- Pkw\_out1 and Pkw\_out2 output words must be linked to the first word of the first 2 words of the PKW slave output cyclic data.
- The output data is only valid if the End\_st output variable is set to 1 and if there is no fault state (Fault\_st = 0).
- The public variables enable the user to read up to 5 sets of registers of a maximum length of 16 registers for each set:
  - The user defines the starting point of a set of registers with the In\_reg public variable.
  - The user defines the length of the set of registers with the corresponding In\_len public variable.
  - The registers content is then returned in the corresponding Out\_dat public variable.



**Example with TeSys T**

The user wants to read 3 sets of TeSys T registers:

- Global statistics: registers 102...106 (5 registers)
- Measurements: registers 465...470 (6 registers)
- Controller identification: registers 64...74 (11 registers)

The following table describes the values of the corresponding In\_reg and In\_len public variables:

<b>Public variable</b>	<b>Value</b>
In_reg[0]	102
In_reg[1]	465
In_reg[2]	64
In_len[0]	5
In_len[1]	6
In_len[2]	11

The following table describes the values of the corresponding Out\_dat public variables:

Public Variable		Register	Description
Out_dat0	Out_dat0[0]	102	Ground current faults count
	Out_dat0[1]	103	Thermal overload faults count
	Out_dat0[2]	104	Long start faults count
	Out_dat0[3]	105	Jam faults count
	Out_dat0[4]	106	Current phase imbalance faults count
Out_dat1	Out_dat1[0]	465	Thermal capacity level (% trip level)
	Out_dat1[1]	466	Average current ratio (% FLC)
	Out_dat1[2]	467	L1 current ratio (% FLC)
	Out_dat1[3]	468	L2 current ratio (% FLC)
	Out_dat1[4]	469	L3 current ratio (% FLC)
	Out_dat1[5]	470	Ground current ratio (x 0.1 % FLC min)
Out_dat2	Out_dat2[0]	64	Controller commercial reference MSB = ASCII char 1, LSB = ASCII char 2
	Out_dat2[1]	65	Controller commercial reference MSB = ASCII char 3, LSB = ASCII char 4
	Out_dat2[2]	66	Controller commercial reference MSB = ASCII char 5, LSB = ASCII char 6
	Out_dat2[3]	67	Controller commercial reference MSB = ASCII char 7, LSB = ASCII char 8
	Out_dat2[4]	68	Controller commercial reference MSB = ASCII char 9, LSB = ASCII char 10
	Out_dat2[5]	69	Controller commercial reference MSB = ASCII char 11, LSB = ASCII char 12
	Out_dat2[6]	70	Controller serial number, register 1
	Out_dat2[7]	71	Controller serial number, register 2
	Out_dat2[8]	72	Controller serial number, register 3
	Out_dat2[9]	73	Controller serial number, register 4
	Out_dat2[10]	74	Controller serial number, register 5

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Range	Default Value	Description
Pkw_in1	INT	–	0	Must be linked to the first word of the PKW slave input cyclic data
Pkw_in2	INT	–	0	Must be linked to the second word of the PKW slave input cyclic data
Pkw_in3	INT	–	0	Must be linked to the third word of the PKW slave input cyclic data
Pkw_in4	INT	–	0	Must be linked to the fourth word of the PKW slave input cyclic data
Rst_cmd	EBOOL	0...1	0	Reset command
Strt_cmd	EBOOL	0...1	0	Start command

## Output Characteristics

The following table describes the DFB outputs:

Output	Type	Range	Default Value	Description
Fault_st	EBOOL	0...1	0	Fault state
Rst_st	EBOOL	0...1	0	Reset state
End_st	EBOOL	0...1	0	End state

## Input/Output Characteristics

The following table describes the DFB input/outputs:

Input/Output	Type	Range	Default Value	Description
Pkw_out1	INT	–	0	Must be linked to the first word of the PKW slave output cyclic data
Pkw_out2	INT	–	0	Must be linked to the second word of the PKW slave output cyclic data

**Public Variables Characteristics**

The following table describes the DFB public variables:

<b>Public Variable</b>	<b>Type</b>	<b>Description</b>
In_reg	ARRAY [0...4] of INT	Array of 5 words for the 5 index registers (In_reg(0)...In_reg(4))
In_len	ARRAY [0...4] of INT	Array of 5 words for the length of each set of registers (In_len[0]...In_len[4])
Out_dat[0]	ARRAY [0...15] of INT	Array of up to 16 words containing the In_len[0] words starting from In_reg[0]
Out_dat[1]	ARRAY [0...15] of INT	Array of up to 16 words containing the In_len[1] words starting from In_reg[1]
Out_dat[2]	ARRAY [0...15] of INT	Array of up to 16 words containing the In_len[2] words starting from In_reg[2]
Out_dat[3]	ARRAY [0...15] of INT	Array of up to 16 words containing the In_len[3] words starting from In_reg[3]
Out_dat[4]	ARRAY [0...15] of INT	Array of up to 16 words containing the In_len[4] words starting from In_reg[4]

---

# Treatment DFB



---

## Introduction

This chapter describes the Scale and Timestamp treatment DFBs.

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Scale: TeSys U DFB for Measurement Unit Conversion	134
Timestamp: TeSys U DFB for Data Time-Stamping	138

## Scale: TeSys U DFB for Measurement Unit Conversion

### Presentation


The Scale derived function block (DFB) is dedicated to the conversion of current measurement unit from relative value (% FLC) to Amps for a TeSys U starter-controller (up to 32 A/15 kW) with a multifunction control unit. It also enables the user to select another unit in the A...mA range.

The Scale DFB is particularly used with the Special\_pkw\_u or the Special\_mdb\_u\_\*\*\* DFBs.

### Characteristics

Characteristic	Value
Name	Scale
Version	1.00
Input	1
Output	1
Input/Output	0
Public Variable	22

### Graphical Representation



### TeSys U Compliance

The Scale DFB is compliant with the following TeSys U sub-assemblies:

<b>Power base</b>	<ul style="list-style-type: none"> <li>● LUB** non-reversing power base (up to 32 A/15 kW)</li> <li>● LU2B** reversing power base (up to 32 A/15 kW)</li> </ul>
<b>Control unit</b>	<ul style="list-style-type: none"> <li>● LUCM multifunction control unit</li> </ul>

## Software Implementation

The following program in ST language is a connection example between the Scale DFB (instance name = Scale\_mdb) and the Special\_mdb\_u DFB (instance name = Spec):

```
(* Scale measure on Modbus SL TeSys 3 *)
Scale_mdb (%M300);
Scale_mdb.Prog_num:=3;
Scale_mdb.In_avg:=Spec.out_data[2];
Scale_mdb.In_l1:=Spec.out_data[3];
Scale_mdb.In_l2:=Spec.out_data[4];
Scale_mdb.In_l3:=Spec.out_data[5];
Scale_mdb.In_gnd:=Spec.out_data[6];
Scale_mdb.In_phimb:=Spec.out_data[7];
Scale_mdb.In_range:=Spec.out_data[14];
Scale_mdb.In_setup:=Spec.out_data[15];
```

In this example, the program number (Prog\_num) for the Special\_mdb\_u DFB must be equal to 3. In this case, the public variables (Out\_data[0]...Out\_data[15]) of the scale DFB return the measurements in % FLA.

See the Special\_mdb\_u DFB public variables description in *Public Variables Characteristics, page 54*.

The Scale DFB converts the measurements unit from % FLA to A and to any unit in the A...mA range:

- The Out\_ri output variables return the current measurements in A.
- The Out\_ii output variables return the current measurements in the unit chosen by the user in the A...mA range.

If a fault occurs:

- the Special\_mdb\_u DFB outputs are set to -1,
- the Scale DFB outputs are set to -1,
- the Scale DFB Fault\_st output is set to 1.

## Input Characteristics

The following table describes the DFB input:

Input	Type	Description
Prog_num	INT	The program number enables the user to select the measurement unit of the Scale DFB outputs (A...mA): <ul style="list-style-type: none"> <li>● 0 = the unit is 1/1 A (coeff = 1)</li> <li>● 1 = the unit is 1/10 A (coeff = 10)</li> <li>● 2 = the unit is 1/100 A (coeff = 100)</li> <li>● 3 = the unit is 1/1000 A (coeff = 1000)</li> </ul>

## Output Characteristics

The following table describes the DFB output:

Output	Type	Description
Fault_st	EBOOL	Fault state

## Public Variables Characteristics

The following table describes the DFB public variables:

Public Variable	Type	Description
In_avg	INT	Average motor current (x 0.1 % FLA)
In_L1	INT	L1 current (% FLA)
In_L2	INT	L2 current (% FLA)
In_L3	INT	L3 current (% FLA)
In_gnd	INT	Ground current (% FLA min)
In_phimb	INT	Current imbalance coefficient
In_range	INT	Control unit sensor maximum current (x 0.1 A): <ul style="list-style-type: none"> <li>● 6 = adjustment range 0.15 to 0.6 A</li> <li>● 14 = adjustment range 0.35 to 1.4 A</li> <li>● 50 = adjustment range 1.25 to 5 A</li> <li>● 120 = adjustment range 3 to 12 A</li> <li>● 180 = adjustment range 4.5 to 18 A</li> <li>● 320 = adjustment range 8 to 32 A</li> </ul>
In_setup	INT	Full load amps setting (% FLA max): <ul style="list-style-type: none"> <li>● minimum = 25 (default value)</li> <li>● maximum = 100</li> </ul>
Out_ravg	REAL	Average motor current in A Scaling formula: $I_{Avg} \times (\text{adjustment range}) \times (\text{FLA setting}) / 100000$
Out_rl1	REAL	L1 current in A Scaling formula: $IL1 \times (\text{adjustment range}) \times (\text{FLA setting}) / 100000$



Public Variable	Type	Description
Out_rl2	REAL	L2 current in A Scaling formula: $IL2 \times (\text{adjustment range}) \times (\text{FLA setting}) / 100000$
Out_rl3	REAL	L3 current in A Scaling formula: $IL3 \times (\text{adjustment range}) \times (\text{FLA setting}) / 100000$
Out_rgnd	REAL	Ground current in A Scaling formula: $IGnd \times (\text{adjustment range} / 4) \times (\text{FLA setting}) / 100000$
Out_rimb	REAL	Current imbalance in A Scaling formula: $Iimb \times IAvg / 100$
Out_rstp	REAL	Full load amps (FLA) in A Scaling formula: $(\text{adjustment range} \times \text{FLA setting}) / 1000$
Out_iavg	INT	Average motor current in unit defined in the Prog_num variable (1) Scaling formula: $Out\_ravg \times \text{coeff} (1)$
Out_il1	INT	L1 current in unit defined in the Prog_num variable (1) Scaling formula: $Out\_rl1 \times \text{coeff} (1)$
Out_il2	INT	L2 current in unit defined in the Prog_num variable (1) Scaling formula: $Out\_rl2 \times \text{coeff} (1)$
Out_il3	INT	L3 current in unit defined in the Prog_num variable (1) Scaling formula: $Out\_rl3 \times \text{coeff} (1)$
Out_ignd	INT	Ground current in unit defined in the Prog_num variable (1) Scaling formula: $Out\_rgnd \times \text{coeff} (1)$
Out_iimb	INT	Current imbalance in unit defined in the Prog_num variable (1) Scaling formula: $Out\_rimb \times \text{coeff} (1)$
Out_istp	INT	Full load amps (FLA) in unit defined in the Prog_num variable (1) Scaling formula: $Out\_rstp \times \text{coeff} (1)$
(1) See the Prog_num input description in <i>Input Characteristics, page 136</i> . For example, if Prog_num = 3, then the unit is mA and the coeff = 1000.		

## Timestamp: TeSys U DFB for Data Time-Stamping


### Presentation

The Timestamp derived function block (DFB) is dedicated to the time-stamping of up to 8 input registers of a TeSys U starter-controller (up to 32 A/15 kW) with a multifunction control unit. It provides an output table of the 8 time-stamped registers and 4 date and time registers (see *DT\_DateTime*, page 126).

### Characteristics

Characteristic	Value
Name	Timestamp
Version	1.00
Input	3
Output	3
Input/Output	0
Public Variable	2

### Graphical Representation



### TeSys U Compliance

The Timestamp DFB is compliant with all the TeSys U sub-assemblies.

## Software Implementation

The following program in ST language is a connection example between the Timestamp DFB (instance name = Ts\_def\_pdp) and the Special\_pkw\_u DFB (instance name = Spec\_pkw\_pdp):

```
(* Link between Timestamp DFB and Special_pkw_u DFB *)
Ts_def_pdp.In_data[0]:= Spec_pkw_pdp.Out_data[0];
Ts_def_pdp.In_data[1]:= Spec_pkw_pdp.Out_data[1];
Ts_def_pdp.In_data[2]:= Spec_pkw_pdp.Out_data[2];
Ts_def_pdp.In_data[3]:= Spec_pkw_pdp.Out_data[3];
Ts_def_pdp.In_data[4]:= Spec_pkw_pdp.Out_data[4];
Ts_def_pdp.In_data[5]:= Spec_pkw_pdp.Out_data[5];
Ts_def_pdp.In_data[6]:= Spec_pkw_pdp.Out_data[6];
Ts_def_pdp.In_data[7]:= Spec_pkw_pdp.Out_data[7];
```

## Input Characteristics

The following table describes the DFB inputs:

Input	Type	Description
Rst_cmd	EBOOL	Reset time-stamping counter
Strt_cmd	EBOOL	Start time-stamping
Rstrm_cmd	EBOOL	Reset time-stamping memory

## Output Characteristics

The following table describes the DFB outputs:

Output	Type	Description
Rec_num	INT	Number of time-stamping operations since last reset
Rst_st	EBOOL	0 = Time-stamping is reset 1 = Time-stamping is not reset
End_st	EBOOL	0 = Time-stamping is not over 1 = Time-stamping is over


**Public Variables Characteristics**

The following table describes the DFB public variables:

Public Variable	Type	Description
In_data[0]...[7]	ARRAY[0...7] of INT	8 data registers to be time-stamped
Out_data[0]...[11]	ARRAY[0...11] of INT	<ul style="list-style-type: none"><li>● Out_data[0]...Out_data[7]: 8 time-stamped data registers</li><li>● Out_data[8]: seconds (1)</li><li>● Out_data[9]: hours and minutes (1)</li><li>● Out_data[10]: month and day (1)</li><li>● Out_data[11]: year (1)</li></ul>
(1) For more information regarding the date and time format, see <i>DT_DateTime</i> , page 126.		

---

# Index



---

## C

Comm\_manager\_t, 45  
Comm\_manager\_u, 33  
Ctrl\_cmd\_mdb\_t\_xxxx, 38  
Ctrl\_cmd\_mdb\_u\_xxxx, 26  
Ctrl\_cmd\_t, 97  
Ctrl\_cmd\_u, 94  
Ctrl\_pfb\_t\_mms, 88  
Ctrl\_pfb\_u\_mms, 85  
Ctrl\_pfb\_u\_ms, 82  
Custom\_mdb\_xxxx, 77  
Custom\_pkw, 127

## S

Scale, 134  
Special\_mdb\_t\_xxxx, 62  
Special\_mdb\_u\_xxxx, 52  
Special\_pkw\_t, 112  
Special\_pkw\_u, 102

## T

TeSys - instructions  
    Comm\_manager\_t, 45  
    Comm\_manager\_u, 33  
    Ctrl\_cmd\_mdb\_t\_xxxx, 38  
    Ctrl\_cmd\_mdb\_u\_xxxx, 26  
    Ctrl\_cmd\_t, 97  
    Ctrl\_cmd\_u, 94  
    Ctrl\_pfb\_t\_mms, 88  
    Ctrl\_pfb\_u\_mms, 85  
    Ctrl\_pfb\_u\_ms, 82  
    Custom\_mdb\_xxxx, 77  
    Custom\_pkw, 127  
    Scale, 134  
    Special\_mdb\_t\_xxxx, 62  
    Special\_mdb\_u\_xxxx, 52  
    Special\_pkw\_t, 112  
    Special\_pkw\_u, 102  
    Timestamp, 138  
Timestamp, 138

