



600 SERIES WEATHER PROTECTED PRODUCT

IP56 Installation Instructions

To achieve IP56 weather protection from the front for your PDL product, it is essential to follow the following steps:

FOR FLUSHBOX MOUNTING

- 1 Ensure the surface that is going to seal off against the product is completely flat and smooth, and a minimal size hole is cut in the wall.
- 2 Ensure that the flush box has been mounted below the wall surface.
- 3 Wire up the product in accordance with NZECP51 1993 in New Zealand and AS3000 Wiring Rules in Australia.
- 4 Use the IP56 mounting screws with an 'O Ring' on each mounting screw. Screw the product to the wall firmly and fit the cover.

FOR SOLID WALL MOUNTING

- 1 Ensure the surface that is going to seal off against the product is completely flat and smooth, and a minimal size hole is cut in the wall.
- 2 Wire up the product in accordance with NZECP51 1993 in New Zealand and AS3000 Wiring Rules in Australia.
- 3 Screw the product firmly to the wall using 4 suitable mounting screws, piercing the gasket flange.
- 4 Insert the two bungs into the flushbox mount holes and fit the cover.



PDL



New Zealand Head Office: PO Box 15 355, Auckland, New Zealand
Telephone +64-9-829 0490, Fax +64-9-829 0491
www.schneider-electric.co.nz

Australia Head Office: Locked Bag 5500, Baulkham Hills Business Centre,
NSW 2153, Australia
Telephone +61-2-9851 2800, Fax +61-2-9629 8340
www.schneider-electric.com.au



PDL Electrical Products are manufactured by

