


Original AutoCAD format A1



NOTE: Contactor up sizing is recommended for frequent startup / heavy DOL starting requirements. For such requirements, kindly connect with Schneider Electric representatives

A vertical timeline diagram with four points labeled A, B, C, and D from top to bottom. Each point is connected to a vertical axis on the left by a horizontal line.

E

F

G

Original AutoCAD format A1