



NOTE:
THESE HANDLES SUITABLE FOR USE WITH:

LK3GU3 GS1JU3
LK3JU3 GS1MU3
LK3MU3 GS1QU3

CATALOG NUMBER
GS1AH130 GS1AH430
GS1AH140 GS1AH440
GS1AHT130 GS1AHT430
GS1AHT140 GS1AHT440

IEC DISCONNECT SWITCH HANDLE
GS1AH130, GS1AH140, GS1AH430, GS1AH440
GS1AHT130, GS1AHT140, GS1AHT430, GS1AHT440

 **SQUARE D**
Schneider Electric

DWG# 37123086
NO.