

# Schneider Electric Altivar Soft Starter ATS480 DTM Library

## V1.2.1

### - Read Me -

This document contains important information about the Altivar Soft Starter ATS480 DTM Library software component.

Please read the complete document before you start the installation and operation of the product.

## 1. Overview

The Altivar Soft Starter ATS480 DTM Library is a software component which represents a package of Altivar Soft Starter ATS480 DTM.

Altivar Soft Starter ATS480 DTM Library Installer → Altivar Soft Starter ATS480 DTM

## 2. Altivar Soft Starter ATS480 DTM Library referenced DTM

Software Component Name	Version
Schneider Electric Altivar Soft Starter ATS480 DTM Library	V1.2.1
Altivar Soft Starter ATS480	V1.2.1.0

## 3. System Requirements

### 3.1 Supported operating systems

This software can be installed on the following operating systems:

- > Microsoft Windows 10 32/64-bit .
- > Microsoft Windows 11 64-bit .

### 3.2 Minimum PC Requirements

Equipment	Minimum
Processor	Pentium 4 or equivalent (Core 2 Duo, 2 GHz)
RAM	2 GB
Free Hard Disk Space	1 GB of free disk space Must be available
Display	Resolution: 1366 x 768 pixels with 32 bit colors DPI: 96 (100%)

### 3.3 Recommended PC Requirements

Equipment	Recommended
Processor	Intel(R) Core(TM) i3
RAM	4 GB
Free Hard Disk Space	2 GB
Display	Resolution: 1920 x 1080 pixels with 32 bit colors DPI: 96 (100%)

## 4. Software Pre Requisites

1. Microsoft .NET Framework 3.5 SP1 MUST be installed, before installing DTM Library.

This is downloadable from the Microsoft website at below link

<http://download.microsoft.com/download/2/0/e/20e90413-712f-438c-988e-fdaa79a8ac3d/dotnetfx35.exe>

2. Acrobat reader DC 32 bit must be installed in the PC

## 5. Installation

### 5.1 Administrator Privileges

In order to install Altivar Soft Starter ATS480 DTM Library software component, you must have administrative privileges to install and uninstall programs.

### 5.2 Re-installing or Uninstalling

You can uninstall the installer from the Add/Remove Programs Control Panel.

If you have already installed Altivar Soft Starter ATS480 DTM Library, the installer gives you options to Modify, Remove

Altivar Soft Starter ATS480 DTM Library.

**Note:** To Repair, Altivar Soft Starter ATS480 DTM Library installer should be available.