

Outlet Box FPSS121

Installation Instructions


⚠ WARNING

HAZARD OF ELECTRIC SHOCK OR ARC FLASH


This product must only be installed by a licensed electrical contractor or other persons authorised by legislation to work on the fixed wiring of any electrical installation.

Failure to follow these instructions can result in death, serious injury or equipment damage.

1. Remove the top cover of the unit.



2. Use the entries below the unit to bring power and data cables. Be aware this unit can only fit 1 x power and 1 x data.




NOTICE

Only to be used with Clipsal C2000 Series Outlets.


Suitable for max 1 power outlet per box.

Only use Screws supplied in the box.


3. Run power cable through the enclosed/segregated side (earth available).



4. Wire the Clipsal C2000 Series Outlet (not supplied).



5. Screw the Clipsal C2000 Series Outlet with the screws supplied in the FPSS packaged box.



6. Peel the plastic surface protector.



Schneider Electric (Australia) Pty Ltd

Contact us: clipsal.com/feedback

National Customer Care Enquiries:

Tel 1300 2025 25

Fax 1300 2025 56

clipsal.com

Schneider Electric (Australia) Pty Ltd reserves the right to change specifications, modify designs and discontinue items without incurring obligation and whilst every effort is made to ensure that descriptions, specifications and other information in this catalogue are correct, no warranty is given in respect thereof and the company shall not be liable for any error therein.

© 2014 Schneider Electric. All Rights Reserved.
Trademarks are owned by Schneider Electric Industries SAS or its affiliated companies.