


# Stago



## Steel trunking 110, 120, 130, 170


INS 5540001  
 INS 5540011  
 INS 5541001  
 INs 5544001  
 INS 5550001  
 INS 5550002  
 INS 5550003  
 INS 5550011  
 INS 5550012  
 INS 5550013

INS 5551000  
 INS 5551001  
 INS 5551002  
 INS 5551003  
 INS 5552001  
 INS 5552002  
 INS 5552003  
 INS 5553000  
 INS 5553001  
 INS 5553002


INS 5553003  
 INS 5553010  
 INS 5553011  
 INS 5553012  
 INS 5553013  
 INS 5553021  
 INS 5553022  
 INS 5553023



### Installation



## Installation



## Dismounting

