

## Application Guide Switched Socket

This application guide applies to the following Unica product.



Cat No.	Description
MGU5.049.18	16 A 250 V 1 Gang Switched International Socket







### SPECIFICATIONS

Voltage	: 250 Vac
Mounting Centre	: 60.3 mm

Thank you for choosing **Schneider Electric** Unica Socket. To ensure proper application of our product, please read through the following information before installation and use.

# Unica

## Compatible Plugs

Plug Types		Corresponding Insertion	Rating
3-pin plug (BS)			13 A 230 V
3-pin China plug			10 A 220 V
2-pin China plug			10 A 220 V







### IMPORTANT NOTE

1. Electrical installation must be carried out by a qualified electrician.
2. Please check your local wiring regulations before actual installation.

### PRODUCT CARE

When cleaning, use a soft damp cloth / tissue to remove dust or dirt. Ensure the product is switched off during cleaning. **DO NOT USE** caustic cleaning agents.

# Compatible Plugs

Plug Types		Corresponding Insertion	Rating
3-pin Thailand plug			16 A 220 V
3-pin India plug			6 A 230 V
2-pin plug (Euro)			2.5 A 230 V

## **▲ WARNING**


### **ELECTRIC SHOCK / SHORT CIRCUIT**

- Use the rated voltage equipment 220-250 Vac
- Use compatible plugs only. See the table


**Failure to follow these instruction can result in death, serious injury or equipment damage**

## MOUNTING INSTRUCTION


1. Align and place the Insert on the wall box.



2. Fasten with screws on both sides.



3. Assemble the Cover frame on the Insert, ensuring proper engagement by a clear "click" sound.



## UNMOUNTING INSTRUCTION

1. To remove the Cover frame, carefully insert a screwdriver between the Cover frame and the Wall surface. Then twist the screwdriver to dislodge the Cover frame from the Insert.
2. Use the other hand to support and remove the Cover frame.

