

# Variable speed drives

## Altivar 312

---

- **Selection guide** ..... page 12
- **Presentation** ..... page 18
- **Altivar 312 variable speed drives**
  - **Characteristics** ..... page 20
  - **References** ..... page 26
- **Options**
  - **Communication buses and networks** ..... page 28
  - **Dialogue tools** ..... page 34
  - **Configuration tools** ..... page 35
  - **Braking resistors** ..... page 40
  - **Line chokes** ..... page 42
  - **Additional EMC input filters** ..... page 44
  - **Output filters and motor chokes** ..... page 46
- **SoMove setup software** ..... page 36
- **Dimensions** ..... page 48
- **Schemes** ..... page 54
- **Mounting and installation recommendations** ..... page 56
- **Motors starters** ..... page 58
- **Functions** ..... page 60