




Module DELTA 8 / Core unit DELTA 8
/ Modulo DELTA 8




Choisir son emplacement / Placement of the core unit / Lugar y forma de instalación




Montage sur DIN / DIN mounting / Montaje sobre carril DIN





Installation murale / Wall mounting / Montaje sobre muro




Installation en armoire 10" / 10" racking / Montaje en armario 10"




Câblage / Wiring / Cableado




Alimentation & Mise à la terre / Power supply & Grounding / Alimentación & Puesta a tierra



Raccordement des ressources / Input connection / Conexión de las Entradas



Chaîner 2 modules / Stacking 2 unit / Conexión de 2 Delta 8



Du port de sécurité du 1er module au port téléphone 1 du second.
 From security port of the 1st unit to telephone line 1 of the second.
 Del Puerto de seguridad del 1er Delta 8 a la línea 1 telefónica del segundo.