

Data Bulletin

QO® Load Center Repair / Replacement Parts Three-Phase Fixed Main Lugs

NOTE: For specific part numbers, go to www.schneider-electric.us, click on Product FAQ's, enter the device catalog number, click SEARCH, then look for the information required. Photos are typical, and may vary slightly from your actual device.

Part:

<p>Indoor Cover</p> 	<p>RB Cover / Door</p>  <p>Interior Trim / Dead Front</p>	<p>Interior Assembly</p> 
<p>Main Lugs</p> 	<p>Main Lugs Keps Nuts</p> 	<p>Indoor Cover Latch Kit</p> 
<p>Indoor Cover Hinges</p> 	<p>Indoor Flush Cover Mounting Screw</p> 	<p>Indoor Surface Cover and RB Interior Trim / Dead Front Mounting Screw</p> 
<p>RB Cover / Door Mounting Screw</p> 	<p>RB / Outdoor Cover Latch and Rivet</p> 	<p>Neutral Bonding Screws (Green)</p> 

Schneider Electric USA
1601 Mercer Road
Lexington, KY 40511 USA
1-888-SquareD (1-888-778-2733)
www.us.SquareD.com

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

© 2005 Schneider Electric All Rights Reserved

