

## Selector Worksheet

# Tower Lights

Use this worksheet to help identify which type of tower light is right for your customer. The following questions will guide you to the correct product, and the steps on the back will help determine how to identify the specific part number from Digest 176.

### 1. What type of environmental protection does your customer require?

- IP65 – Dust tight and protected against water hose down; choose **XVB** or **XVU**
- IP54 – Dust resistant and protected against splashing water; choose **XVC**

### 2. Does your customer need an audible sounder?

- If yes, choose **XVB**, **XVC** or **XVU**

### 3. Does your customer want pre-assembled and pre-wired?

- If yes, choose **XVC**
- If no, choose **XVB**, or **XVU**

*\*For a full selector panorama, go to pages 19-6/7 in Digest 176*



**XVB**

70 mm Diameter



**XVC**

40 mm, 60 mm  
or 100 mm Diameter



**XVU**



by Schneider Electric

# How to find the part number

Follow the steps below to locate the part number you need. Page numbers refer to Schneider Electric's Digest 176. If you don't have a copy of this Catalog, please request one from your local representative or visit [www.schneider-electric.us](http://www.schneider-electric.us).

### Step 1: To locate the correct pages in the Digest

- If XVB is needed, go to page 19-111
- If XVC is needed, go to page 19-108

### Step 2: For XVB: if customer wants a beacon, go to page 19-110

- Select beacon from page 19-110 (a single part number is all that is required)

### Step 3: For XVB: if customer wants a tower light, go to page 19-111

- Choose base and cover (XVBC21) [one required]
- Choose lens unit(s) from page 19-111 (you can use up to five lens units in a single XVB tower light)
- If desired, customer can choose a strobe for the top unit
- Select LED or incandescent bulb for each lens unit from page 19-112
- Select tube and accessories as desired from page 19-112

### Step 4: For XVC, go to page 19-108/109

- Select tower diameter (40 mm, 60 mm or 100 mm)
- Select single part number from the tables reflecting voltage and number of lens units
- Select accessories as desired (all XVC units come pre-assembled and pre-wired)

### Step 5: For XVU, go to [handout](#)

(<https://schneider-electric.box.com/s/je411rlunocytolc31y4u3e9uj6n0p05>)



XVB



XVC



XVU

### Schneider Electric USA

1415 S. Roselle Road  
Palatine, IL 60067  
Tel: 847-397-2600  
Fax: 847-925-7500  
[www.schneider-electric.com/us](http://www.schneider-electric.com/us)