



W903819400131

LC4-D09A...D25A



LC4-D32A



LC4	D09A...D18A	D25A	D32A
b	218	221	-
C1	96	102	102
+ LAD-N/C (2/4 contacts / контакты)	127	133	133
+ LA6-DK10	139	145	145
+ LAD-T, R,S	147	153	153

Contrôle / Control / Управление:

LC4-D09...D32: C = 1.7 N.m

Montage relais / relay mounting / Установка реле:

LC4-D09/12/18: C = 1.7 N.m

LC4-D25/32: C = 2.5 N.m

Câblage relais / relay wiring / Монтаж реле:

C = 2.5 N.m

Câblage sectionneur/fuse carriers wiring /

Монтаж держателей предохранителей:

LC4-D09/12/18/25: C = 1.2 N.m

LC4-D32: C = 2 N.m

