

# MV15B-24/230

## Actuator Valve

### Installation instructions/Monteringsanvisning/Instructions d'installation/Montageanleitung/Instruccions de instalaci3n

Hot media hazard. Before removing actuator from valve or opening the valve, ensure that the valve control medium is isolated and relieve the pressure. Work should only be carried out by a competent engineer.



Fara f3r varma media. Innan st3lldonet avl3gsnas fr3n ventilen eller ventilen 3ppnas skall tryckl3shet s3kerst3llas 3ver ventilen. Arbetet skall utf3ras av f3r 3ndam3let beh3rig tekniker.



