

fr en de it es nl dk se pt
no fi ru

PRF1 Master

Réf. :	Réf. :	4P 16643
16630	2P 16641	6P 16644
	3P 16642	8P 16645





Réf. : 16646






Schneider
Electric

**Installez / Install / Installieren / Installazione / Instale /
Installeren / Installer / Installera / Instale / Installer /
Asenna / Устанџка**




**Signalisation / Signalling / Meldung / Segnaletica / Señalización / Signalerung /
Signalerung / Signalerung / Sinalização / Signalerung / Merkinanto / Сигнализация**




PRF1 Master


TT / TN-S / IT (+N) Type 1 + Type 2




TT / TN-S / IT (+ N) Type 1




Type 2






TN-C / IT Type 1 + Type 2



TN-C / IT Type 1



Type 2



GHE1259301_07 (03/2009)