


### CN1定义

13	11	9	7	5	3	1
PLS	PLS_24	DI0	DO0	CZ-	PTOZ-	0VM
12	10	8	6	4	2	
/PLS	DI1	DI_COM	DO_COM	CZ+	PTOZ+	
26	24	22	20	18	16	14
SIGN	SIGN_24V	DI4	DI2	DO1	PTOB+	PTOA+
25	23	21	19	17	15	
/SIGN	DI5	DI3	DO2	PTOB-	PTOA-	

### 与漏型输出PLC的配合



### 与源型输出PLC的配合

