

Schneider Electric Altivar Process ATV6xx DTM Library

V3.8.3

- Read Me -

This document contains important information about the Altivar Process ATV6xx DTM Library software component.

Please read the complete document before you start the installation and operation of the product.

1. Overview

The Altivar Process ATV6xx DTM Library is a software component which represents a package of Altivar Process ATV6xx DTM.

Altivar Process ATV6xx DTM Library Installer

AltivarProcess ATV6xx DTM

2. Altivar Process ATV6xx DTM Library referenced DTM

Software Component Name	Version
Schneider Electric Altivar Process ATV6xx DTM Library	V3.8.3
Altivar Process ATV6xx	V3.8.3.0

3. System Requirements

3.1 Supported operating systems

This software can be installed on the following operating systems:

- > Microsoft Windows 7 32/64-bit
- > Microsoft Windows 8.1 32/64-bit
- > Microsoft Windows 10 32/64-Bit
- > Microsoft Windows 11 64-Bit

3.2 Minimum PC Requirements

Equipment	Minimum
Processor	Pentium 4 / Core 2 Duo, 2 GHz
RAM	4 GB
Free Hard Disk Space	1 GB of free disk space Must be available
Display	Resolution: 1024 x 768 pixels with 32 bit colors DPI: 96

3.3 Recommended PC Requirements

Equipment	Recommended
Processor	Intel(R) Core(TM) i3
RAM	4 GB
Free Hard Disk Space	2 GB
Display	Resolution: 1920 x 1080 pixels with 32 bit colours DPI: 96

4. Software Pre Requisites

1. Microsoft.NET Framework 3.5 SP1 MUST be installed, before installing DTM Library.

This is downloadable from the Microsoft website at below link

<http://download.microsoft.com/download/2/0/e/20e90413-712f-438c-988e-fdaa79a8ac3d/dotnetfx35.exe>

2. Acrobat reader DC 32 bit must be installed in the PC

5. Installation

5.1 Administrator Privileges

In order to install Altivar Process ATV6xx DTM Library software component, you must have administrative privileges to install and uninstall programs.

5.2 Re-installing or Uninstalling

You can uninstall the installer from the Add/Remove Programs Control Panel.

If you have already installed Altivar Process ATV6xx DTM Library, the installer gives you options to Modify, Remove

Altivar Process ATV6xx DTM Library.

Note: To Modify or Repair, Altivar Process ATV6xx DTM Library installer should be available.

5.3 Language Packs

> Install the respective language packs for other language support.

> You can download the language packs for DTM from Schneider website .