

# ReadMe

**Product name: XX Configuration Software**

**Version: 2.1.1.0 (EN)**

## 1. Terms of usage

See the file « End User License Agreement (EULA) ».

## 2. Description

« XX Configuration Software » is a computer software dedicated to the configuration of ultrasonic OsiSense XX sensors from the manufacturer "Telemecanique Sensors".

## 3. Requirements

Operating system:

- Windows 7 SP1 (x86 & x64)
- Windows 8.1 (x86 & x64)
- Windows 10 (x86 & x64)

Internet Explorer ≥ 9.0

Disk space ≥ 1 GB

RAM memory ≥ 2 GB

Processor speed ≥ 1.2 GHz

Display resolution ≥ 1360x768

## 4. Release

See the file « Release Notes ».

## 5. Installation

To install the software "XX Configuration Software", you must use the setup file delivered on the USB key or download it on the WEB site:

<http://www.tesensors.com/global/product/gr/XX0002/>

The installation of the custom USB driver (Telemecanique Sensors) is required to communicate with the XXZBOX01 interface box. This installation is automatic when you install the software "XX Configuration Software".

Depending on the version of Windows used, some Windows updates may be required to continue installing the software. After each update installation, you **must restart** your computer; otherwise the installation of additional software cannot run.

The software is installed by default in the directory:

x64 : C:\Program Files (x86)\Telemecanique Sensors\XX Configuration Software

x86 : C:\Program Files\Telemecanique Sensors\XX Configuration Software

The default directory used for backing up projects and analysis files is:

C:\<user>\MyDocuments\XXConfigurationSoftware

## 6. Maintenance

In case of request by the technical support, the traceability files are saved in the directory:

- %TEMP%\XX\_software\_setup.log
- %APPDATA%\Schneider Electric\XXConfigurationSoftware\logs\MainModule.log
- %APPDATA%\Schneider Electric\XXConfigurationSoftware\logs\trace.log

## 7. Usage

Start the software from the Windows menu "Start > Telemecanique Sensors > XX Configuration Software". Only one instance of the application can be opened at a time.

## 8. Uninstall

Uninstalling the software can only be done from the Windows menu "Control Panel > Programs and Features". Uninstalling the "XX Configuration Software" does not uninstall the pre-requisites.

## 9. License registration

The product is subject to a license. This license is free.  
You have 21 days of product evaluation before the mandatory registration of the license.

The activation code associated with the product is: **A-2N35-FFUJ-ZLC3**.  
This may be requested during the registration process.