



**POWER - Power Monitoring and Control**

**How to check the Sepam Serial Number**

**SEPAM SERIES 20/40**

- Remember that in order to identify a Sepam, you have to check the 2 labels on the right side panel of the base unit describing the product's functional and hardware features.

**Hardware reference and designation label**

User Machine Interface model  
Power supply

**Functional reference and designation label**

Type of application  
Working language

Additional information (not given systematically)

**SEPAM SERIES 80**

- In order to identify a Sepam, you have to check the 3 labels which are visible when the door of the front panel is opened.
  - label with base unit hardware reference, stuck on the back of the door on the front panel
  - 2 labels stuck on the cartridge

Serial n°  
Reference n°  
Description  
Commercial name

DES0684  
59707  
Memory cartridge series 80  
Cartouche mémoire série 80  
MMS020  
Origin: France

Cartridge hardware reference.

59730 substation S81  
sous-station S81  
59709 English / French series 80 33  
Anglais / Français série 80 33

Reference of software loaded in the cartridge:  
■ application  
■ working language.

**For ant further information please contact the PMC Global Technical Support :  
[Global-PMC-Tech-Support@Americas](mailto:Global-PMC-Tech-Support@Americas)**