

# SoMachine Software V3.0

## Altivar Library Update

### Read Me



**Library Version: 4.2.5.0+ (V006)**

**Release Date: 14.11.2011**

**This document contains important information  
about the SoMachine software. Please read the complete  
document before you run the product.**

This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. All pertinent state, regional, and local safety regulations must be observed when installing and using this product. When devices are used for applications with technical safety requirements, the relevant instructions must be followed. Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results. Failure to observe this information can result in injury or equipment damage. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us. No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

© 2011 Schneider Electric. All rights reserved.

November 2011

### **English:**

Please install the following patch (SoMaV3.0 Altivar Library Update 4.2.5.0+), which includes an updated version of the Altivar Library.

This patch installation is mandatory.

This patch can only be installed on SoMachine Version 3.0.

This patch will erase and rewrite the Altivar Library in order to update the AltivarXX\_control Function Blocks.

Please restart SoMachine after the patch installation in order to take the modification into account.

Thank you for your understanding.

### **Français:**

Veillez installer le patch suivant (SoMaV3.0 Altivar Library Update 4.2.5.0+), qui apporte une nouvelle version de la Bibliothèque Altivar. L'installation de ce patch est obligatoire.

Ce patch peut seulement être installé sur la version 3.0 de SoMachine.

Le patch va écraser l'ancienne version de la bibliothèque Altivar Library de façon à actualiser le Fonction Block AltivarXX\_control.

Merci de redémarrer SoMachine après l'installation du patch afin que les modifications soient prises en compte.

Merci pour votre compréhension.

## **Italiano:**

Si prega di installare il seguente patch (SoMaV3.0 Alivar Library Update 4.2.5.0+), che include una nuova versione della Libreria Altivar.

L'installazione di questo patch è obbligatorio.

Questo patch può essere installato solo sulla versione 3.0 di SoMachine.

Il patch sovrascrivera' la vecchia versione della Libreria Altivar al fine di aggiornare il blocco funzione AltivarXX\_control.

Dopo avvenuta installazione si prega di riavviare SoMachine affinche' le modifiche siano attualizzate.

Grazie per la vostra comprensione.

## **中文:**

请安装下面的补丁 ( SoMaV3.0 Altivar Library Update 4.2.5.0+ )。该补丁是对Altivar库文件的更新；

请务必安装该补丁；

该补丁只对SoMachine 3.0版本；

已有的Altivar库文件将被替换，以更新功能块AltivarXX\_control Function；

请关闭并重新打开SoMachine，补丁方会生效；

感谢您的谅解。

## **Español:**

Por favor instale el siguiente parche (SoMaV3.0 Altivar Library Update 4.2.5.0+), el cual incluye una versión actualizada de la biblioteca Altivar.

La instalación de este parche es obligatoria.

Este parche solo puede ser instalado en la versión de SoMachine 3.0. Este parche eliminará y volverá a escribir la biblioteca Altivar con el objeto de actualizar los bloques de funciones AltivarXX\_control.

Por favor reinicie SoMachine después de la instalación del parche con el objeto de tomar en cuenta la modificación.

Gracias por su comprensión.

## **Deutsch:**

Bitte installieren Sie den folgenden Patch (SoMaV3.0 Altivar Library Update 4.2.5.0+), der die aktualisierte Version der Altivar Bibliothek enthält.

Die Installation dieses Patches ist zwingend.

Dieser Patch kann nur auf einer SoMachine Version 3.0 installiert werden.

Dieser Patch löscht und erneuert die Altivar Bibliothek, um die AltivarXX\_control Funktionsbausteine zu aktualisieren.

Bitte schließen Sie eine laufende SoMachine Applikation und starten sie neu um sicherzustellen, dass die Aktualisierung der Bibliothek wirksam wird.

Danke für Ihr Verständnis.