



6. SEE MANUAL FOR INSTALLATION CLEARANCES & OPERATION DETAILS.
5. REMOVABLE DUCT ADAPTERS PROVIDED ON UNITS HAVING "W" DIMENSION OF 60" OR LESS.
4. POWER DISTRIBUTION BLOCK OR BUSS BAR PROVIDED ON SUPPORT BRACKET DEPENDING ON LOAD BANK VOLTAGE AND KW.
3. WHEN UNIT IS OVER 60" WIDE, MOUNT VIA TOP & BOTTOM FLANGES. FABRICATE A STRUCTURE AT OUTBOUND BOTTOM FLANGE IF REQUIRED FOR ADDED SUPPORT.
2. ALL DIMENSIONS ARE APPROX.
1. WEIGHT:
- NOTES:



RADIATOR MOUNT LOAD BANK
GENERAL REFERENCE OUTLINE DRAWING

Model 1100 - 26"

Rev. F