

STR-300



Room Temperature Transmitter



STR300

Room temperature transmitter
Transmitter med temperaturgivare
Raum-Temperaturmessumformer
Sonde de température ambiante
Transmisor de temperatura ambiente
Trasmettitore di temperatura per ambiente

0FL-4339-001

Instruction
Montageanvisning
Bedienungsanleitung
Instructions d'installation
Instrucciones de empleo
Istruzioni per installazioni





5. 4...20mA 0...+40°C

UG=15...30 VDC