

PowerLogic™ PowerView™ Installation Guide

INSTALLATION MINIMUM REQUIREMENTS

Software

- Windows 2000 Professional SP4; Windows XP Professional SP2; or Windows Vista SP1 Business, Ultimate, or Enterprise
- Microsoft Office Excel 2000, XP, 2003, or 2007
- .Net Framework 2.0 (installed during PowerView installation).
- Microsoft SQL Server 2005 (MSSQL2005) Express (installed during PowerView installation)
- Microsoft Data Access Components (MDAC) 2.8 (installed during PowerView installation)
- Microsoft Message Queuing (MSMQ) (installed during PowerView installation)
- Microsoft Office Web Components (installed manually if necessary)

Hardware

- Hard drive: 5 GB on Drive C:\
- RAM: 512 MB
- CPU: 1 GHz
- Display resolution: 1024 x 768

NEW POWERVIEW 2.0 INSTALLATION

1. Insert the CD-ROM into the CD-ROM drive. Setup will start automatically.
2. Setup verifies that the Microsoft Office Web Components are installed. If they are not installed, a dialog box opens explaining that they are missing. After a few seconds the dialog box closes, and your web browser automatically opens the download page for the Microsoft Office Web Components. After the page loads, do the following:
 - a. Follow the instructions on the Microsoft web site to download and install the Microsoft Office Web Components.
 - b. After the installation, click **Finish** in the PowerLogic PowerView Setup dialog box, remove the PowerView installation CD-ROM from the CD-ROM drive, then return to step 1.
3. *Windows 2000:* PowerView Setup verifies that MDAC 2.8 is installed. If it is not installed, review the license agreement, then click **Accept**.
4. PowerView Setup verifies that .Net Framework 2.0, MSSQL2005 Express Advanced, and MSMQ are installed. If .Net Framework 2.0, MSDE2000 SP3a, MSSQL2005 Express, or MSMQ are not installed, do the following:
 - a. Review the license agreement.
 - b. Click **Accept** to install the prerequisite applications. Progress messages display while the applications are installed.
5. Review the PowerView license agreement, then select **I accept the terms in the License Agreement**.
6. Click **Next**.
7. If asked, enter a password for SQL Server. If you do not have a password, contact your network administrator.
8. Click **Install**. Progress messages display while PowerView is installed.
9. After PowerView is installed, click **Finish**.
10. Click **Yes** to restart Windows and to complete the installation.

UPGRADE POWERVIEW 1.0 TO POWERVIEW 2.0

Keep the following in mind when upgrading PowerView 1.0 to PowerView 2.0:

- You do not need to uninstall PowerView 1.0 to upgrade to PowerView 2.0.
- All data stored in the PowerView 1.0 database will be copied automatically to the new PowerView 2.0 MSSQL2005 Express database.

When you are ready to upgrade PowerView 1.0 to PowerView 2.0, insert the CD-ROM into the CD-ROM drive, then follow the instructions in “**New PowerView 2.0 Installation**” on page 1.