




EcoBreeze Remote Display Installation Instructions — ACECCP100SE



Important: For outdoor applications, use weather-proof conduit

Operating conditions:
Ambient temperature 0–55°C (32–131°F)
Humidity Relative humidity 5% - 95% non-condensing



Customer support and warranty information is available at the Schneider Electric Web site: www.schneider-electric.com.