




STC120

Pipe contact temperature sensor
Anlignings temperaturgivare
Anlegetempertursensor
Sonde d'applique
Sensor de temperatura aplicada
Sensore temperatura a contatto


OFL-3889-002

Instruction
Montageanvisning
Bedienungsanleitung
Instructions d'installation
Instrucciones de empleo
Istruzioni per installazioni


1.



2.



3.



4.

