APC by Schneider Electric

Smart-UPS RT

Uninterruptible Power Supply
15 kVA, 20 kVA
230 V Solution

THIS GUIDE SPECIFICATION IS WRITTEN IN ACCORDANCE WITH THE CONSTRUCTION SPECIFICATIONS INSTITUTE (CSI)
MASTERFORMAT. THIS SECTION MUST BE CAREFULLY REVIEWED AND EDITED BY THE ARCHITECT OR THE ENGINEER TO MEET
THE REQUIREMENTS OF THE PROJECT. COORDINATE THIS SECTION WITH OTHER SPECIFICATION SECTIONS IN THE PROJECT
MANUAL AND WITH THE DRAWINGS.

WHERE REFERENCE IS MADE THROUGHOUT THIS SECTION TO "PROVIDE", "INSTALL", "SUBMIT", ETC., IT SHALL MEAN THAT THE CONTRACTOR, SUBCONTRACTOR, OR CONTRACTOR OF LOWER TIER SHALL "PROVIDE", "INSTALL", SUBMIT", ETC., UNLESS OTHERWISE INDICATED.

UNINTERRUPTIBLE POWER SUPPLY

PART 1 - GENERAL

1.1 SUMMARY

A. **Scope:** This specification describes the operation and functionality of a continuous duty, single-phase, static Uninterruptible Power Supply (UPS) hereafter referred to as the UPS.

B. Included Features of the UPS:

- The UPS utilizes double conversion online topology designed to protect electronic equipment by supplying reliable, network-grade power featuring extremely tight voltage and frequency regulation.
- 2. The UPS features internal bypass and input power factor correction.
- The primary sections of the UPS are: input disconnect and filter stage, input PFC
 power stage, energy storage stage (DC bus capacitor bank), output power (inverter)
 stage, bypass, and a battery charger. The control of power module and fault detection
 logic is microcontroller-based.
 - a. The input disconnect and filter stage contains an input back-feed relay, input filter, and transient suppression.
 - b. The Input PFC power stage contains non-isolated power-factor-correcting AC/DC converters. These converters are capable of full power operation in a very wide input voltage range or from a nominal DC battery voltage.
 - c. The energy storage stage is a split DC bus capacitor handling seamless transitions from battery to online and vice versa as well as the low and high frequency power stages ripple.
 - d. The output power (inverter) stage operates directly from the DC bus and produces a configurable AC output voltage of 220, 230 or 240 Vac output. The output of the UPS is connected either to the inverter or through a bypass relay to the filtered input line.
 - e. The UPS contains a battery charger, which operates from the DC bus. The UPS batteries are modular, hot-swappable, and user-replaceable. The UPS can be restarted immediately after a prolonged power outage without waiting for the battery to be recharged.
- 4. The UPS utilizes green mode, an operating mode that bypass unused electrical components in good power conditions to achieve very high operating efficiency (typically 98%) without sacrificing any protection. The UPS provides early-warning fault analysis on batteries and will project battery replacement dates, enabling timely preventive maintenance.
- 5. The UPS has flash memory to facilitate firmware upgrades.
- 6. The multi-color LCD display with multicolor backlight provides detailed information, with the ability to configure the display locally.

C. Performance, Design, and Configurations:

The UPS and associated equipment operates in conjunction with a primary power supply and an output distribution system to provide quality uninterrupted power for a mission-critical, electronic equipment load.

- 1. This specification describes the performance, functionality, and design of the UPS, external battery packs, and connectivity solutions.
- 2. All programming and miscellaneous components for a fully operational system as described in this specification are available as part of the UPS.
- 3. The UPS and battery packs are available in the following configurations:

TYPE	MODEL Description	SKU
Tower/	APC Smart-UPS RT 15kVA 230V	SRTG15KXLI
Rack Convertible	APC Smart-UPS RT 20kVA 230V	SRTG20KXLI
	APC Smart-UPS RT 192V 9Ah Battery Pack	SRTG192XLBP2

1.2 REFERENCES

A. General: The publications listed below form a part of this Specification to the extent referenced. The publications are referred to in the text by the basic designation only. The edition/revision of the referenced publications is the latest date as of the date of the Contract Documents, unless otherwise specified.

B. Institute of Electrical and Electronics Engineers, Inc. (IEEE):

 ANSI/IEEE 519, "Guide for Harmonic Control and Reactive Compensation of Static Power Converters" (copyrighted by IEEE, ANSI-approved).

C. International Organization for Standardization (ISO):

- 1. ISO 9001, "Quality Management Systems Requirements."
- 2. ISO 14001, "Environmental Management Systems Requirements with Guidance for Use."

1.3 STANDARDS

A. Regulatory Compliance:

1. By model:

Model Description	SKU	Approvals	
APC Smart-UPS RT 15kVA 230V	SRTG15KXLI	CE, IEC/EN 62040-1: 2013, EN 62040-2: 2006, EN/IEC 62040-3, EN/IEC 61000-4-2	
APC Smart-UPS RT 20kVA 230V	SRTG20KXLI		

1.4 SYSTEM DESCRIPTION

A. Mechanical Design

- 1. The UPS is contained in a rugged steel cabinet with plastic front bezels
- 2. The UPS dimensions are:

UPS Model Description	sku	Height in mm	Width in mm	Depth in mm
APC Smart-UPS RT 15kVA 230V	SRTG15KXLI	306	440	700
APC Smart-UPS RT 20kVA 230V	SRTG20KXLI	306	440	700

- 3. The UPS cabinet is capable of conversion between Tower and Rack-Mount configurations.
- 4. For Rack-Mount application, the rail kit needs be purchased separately.

B. System Characteristics:

- 1. **System Capacity:** The system is rated to be capable of supporting:
 - a. 15 kVA or 15000 W, whichever limit is reached first (for the 15 kVA model).
 - b. 20 kVA or 20000 W, whichever limit is reached first (for the 20 kVA model).
- 2. **Online Efficiency:** The UPS full-load efficiency stated here is without degradation of output regulation as specified. Efficiency is at least 94.4% at full load and at least 94% at half load for the 15 kVA and 20 kVA models.
- Green Mode Efficiency: The UPS full-load efficiency stated here is without degradation of output regulation as specified. Efficiency is at least 98% for the 15 kVA and 20 kVA models.

4. Input:

a. AC Input Nominal Voltage:

220/230/240 Vac, single phase, 3 wire (L + N + G), connected via hardwire. 380/400/415 Vac, 3- phase, 5 wire (L1 + L2 + L3 + N + G), connected via hardwire.

b. AC Input Voltage Range:

160-285 Vac (L-N) at full load, while providing nominal charging to the battery system; or 100-160 Vac (L-N) at 50% load, while providing nominal charging to the battery system.

- Input Frequency Range: 40-70 Hz, auto-selecting.
- d. **Online Input Power Factor:** 15 KVA and 20 kVA models offer minimum 0.99 for 75% and 100% at 230 Vac.
- e. **Green Mode Input Power Factor:** 15 kVA and 20 kVA units offer ≥ 0.95 (for Resistive load ≥ 25%) at 230 Vac.) at 230 Vac
- f. Input Current Distortion:

15 kVA and 20 kVA models: <4% for 50% Resistive load, <3% for 100% Resistive load.

- g. Input Circuit Breaker (Recommendation):
 - 1) 15 kVA (1:1/3:1): 100 A; (3:3): 40A for each phase;

- 2) 20 kVA (1:1/3:1): 125 A; (3:3): 50A for each phase.
- h. Input Surge Protection:
 - 1) 600 Joules.
- 5. UPS Output:
 - a. AC Nominal Output Voltage: Single Phase

Single-Phase: 220/230/240 Vac. XLI models are factory set at 230 Vac.

3-Phase: 380/400/415 Vac. XLI models are factory set at 400 Vac.

- b. Output Connectors:
 - (1) IEC 320 C19; 5-wire HW, L1+L2+L3 + N + G
- c. Output Frequency: 50/60 +/- 4 Hz (auto-sense).
- d. Output Frequency Regulation: Free Running: Nominal +/- 0.1 Hz
- e. AC output voltage distortion (THD):

15 kVA and 20 kVA:

- 1) <2% @ 100% full linear load.
- 2) <4% @ 100% full non-linear load.
- f. AC output static voltage regulation: +/-1%.
- g. AC output dynamic voltage regulation:

15 kVA and 20 kVA: 5% rms of the initial value.

- h. Overload Rating:
 - 1) Normal Operation (Online):
 - a) <105% continuous
 - b) 105% ~ 125% for 5 minutes.
 - c) 125% ~ 150% for 1 minute.
 - d) >150% for 500ms.
 - Bypass Operation: Overload is limited by the upstream branch protection feeding the UPS.
 - a) Typically, a circuit breaker should be fitted at the input of the 15 kVA and 20kVA model. (Please refer to section 4.g.)
 - b) The overload capability of 15 kVA and 20 kVA is:

<130% continuous;

130% ~ 150% for 10 minutes to shutdown;

150% ~ 200% for 1 minutes to shutdown;

>200% for 1 second to shutdown;

10 rated current, 100ms.

- i. Output Load Power Factor Rating:
 - 1) 0.5 leading to 0.5 lagging.
- j. Crest Factor:
 - 1) 3:1
- 6. Battery:
 - a. **Battery Type:** Maintenance-free sealed lead-acid battery with suspended electrolyte, leak proof:

15 kVA and 20 kVA: 3456 VAH.

1.5 SUBMITTALS

C. Proposal Submittals:

- 1. Product catalog sheets or brochures.
- 2. Product guide specifications.
- 3. Product technical specifications.
- 4. System package submittal drawings including a single-line and mechanical diagrams.

D. **Delivery Submittals:**

- 1. Installation manual, which includes instructions for storage, handling, examination, preparation, installation, and start-up of UPS.
- 2. Operation Manual includes safety information, specifications, UPS features, configuration, UPS settings and troubleshooting information.

1.6 PROJECT CONDITIONS

- E. **Environmental Requirements:** Do not install the solid state UPS until space is enclosed and weatherproof, wet work in space is completed and nominally dry, work above ceilings is complete, and ambient temperature and humidity conditions are and will be continuously maintained at values near those indicated for final occupancy.
 - 1. The UPS is capable of withstanding any combination of the following environmental conditions in which it must operate without mechanical or electrical damage or degradation of operating characteristics.
 - a. Storage Ambient Temperature: 5°F to 113°F (-15°C to 45°C).
 - b. **Operating Ambient Temperature:** 0°C to 40°C (32°F to 104°F), normal operating. 40°C to 50°C (104°F to 122°F), 100% to 75% output linear derating. 25°C (77°F) is ideal for most battery types.
 - c. Relative Humidity: 0% to 95% non-condensing.
 - d. Altitude:
 - 1) Storage Altitude: 0 to 15,000 meters above sea level.
 - 2) **Operating Altitude:** 0 to 3,000 meters above sea level. From 1,000 meters to 3,000 meters, the UPS must be loaded by derating 1% of its nominal capacity per rising every 100 meters. At altitude of 3,000 meters, the UPS must be loaded only up to 80% of its nominal capacity.
 - e. **Audible Noise:** 15kVA/20KVA: less than 58 dBA at 3 feet (1 meter) when Temperature is lower than 28°C.
 - f. Protection Class: IP 20 rating.

1.7 WARRANTY

F. **Limited Warranty:** Schneider Electric IT Corporation (SEIT) warrants the UPS to be free from defects in materials and workmanship for a period of 3 years (2 years for the battery) from the date of purchase.

1. Warranty Limitations:

- a. The obligation of Schneider Electric IT Corporation (SEIT) under this warranty is limited to repairing or replacing, at its own sole option, any defective product.
- b. This warranty does not apply to equipment that has been damaged by accident, negligence, or misapplication or has been altered or modified in any way.
- c. This warranty applies only to the original purchaser who must have properly registered the product within 10 days of purchase.
- d. EXCEPT AS PROVIDED HEREIN, Schneider Electric IT Corporation (SEIT) MAKES NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.
- e. EXCEPT AS PROVIDED ABOVE, IN NO EVENT WILL Schneider Electric IT Corporation (SEIT) BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. Specifically, Schneider Electric IT Corporation (SEIT) is not liable for any costs, such as lost profits or revenue, loss of equipment, loss of use of equipment, loss of software, loss of data, costs of substitutes, claims by third parties, or otherwise.
- f. This warranty gives you specific legal rights, and you may have other rights that vary from state to state.

2. Warranty Procedures:

- a. To obtain service under warranty the purchaser must obtain a Returned Material Authorization (RMA) number from customer support.
- b. Products must be returned with transportation charges prepaid and must be accompanied by a brief description of the problem encountered and proof of date and place of purchase.

PART 2 - PRODUCTS

2.1 MANUFACTURERS

A. **Basis of Design:** Products specified are Smart-UPS On-Line Uninterruptible Power Supplies as manufactured by APC by Schneider Electric and as listed on page 2 of this specification. Items specified are to establish a standard of quality for design, function, materials, and appearance. Equivalent products by other manufacturers are acceptable. The Architect/Engineer will be the sole judge of the basis of what is equivalent.

2.2 MODES OF OPERATION

- A. **Normal:** The UPS output power stage (inverter) constantly recreates the UPS output voltage waveform by converting the DC bus voltage to AC voltage through a set of IGBT switches. In both online operation and battery operation, the output power stage (inverter) creates an output voltage waveform independent of the mains input voltage waveform. Input voltage anomalies such as brown-outs, spikes, surges, sags, and outages do not affect the amplitude or sinusoidal nature of the recreated output voltage sine wave of the output power stage (inverter). The input PFC power stage and the output power stage (inverter) shall operate in an on-line manner to continuously regulate power to the critical load. The input PFC stage shall be capable of full battery recharge while simultaneously providing regulated power to the load for all line and load conditions within the range of the UPS specifications.
 - 1. Overload Capability: As the details listed on page 4.
 - 2. **Output Contactor:** The output power stage (inverter) is equipped with an output mechanical relay to provide physical isolation of the inverter from the critical bus. With this feature a failed inverter will be removed from the critical bus.
 - 3. **Battery Protection**: The inverter is provided with monitoring and control circuits to limit the level of discharge on the battery system.
- B. **Battery**: Upon failure of the AC input source, the critical load continues being supplied by the output inverter, which derives its power from the battery system. There is no interruption in power to the critical load during both transfers to battery operation and retransfers from battery to normal operation.
 - 1. The UPS battery system is comprised of battery modules. Replacement batteries are user-replaceable, hot-swappable replacement battery cartridges (RBCs).
 - 2. For 15 kVA and 20 kVA models, a minimum of one battery pack (4 RBCs) must be installed, providing \pm 192 VDC nominal DC bus rail.
 - 3. Each RBC provides 96 VDC.
 - 4. The batteries of the UPS models in this specification are maintenance-free, leak-proof, valve-regulated lead-acid (VRLA) batteries with suspended electrolyte.
 - 5. The UPS incorporates the Intelligent Battery Management system to continuously monitor the health of each removable battery module as well as external battery packs installed in extended run battery cabinets. This system notifies the user in the event that a failed or weak battery module is found.
 - 6. Additional battery packs may be added to increase runtime. The battery packs and the battery modules within them are hot-pluggable, allowing for easy and quick installation or replacement without the need for electrical wiring, electrician services, or powering down of the UPS. The maximum number of external battery packs that may be connected to the UPS is 4 for all units
 - 7. The UPS is shipped with battery modules preinstalled but disconnected.
- C. **Charging:** Upon restoration of the AC input source, the UPS simultaneously recharges the battery and provides regulated power to the critical load.
 - 1. The intelligent battery management system contains a temperature monitoring circuit and compensation algorithm that regulates the battery charging current and voltage so as to optimize battery life.
 - 2. The battery charging circuit remains active when in bypass and online states.

- 3. The UPS can be restarted immediately after a prolonged power outage without waiting for the battery to be recharged.
- D. Bypass: The system automatic bypass provides a transfer of the critical load from the Inverter output to the automatic bypass input source during times when the inverter cannot support the load. Such times may be due to prolonged or severe overloads or to UPS failure. The UPS constantly monitors the output current as well as the bypass source voltage and inhibits potentially unsuccessful transfers to automatic bypass from taking place. The design of the automatic bypass switch power path consists of a bypass relay for 15 kVA and 20 kVA models.
 - 1. Automatic Transfers: An automatic transfer of load to bypass takes place whenever the load on the critical bus exceeds the overload rating of the UPS. Automatic transfers of the critical load from bypass back to normal operation take place when the overload condition is removed from the critical bus output of the system. Automatic transfers of load to bypass also take place if for any reason the UPS cannot support the critical bus.
 - 2. **Manual Transfers:** Manually initiated transfers to and from bypass may be initiated by the user display interface.

2.3 INPUT PFC POWER STAGE

- A. **General:** The input PFC power stage of the UPS constantly rectifies the power imported from the mains input of the system, converting input mains AC power to DC power for precise regulation of the DC bus voltage, battery charging, and output power stage (inverter) regulated output power.
- B. **Input Current Total Harmonic Distortion:** The input current THDI will be held to 4% at 50% Resistive load and 3% at full Resistive load for the 15 kVA and 20 kVA models while providing conditioned power to the critical load bus and charging the batteries under steady-state operating conditions. This will be accomplished with no additional filters, magnetic devices, or other components.

C. Input Current Limit:

- 1. The input converter controls and limits the input current draw from utility to 150% of the UPS output. During conditions where input current limit is active, the UPS is able to support 100% load, charge batteries at 20% of the UPS output rating, and provide voltage regulation with mains deviation of up to +/-20% of the nominal input voltage.
- 2. In cases where the source voltage to the UPS is nominal and the applied UPS load is equal to or less than 100% of UPS capacity, input current will not exceed 130% of UPS output current, while providing full battery recharge power and importing necessary power for system losses.

D. Charging:

- The battery charging circuit contains a temperature compensation circuit, which shall regulate the battery charging to optimize battery life.
- 2. The battery charging circuit remains active when in bypass and in normal operation.

2.4 OUTPUT POWER STAGE (INVERTER)

- A. **General:** The UPS output power stage (inverter) constantly recreates the UPS output voltage waveform by converting the DC bus voltage to AC voltage through a set of IGBT-driven power converters. In both normal operation and battery operation, the output power stage (inverter) creates an output voltage independent of the mains input voltage. Input voltage anomalies such as brown-outs, spikes, surges, sags, and outages shall not affect the amplitude or sinusoidal nature of the recreated output voltage sine wave of the output power stage (inverter).
- B. **Overload Capability:** As the details listed on page 4.
- C. **Output Contactor:** The output power stage (inverter) is equipped with an output mechanical contactor to provide physical isolation of the inverter from the critical bus. With this feature a failed inverter will be removed from the critical bus.
- D. **Battery Protection:** The inverter is provided with monitoring and control circuits to limit the level of discharge on the battery system.

2.5 DISPLAY AND CONTROLS

- A. **Control Logic:** The UPS is controlled by an embedded microcontroller which performs the following functions:
 - 1. Monitoring the quality of the output voltage.
 - 2. Monitoring vital parameters of the UPS.
 - 3. Executing the state machine.
 - 4. Controlling the input and output power stage
 - 5. Remaining runtime calculation.
 - 6. Self-diagnostics, self-test, and proactive fault detection.
 - 7. Communication to the Network Management Card or another SmartSlot accessory card, if the UPS is equipped with such a card.
- B. **Display Interface**: Located on the front of the UPS is an LCD user display comprised of a graphical, high resolution (2.3"x1.7") LCD (320 x 240 Pixels) and 5 pushbutton switches.
 - 1. **Orientation:** The LCD display may be turned 90 degrees clockwise or counterclockwise to accommodate the mounting orientation of the UPS as a tower UPS or as a rack-mounted UPS.
 - 2. **Control Functions:** The following control functions can be accomplished by use of the pushbutton switches.
 - a. POWER ON/OFF button.
 - b. Escape button.
 - c. OK button.
 - d. Up button.
 - e. Down button.
- C. **Data displayed on the Display Interface:** The following indicators are available on the Display Interface Unit:
 - 1. Load icon and disable/mute audible alarm icon.
 - 2. The UPS status information (Input and Output Voltage, Output Frequency, Load, and Runtime).
 - 3. Operation mode icons (On-Line mode, Bypass mode, Green mode, and Battery mode)
 - 4. Battery status icons.
 - 5. Outlet group status icons.
 - Backlight screens: Amber is an indication that requires attention and Red indicates a UPS alarm that requires immediate attention.
- D. **EPO switch:** All UPS models documented in this specification are equipped with an Emergency Power Off (EPO) terminal that can be wired so as to provide the means to instantaneously de-energize the UPS and its load from a remote location in case of emergency. The UPS can accept normally closed (NC) contacts and normally open (NO) contacts.
- E. **Maintenance Bypass Signal (MBS):** All UPS models documented in this specification are equipped with **Maintenance Bypass Signal (MBS)** terminal that can be wired so as to provide the means to instantaneously turn the UPS to bypass mode from a remote location during times where maintenance or service of the UPS is required. The UPS can accept normally closed (NC) contacts.
- F. **Parallel Port:** Parallel communication port. When UPS models operates at parallel mode, connect parallel cables (supplied) between the models. There would be 4 models run in parallel at most.
- G. **Audible Alarms:** Using audio signal, the UPS will notify the user about important events. The following is the list of distinct audio alarms:
 - 1. The UPS is on battery.
 - 2. The UPS is on battery and the remaining battery capacity is low.
 - 3. The UPS has shut down due to low battery capacity.
 - 4. The battery needs to be replaced.
 - 5. The UPS is overloaded.
 - 6. The UPS is in fault state.
- H. **Potential Free (Dry) Contacts:** The following potential free contacts are available on an optional APC SmartSlot Relay I/O Card:
 - 1. The UPS is on battery.

- 2. The UPS is on battery and the remaining battery capacity is low.
- 3. The UPS is off.
- 4. The battery needs to be replaced.
- 5. The UPS is in bypass.
- 6. The UPS is overloaded.
- 7. The UPS is in fault state.
- Communication Interface: For purposes of remote communications with the UPS the following are available and contained within the UPS:
 - 1. All models have a serial port (RJ45), USB (Type B), and a Smart-Slot which can accommodate additional optional communication accessories.

2.6 BATTERY

- A. The UPS battery is of modular construction made up of owner-replaceable, hot-swappable, fused, battery modules. Each battery module is monitored to determine the highest battery unit temperature for use by the UPS battery diagnostic and by the temperature compensated charger circuitry.
- B. The batteries are of the valve regulated lead acid (VRLA) type.

2.7 Smart Battery Management

- A. Definitions:
 - 1. Battery Module: A string of battery cells arranged to produce a battery assembly with a connector.
 - 2. Replacement Battery Cartridge (RBC): An APC battery cartridge consisting of two battery modules.
 - 3. Replacement RBCs can be ordered from the APC web site, www.apc.com.
 - 4. Smart External Battery Pack (XLBP): An enclosure that contains RBC(s).

NOTE: Do not use a battery that is not APC-approved.

The system will not detect the presence of a non-APC-approved battery, and such a battery may adversely affect the operation of the system. Use of a non-APC-approved battery will void the manufacturer warranty.

- B. Features:
 - 1. Monitors and shows on the UPS Display Interface screen the date for the end of useful life for battery pack.
 - 2. Emits an alarm and shows a message on the UPS Display Interface screen to indicate the estimated battery end of life. On the UPS Display Interface screen the user can set the number of days before the alarm is heard and the message appears on the UPS Display Interface screen.
 - 3. Users need to manually set the number of XLBPs.
 - 4. Monitors the internal temperature of XLBP and automatically adjusts the battery charging.

C. Maintenance:

- RBC maintenance: The APC RBC uses sealed lead acid battery cells and does not require maintenance.
- 2. Runtime Test (Calibration): This should be performed anytime the steady state load is changed significantly, for example when a new server is added to or removed from the UPS load.
- 3. Battery health monitoring: The battery energy output and voltage are monitored to assess the health of the installed batteries when the UPS is operating on battery.
- Battery health monitoring is done during a UPS Self Test, during a Runtime Calibration Test, and when the UPS is operating on battery power. The UPS can be configured to perform periodic, automatic Self Tests.

D. End of useful life

- Near end of life notification: A warning message will appear on the UPS display interface screen
 when battery pack is approaching the end of its useful life. For configuration details refer to
 Replacement Notification Time and Replacement Battery Alarm Time. The estimated replacement
 date for each RBC is available through the UI.
- Needs replacement notification: The UPS display interface screen shows when RBC replacement is required. The RBC must be replaced as soon as possible. When an RBC requires replacement, the UPS display interface may recommend that additional RBCs be replaced if they will soon reach the end of their useful life.
 - CAUTION: Continued operation after end of useful life notification may cause damage to the batteries.
- 3. Recycling: Remove the RBC from the XLBP. Recycle the RBC. Do not disassemble an RBC.

2.8 ACCESSORIES

A. Software and Connectivity:

- 1. **Network Management Card:** The Network Management Card allows one or more network management systems (NMSs) to monitor and manage the UPS in TCP/IP network environments. The Network Management Card 3 with Environmental Monitoring (AP9641) is available on 15kVA to 20kVA units.
- 2. **Unattended Shutdown:** The UPS, in conjunction with a network interface card, is capable of gracefully shutting down one or more operating systems during the time when the UPS is in onbattery mode. PowerChute Network Shutdown software is provided with the Network Management Card.
- B. **Remote UPS Monitoring:** The following three methods of remote UPS monitoring are available:
 - 1. **Web Monitoring:** Remote monitoring is available via a web browser such as Internet Explorer.
 - 2. **Dry Contact Monitoring and Control:** The UPS must be equipped with the APC SmartSlot Relay I/O Card to implement this type of monitoring.
- C. Software Compatibility: Please refer to the APC web site for latest software compatibility listings.
 - 1. **PowerChute Network Shutdown:** This software is provided with the Network Management Card 3 with Environmental Monitoring (AP9641) for all models. It is compatible with the following operating systems.
 - a. IBM AIXTM
 - b. HP/UX
 - c. Linux
 - d. Mac OS X
 - e. Solaris
 - f. Windows® 7
 - g. Windows® 10
 - h. Windows Server 2012
 - i. Windows Server 2016
 - j. Windows Server 2019
 - k. Windows Storage Server 2016
 - I. Microsoft Hyper-V Server 2016
 - m. Microsoft Hyper-V Server 2019
 - n. Microsoft SCVMM 2016
 - o. VMware ESXi

PART 3 - EXECUTION

3.1 FACTORY-ASSISTED STARTUP

If a factory-assisted UPS start-up is requested, factory-trained service personnel will perform the following inspections, test procedures, and on-site training.

A. Visual Inspection:

- 1. Inspect equipment for signs of damage.
- 2. Verify installation per manufacturer's instructions.
- 3. Inspect battery modules.

B. Mechanical Inspection:

- 1. Check all UPS and external service bypass panel internal power wiring connections.
- 2. Check all UPS and external service bypass panel terminal screws, nuts, and/or spade lugs for tightness.

C. **Electrical Inspection:**

- 1. Verify correct input and bypass voltage.
- 2. Verify correct UPS control wiring and terminations.
- 3. Verify voltage of all battery modules.
- 4. Verify that neutral and ground conductors are properly landed.

5. Inspect external service bypass panel for proper terminations.

D. Site Testing:

- 1. Ensure proper system start-up.
- 2. Verify proper firmware control functions.
- 3. Verify proper firmware bypass operation.
- 4. Verify proper bypass switch operation (where applicable).
- 5. Verify proper inverter operation and regulation circuits.
- 6. Simulate utility power failure.
- 7. Verify proper charger operation.
- 8. Document, sign, and date all test results.
- E. **On-Site Operational Training:** During the factory-assisted start-up, operational training for site personnel includes User Display Interface, Menu overview, start-up and shutdown procedures, maintenance bypass and AC disconnect operation, and alarm information.

3.2 FIELD QUALITY CONTROL

A. Manufacturer Field Service:

- Worldwide Service: The UPS manufacturer has a worldwide service organization available, consisting of factory-trained field service personnel to perform start-up, preventive maintenance, and service of the UPS system and power equipment. The service organization offers service support 24 hours a day, 7 days a week, 365 days a year.
- 2. **Replacement Parts**: Parts are available through the worldwide service organization 24 hours a day, 7 days a week, 365 days a year. The worldwide service organization is capable of shipping parts within four working hours or on the next available flight, so that the parts may be delivered to the customer site within 24 hours.

3.3 MAINTENANCE

A. A complete offering of preventative and full service maintenance contracts for the UPS system and the battery system are available from APC by Schneider Electric. Contract work is performed by Schneider Electric factory-trained service personnel.

END OF GUIDE SPECIFICATION

Revision 2: Jan. 2021