

Network Management Card 2 (NMC2) for Modular PDU

PDPM72F-5U, PDPM138H-5U, PDPM144F, PDPM138H-R, PDPM277H, PDPM288G6H

What’s in This Document

Schneider Electric Device IP Configuration Wizard..... 1

Affected Revision Levels 1

AOS & TCP/IP Stack Modifications (apc_hw05_aos_664.bin).....2

Modular Power Distribution Unit Application (apc_hw05_xrdp2g_664.bin)3

Miscellaneous.....3

Schneider Electric Device IP Configuration Wizard

The Device IP Configuration Wizard is a Windows application designed specifically to remotely configure the basic TCP/IP settings of Network Management Cards. The Wizard runs on Windows® 2000, Windows Server 2003, Windows Server 2012, and, on 32- and 64-bit versions of Windows Vista, Windows XP, Windows Server 2008, Windows 7, Windows 8, and Windows 10 operating systems. This utility supports cards that have firmware version 3.X.X or higher and is for IPv4 only. The Wizard is available as a free download from the APC web site at www.apc.com:

1. Go to www.apc.com/tools/download and select **Software Upgrades > Wizards and Configurators** from the **Filter by Software/Firmware** drop-down list.
2. Click **Submit** to view the list of utilities available for download.
3. Click on the **Download** button to download the **Device IP Configuration Wizard**.

Affected Revision Levels

File	Detail
apc_hw05_aos_664.bin	Network Management Card Operating System & TCP/IP Stack for Hardware Platform version 05
apc_hw05_xrdp2g_664.bin	Modular Power Distribution Application
powernet428.mib	PowerNet(R) SNMP Management Information Base (MIB)

For details on upgrading the network management card firmware, see the user's guide on the utility CD or on the APC web site (www.apc.com).

AOS & TCP/IP Stack Modifications (apc_hw05_aos_664.bin)

Compatibility

apc_hw05_xrdp2g_664.bin	Modular Power Distribution Application xrdp2g
powernet428.mib	PowerNet(R) SNMP Management Information Base (MIB)

Known Issues in This Version

1. Disabling an individual event for email notification may cause an unexpected network interface restart.
2. When using Syslog TCP, there is no line break at the end of the payload message.
3. SNMPv3 communication and monitoring on some third party SNMP management tools such as ManageEngine OpManager does not work properly.
4. Modifying RADIUS settings via config.ini may cause an unexpected network interface restart.
5. IPv6 connectivity outside of local subnet does not work in all environments.
6. The NMC may experience an unexpected network interface restart while editing a firewall policy.
7. Modifying large groups of event actions by severity may cause an unexpected network interface restart .
8. NMC display reboots automatically, when the laptop which is used to connect the UPS tuner to the product comes out of sleep mode.

New Features and Enhancements

1. NMC Security Wizard Command Line Interface (CLI) Utility. Soon-to-release updated tool with CLI-only interface and security enhancements.
2. ROBOT Vulnerability Mitigation. Added support for ROBOT TLS vulnerability mitigation using new 'cipher' CLI command or INI configuration option.

NOTE: This mitigation is not compatible with some web browsers.

Bugs Fixed in This Version

1. Fixed issue which prevented NMC from accepting SSL/TLS certificates issued by third party Certificate Authorities such as Microsoft Certificate Services, especially those using custom certificate templates.
2. Fixed an issue which caused a blank white screen for some users caused by an abnormally large number of cookies present in the web browser client accessing the NMC.

Modular Power Distribution Unit Application (apc_hw05_xrdp2g_664.bin)

Compatibility

apc_hw05_aos_664.bin	Network management card OS & TCP/IP Stack
powernet428.mib	PowerNet(R) SNMP Management Information Base (MIB)

See *AOS & TCP/IP Stack Modifications (apc_hw05_aos_664.bin)*, page 2 for a list of modifications and enhancements that affect this application version.

Known Issues in This Version

None.

New Features and Enhancements

None.

Bugs Fixed in This Version

None.

Miscellaneous

Recovering From a Lost Password

See the User's Guide on the Utility CD or on the APC Web site (www.apc.com) for instructions on how to recover from a lost password.

Event Support List

For the event names and event codes for all events supported for a currently connected APC device, first retrieve the Config.ini file from a configured network management card.

To use FTP to retrieve the Config.ini file from a configured network management card:

1. Open a connection to the network management card, using its IP Address:
ftp> open <ip_address>
2. Log on using the Administrator user name and password.
3. Retrieve the Config.ini file containing the settings of the network management card of the UPS.
ftp> get config.ini.

The file is written to the folder from which you launched FTP.

In the Config.ini file, find the section heading [EventActionConfig]. In the list of events under that section heading, substitute 0x for the initial E in the code for any event to obtain the hexadecimal event code shown in the user interface and in the documentation.

For example, the hexadecimal code for the code E0033 in the Config.ini file (for the event "System: Configuration change") is 0x0033.

Powernet MIB Reference Guide

NOTE: The MIB Reference Guide, available on the network management card CD and on the APC Web site (www.apc.com), explains the structure of the MIB, types of OIDs, and the procedure for defining trap receivers. For information on specific OIDs, use a MIB browser to view their definitions and available values directly from the MIB itself. You can view the definitions of traps at the end of the MIB itself (the file powernet428.mib on the network management card CD and also downloadable from the APC Web site, www.apc.com).

HASH Signatures

Add Hash Signatures as follows ,

MD5 Hash: 75800c5bcefe248ec6bee89e0c703958

SHA-1 Hash: d3c328082d9c3169fb58c52d76ce76ac7c62d1b5

SHA-256 Hash:

1034613ca0768628bf81f737806ff64aad93f3acfb3889f3e8535ff2624f6f32