


XBT-K8 Display terminal

UNI-TE[®] Protocol

User Guide 1990



WARNING

Four modes of operation are incorporated in the XBT-K8 display terminal :

- ASCII mode : used by all programmable systems,
- ADJUSTMENT protocol : used with the terminal port on TSX7,
- Parallel link : used with all logic systems.

For these 3 types of operation, see user guide XBTX-K700E.

- UNI-TE protocol : used when the XBT-K8 is connected to the UNI-TELWAY bus described in this manual.

REGISTERED TRADEMARKS

UNI-TE and UNI-TELWAY are registered trademarks of Telemecanique
PS/2 is a registered trademark of IBM Corporation



WARNING

UNINTENDED EQUIPMENT OPERATION

Do not use XBT terminals to directly manipulate outputs in applications where loss of communication can result in loss of machine or process control.

Failure to observe this warning can cause equipment damage or severe personal injury.

Index

Chapter	Page
1 Description	
1.1 General	3
1.2 Introduction to the XBT-K8 industrial displays	4
2 Technical characteristics	
2.1 Enviromental characteristics	7
2.2 Mechanical characteristics	7
2.3 Mounting	9
2.4 Electrical characteristics	10
3 Selecting the operating modes	
3.1 Selecting with the connector	12
3.2 Selecting manually	13
3.3 Selecting by command	16
4 Storing the messages	
4.1 Storing syntax	18
4.2 Storing the messages with a PC, PS/2	22
5 Communication	
5.1 General	23
5.2 Operation	25
5.3 UNI-TE requests	29
5.4 General usage requests	30
5.5 Requests to access XBT-K resources	35
5.6 Requests to access the message segment in the XBT-K8	43
5.7 Uploading and downloading the memory area	46
5.8 Requests used by the XBT-K8 CLIENT	57
5.9 Review of UNI-TE requests	58

Index

Chapter	Page
6 Application example	60
7 Connections	
7.1 Pin connections for the connectors	66
7.2 Connections for a PC, PS/2	68
7.3 Connections for the UNI-TELWAY bus	69
7.4 Connections for the parallel bus	72
8 Self-tests	
8.1 Automatic self-tests	73
8.2 Controlled self-tests	74
9 Error messages	
9.1 Messages displayed on the XBT-K8	76
9.2 Special messages for the XBT-K8	77
10 Appendix	
10.1 XBT-K message definition table	78
10.2 ASCII character table	79
10.3 Display character table	80