



EAV9613609

Easy Altivar ATV310 complete parameters list

ENGLISH

Reference menu	Reference mode 402 External reference value 403 Integrated display jog dial reference 801 Speed reference 59.11 Internal PID reference 806 PID reference value
Monitoring parameter	Monitoring mode 402 External reference value 403 Integrated display jog dial reference 801 Speed reference 802 Output frequency 803 Motor current 804 PID error 805 PID Feedback 806 PID reference 807 Main voltage 808 Motor thermal state 809 Drive thermal state 810 Output power
Drive status	811 Product status [-00] Drive ready [-01] Drive running [-02] Acceleration [-03] Deceleration [-04] DC injection braking in progress [-05] Current limitation state [-06] Freewheel stop control or freewheel state [-07] Auto-adapted deceleration [-08] Controlled stop on mains phase loss [-09] Auto-tuning in progress [-10] Fast stop state [-11] No line power state [-12] Drive in back state [-13] Remote control mode [-14] Local control mode
Maintenance menu	900- MAINTENANCE MENU 901 State of logic inputs L11 to L14 902 State of the logic output LO1 and relay R1 903 Display of high speed value 904 Drive Power rating 037 075 U15 U22 U30 U40 U55 U75 D11 D15 D18 D22 905 Drive voltage rating N4 906 Specific Product Number 907 Card 1 Software Version 908 Card 2 Software Version 909 Run elapsed time display 910 Power On time display 911 Fan time display 912 Process Elapsed time 913 Modbus communication status 914 Last fault 1 915 State of drive at fault 1 916 Last fault 2 917 State of drive at fault 2 918 Last fault 3 919 State of drive at fault 3 920 Last fault 4 921 State of drive at fault 4 999 HMI Password F000 Fault list F001 Precharge F002 Unknown drive rating F003 Unknown or incompatible power board F004 Internal serial link

Detected fault codes	F005 Invalid industrialization zone F006 Current measurement circuit F007 Internal thermal sensor fault F008 Internal CPU F009 Overbraking F010 Overcurrent F011 Drive overheat F012 Process overload F013 Motor overload F014 1 Output phase loss F015 3 Output phases loss F016 Main overvoltage F017 Input phase loss F018 Motor short-circuit F019 Ground short-circuit F020 IGBT short circuit F021 Load short circuit F022 Modbus interruption F024 HMI communication F025 Overspeed F026 PI feedback fault F027 IGBT overheat F028 Autotuning fault F029 Process underload fault F030 Undervoltage F031 Incorrect configuration F032 Invalid configuration F033 A11 current loss F034 Download invalid configuration F035 Pre-charge resistor protection fault
Short menu	Configuration mode 301 Standard motor frequency [00]* 50Hz IEC [01] 60Hz NEMA 401 Reference channel 1 [01]* Analog terminal [163] Remote display [164] Modbus [183] Integrated display with Jog dial 501.0 Acceleration 0.0 s to 999.9s (3.0s*) 501.1 Deceleration 0.0 s to 999.9s (3.0s*) 512.0 Low speed 0.0Hz to High speed (0Hz*) 512.2 High speed Low speed to Max frequency (50 or 60Hz determined by 301 parameter value) 302 Rated Motor Power Drive power -5 to +2 (Determined by drive rating and dual rating*) 305 Rated motor current (0.25-1.5In) (Determined by drive rating and dual rating*) 204.0 A11 type [5U]* 0-5V [10U] 0-10V [0A] x-y mA [LIU] Logic inputs 101 Store customer parameter set [00]* Disabled [01] Stores current configuration 102 Factory / recall customer parameter set [00]* Disabled [02] Customer configuration [64] Factory set configuration
Macro	COMPLETE MENU 100 Macro-configuration [00]* Start/stop [04] PID regulation [09] Speed
I/O menu	200- I/O MENU 201 Type of control [00]* 2-wire control [01] 3-wire control

I/O menu (cont.)	202 2-wire type control [00] Level [01]* Transition [02] Forward priority 203 Logic inputs type [00]* Positive [01] Negative internal supply [02] Negative external supply 204- A11 CONFIGURATION MENU 204.0 A11 type [5U]* Voltage: 0-5Vdc [10U] Voltage: 0-10Vdc [0A] Current: x-y mA [LIU] Logic inputs 204.1 A11 current scaling parameter of 0% 0-20mA (4mA*) 204.2 A11 current scaling parameter of 100% 0-20mA (20mA*) 204.3 A11 filter time 0 s to 10 s (0 s*) 205- R1 CONFIGURATION MENU 205.0 R1 assignment [00] Not assigned [01]* No fault [02] Drive run [04] Frequency threshold reached [05] HSP reached [06] I threshold reached [07] Frequency reference reached [08] Motor thermal reached [21] Process underload fault [22] Process overload fault [123] Loss of 4-20mA signal 205.1 R1 status (output active level) [00]* Positive logic : active high [01] Negative logic: active low 206- LO1 CONFIGURATION MENU 206.0 LO1 Assignment [00]* Not assigned [01] No fault [02] Drive run [04] Frequency threshold reached [05] HSP reached [06] I threshold reached [07] Frequency reference reached [08] Motor thermal reached [21] Process underload fault [22] Process overload fault [123] A11 alarm 4-20mA [126] Auxiliary pump active 206.1 LO1 status (output active level) [00]* Positive logic : active high [01] Negative logic: active low 207 Process overload time delay 0 to 100 s (0 s*) 208 Process overload threshold 70 to 150% of nominal motor current (90%*) 209 Process overload fault duration 0 to 6 min (0 min*) 210 Process underload time delay 0 to 100 s (0 s*) 211 Process underload threshold 20 to 100% of nominal motor current (60%*) 212 Process underload fault duration 0 to 6min (0min*) 213 Motor frequency threshold 0 to 400Hz (50Hz* or 60Hz) 214 Motor current threshold 0 to 1.5In (In*) 215 Motor thermal state threshold 0 to 118% of motor thermal state (100%*) 216.0 AO1 assignment [00]* Not assigned [129] Motor current [130] Output frequency [131] Ramp output
------------------	---

I/O menu (cont.)	[135] PID reference [136] PID feedback [137] PID error [139] Output power [140] Motor thermal state [141] Drive thermal state 216.1 AO1 type [10U] Voltage: 0-10 Vdc [0A]* Current: 0-20 mA [4A] Current: 4-20 mA 217 Speed Template [BSD]* Standards [BLS] Pedestal [BNS] Deadband [BNSO] Deadband at 0% 300- MOTOR CONTROL MENU 301 Standard motor frequency [00]* 50Hz [01] 60Hz 302 Rated motor power Drive power -5 to +2 (Determined by drive rating and dual rating*) 303 Rated motor cos phi 0.5 to 1 (Determined by drive rating and dual rating*) 304 Rated motor voltage 360 to 460V (380V*) 305 Rated motor current 0.25 to 1.5In (Determined by drive rating and dual rating*) 306 Rated motor frequency 10 to 400Hz (50Hz*) 307 Rated motor speed 0 to 24000rpm (Determined by drive rating and dual rating*) 308 Maximum frequency 10 to 400Hz (60Hz*) 309 Motor control type [00] Performance: Vector control [03]* Standard: U/F 2 points [06] Pump: U/F 310 IR compensation 25 to 200% (100%*) 311 Slip compensation 0 to 150% (100%*) 312 Frequency loop stability 0 to 100% (20%*) 313 Frequency loop gain 0 to 100% (20%*) 314 Flux Profile 0 to 100% (20%*) 315 Switching frequency 2 to 12kHz (4kHz*) 317 Motor noise reduction [00]* No [01] Yes 318 Auto-tuning [00]* No: Use factory parameters of standard motors [01] Yes: Request auto-tuning [02] Done: Auto-tuning has already been performed 319 Motor parameter choice [00]* Nominal motor power [01] Nominal motor cos phi 320 Vector control 2 points [00]* No [01] Yes 321 Max voltage of constant power Rated motor voltage to 460V (380V*) 322 Max frequency of constant power Rated motor frequency to 400Hz (50Hz*) 323 Dual Rating [00] Normal duty [01]* Heavy duty
Motor control menu	
Function / Ramp menu	
Function / Stop configuration menu	

Control menu	400- CONTROL MENU 401 Reference channel 1 [01]* Analog terminal [163] Remote display [164] Modbus [183] Integrated display with Jog dial 402 External reference value -400 to 400Hz 403 Integrated display jog dial reference 0 to 100% 404 Reverse inhibition [00]* No [01] Yes 405 Stop key priority [00] No: Stop inactive [01]* Yes: Stop active 406 Channel configuration [01]* Combined mode [02] Separate mode 407 Command channel 1 [01]* Terminals [02] Integrated display [03] Remote display [10] Modbus 408 Forced local assignment [00]* No: Function inactive [L1H] L11 active High [L2H] L12 active High [L3H] L13 active High [L4H] L14 active High [LUH] LIU active High 409 Forced local reference [00]* Not assigned [01] Analog terminal [163] Remote display [183] Integrated jog dial 410 Forced local command [01] Terminals [02]* Integrated display [03] Remote display
Function / Ramp menu	500- FUNCTION MENU 501- RAMP MENU 501.0 Acceleration 0.0 to 999.9s (3.0s*) 501.1 Deceleration 0.0 to 999.9s (3.0s*) 501.2 Ramp shape assignment [00]* Linear [01] S shape [02] U shape 501.3 Ramp switching commutation [00]* Not assigned [L1H] to [L4H] L11 to L14 active High [LUH] LIU active High [L1L] to [L4L] L11 to L14 active Low [LUL] LIU active Low 501.4 Acceleration 2 0.0 to 999.9s (5.0s*) 501.5 Deceleration 2 0.0 to 999.9s (5.0s*) 501.6 Decel Ramp Adaptation assignment [00] Function deactivated [01]* Function activated [02] Motor brake 502- STOP CONFIGURATION MENU 502.0 Type of stop [00]* Ramp stop [03] DC injection stop [08] Fast stop [13] Free wheel stop 502.1 Freewheel stop assignment [00]* Not assigned [L1L] to [L4L] L11 to L14 active Low to stop [LUL] LIU active Low to stop 502.2 Fast stop assignment [00]* Not assigned [L1L] to [L4L] L11 to L14 active Low to stop [LUL] LIU active Low to stop 502.3 Ramp divider 1 to 10 (4*)

The (*) indicates a parameter factory setting.

Easy Altivar ATV310 complete parameters list

Function / Stop configuration menu	502.4 DC injection assignment [00]* Not assigned [L1H] to [L4H] L1 to L14 active High [LUH] LIU active High
	502.5 DC injection level 0.1 to 1.41In (0.64 In*)
Function / reverse direction	502.6 IDC injection time for DCIL 0.1 to 30 s (0.5 s*)
	502.7 DC injection level 2 0.1In to DC injection level (0.5 In*)
DC injection function	502.8 Injection standstill braking time 0.1 to 30 s (0.5 s*)
	503 Reverse direction [00]* Not assigned [L1H] to [L4H] L1 to L14 active High [LUH] LIU active High
Jog function	504- AUTO DC INJECTION MENU
	504.0 Automatic DC injection [00] Function inactive, no DC injected current. [01]* Time limited DC injection [02] Continuous DC injection
Motor potentiometer function	504.1 Automatic DC injection current 0 to 120% of nominal motor current (70%*)
	504.2 Automatic DC injection time 0.1 to 30s (0.5s*)
Preset speed function	505.0 Jog assignment [00]* Not assigned [L1H] L1 active High [L2H] L2 active High [L3H] L3 active High [L4H] L4 active High [LUH] LIU active High
	505.1 Jog frequency 0 to 10Hz (*5Hz)
Current limitation function (cont.)	506- Speed up and down
	506.0 Up speed command [00]* Not assigned [L1H] to [L4H] L1 to L14 active High [LUH] LIU active High
Speed limitation function	506.1 Down speed command [00]* Not assigned [L1H] to [L4H] L1 to L14 active High [LUH] LIU active High
	506.2 Store [00]* No [01] RAM [02] ROM
Phase loss	506.3 Clear the function [00]* Not assigned [L1H] to [L4H] L1 to L14 active High [LUH] LIU active High [159] Acceleration and deceleration with command active high
	506.4 Reactivity of +/- speed around ref. 0 to 100% (0%*)
Undervoltage	507- PRESET SPEED MENU
	507.0 2 Preset speeds [00]* Not assigned [L1H] L1 active High [L2H] L2 active High [L3H] L3 active High [L4H] L4 active High [LUH] LIU active High
Degr. line	507.1 4 Preset speeds same as 2 Preset speeds
	507.2 8 Preset speeds same as 2 Preset speeds
Reset power run	507.3 Preset speed 2 0 to 400Hz (10Hz*)
	507.4 Preset speed 3 0 to 400Hz (15Hz*)
Communication menu	507.5 Preset speed 4 0 to 400Hz (20Hz*)

Preset speed function	507.6 Preset speed 5 0 to 400Hz (25Hz*)
	507.7 Preset speed 6 0 to 400Hz (30Hz*)
Jump frequency	507.8 Preset speed 7 0 to 400Hz (35Hz*)
	507.9 Preset speed 8 0 to 400Hz (40Hz*)
PID Control function	508 Skip frequency 0 to 400Hz (0Hz*)
	509- PID MENU
PID / Pump management function	509.00 PID feedback assignment [00]* Not assigned [01] Analog terminal
	509.01 PID proportional gain 0.01 to 100 (1*)
Speed limitation function	509.02 PID integral gain 0.01 to 100 (1*)
	509.03 PID derivative gain 0.00 to 100.0 (0*)
Motor thermal protection	509.04 PID feedback scale factor 0.1 to 100.0 (1.0*)
	509.05 Activation internal PID reference [00]* No [01] Yes
Current limitation function	509.06 2 preset PID assignment [00]* Not assigned [L1H] L1 active High [L2H] L2 active High [L3H] L3 active High [L4H] L4 active High [LUH] LIU active High
	509.07 4 preset PID assignment [00]* Not assigned [L1H] L1 active High [L2H] L2 active High [L3H] L3 active High [L4H] L4 active High [LUH] LIU active High
Phase loss	509.08 2 preset PID reference 0 to 100% (25%*)
	509.09 3 preset PID reference 0 to 100% (50%*)
Undervoltage	509.10 4 preset PID reference 0 to 100% (75%*)
	509.11 Internal PID reference 0 to 100% (0%*)
IGBT	509.12 PID reference ramp 0 to 99.9s (0s*)
	509.13 PID min value reference 0 to 100% (0%*)
Degr. line	509.14 PID max value reference 0 to 100% (100%*)
	509.15 PID predictive speed 0.1 to 400Hz (0.0*)
Communication menu	509.16 PID correction reverse [00]* No, no negative speed [01] Yes, no negative speed [02] No, allow negative speed [03] Yes, allow negative speed
	509.17 PID auto/manual assignment [00]* Not assigned [L1H] to [L4H] L1 to L14 active High [LUH] LIU active High
Reset power run	509.18 PID manual reference [00]* No [01] Analog terminal [183] Integrated display with Jog dial
	512.1 Low speed operating time 0.1 to 999.9s (0s*)
Speed limitation function	509.19 PID: wake up level 0 to 100% (0%*)
	509.20 PID: Wake up threshold 0 to 100% (0%*)

PID Control function (cont.)	59.21 Sleep offset threshold 0 to High speed (0Hz*)
	59.22 PID feedback supervision threshold 0 to 100% (0%*)
PID / Pump management function	59.23 PID supervision function time delay 0 to 600s (0s*)
	59.24 Maximum frequency detection Hysteresis 0 to High speed (0Hz*)
Current limitation function	59.25 PID feedback supervision [01]* Free wheel [04] Fallback speed
	59.26 Fallback speed 0 to High speed (0Hz*)
Speed limitation function	510- PUMP SUB-MENU
	207 Process overload time delay 0 to 100 s (0 s*)
Motor thermal protection	208 Process overload threshold 70 to 150% of nominal motor current (90%*)
	209 Process overload fault duration 0 to 6 min (0 min*)
Phase loss	210 Process underload time delay 0 to 100 s (0 s*)
	211 Process underload threshold 20 to 120% of nominal motor current (60%*)
Undervoltage	212 Process underload fault duration 0 to 6min (0min*)
	510.0 Selecting operating mode [00]* Single frequency conversion mode [01] Single frequency conversion combined with auxiliary pump mode
IGBT	510.1 Starting frequency of the auxiliary pump 0 to Maximum frequency (50Hz*)
	510.2 Time delay before starting auxiliary pump 0 to 999.9s (2s*)
Degr. line	510.3 Auxiliary pump ramp reaching 0 to 999.9s (2s*)
	510.4 Auxiliary pump stop frequency 0 to Maximum frequency (0Hz*)
Communication menu	510.5 Auxiliary pump stop time delay 0 to 999.9s (2s*)
	510.6 Auxiliary pump stop ramp 0 to 999.9s (2s*)
Reset power run	510.7 Zero flow detection period 0 to 20min (0min*)
	510.8 Zero flow detection activation threshold 0 to 400Hz (0Hz*)
Speed limitation function	510.9 Zero flow detection offset 0 to 400Hz (0Hz*)
	511- CURRENT LIMITATION MENU
Motor thermal protection	511.0 2nd current limitation commutation [00]* Not activated [L1H] L1 active High [L2H] L2 active High [L3H] L3 active High [L4H] L4 active High [LUH] LIU active High [L1L] L1 active Low [L2L] L2 active Low [L3L] L3 active Low [L4L] L4 active Low [LUL] LIU active Low
	511.1 Current limitation 0.25 to 1.5In (Determined by drive rating and dual rating*)
Phase loss	511.2 Current limitation 2 0.25 to 1.5In (Determined by drive rating and dual rating*)
	512- SPEED LIMIT MENU
Undervoltage	512.0 Low speed 0Hz to high speed (0Hz*)
	512.1 Low speed operating time 0.1 to 999.9s (0s*)

Speed limitation function (cont.)	512.2 High speed Low speed to Max frequency (50 or 60Hz determined by 301 parameter value)
	512.3 2 High speed assignment [00]* Not assigned [L1H] to [L4H] L1 to L14 active High [LUH] LIU active High
Automatic restart after a detected fault	512.4 4 High speed assignment [00]* Not assigned [L1H] to [L4H] L1 to L14 active High [LUH] LIU active High
	512.5 High speed 2 Low speed to Max frequency (50 or 60Hz*)
Degr. line	512.6 High speed 3 Low speed to Max frequency (50 or 60Hz*)
	512.7 High speed 4 Low speed to Max frequency (50 or 60Hz*)
Reset power run	513 Cooling fan control [00] Fan runs when drive runs [01]* Thermal control
	600- FAULT DETECTION MANAGEMENT MENU
Motor thermal protection	601 Detected fault reset assignment [00]* Not assigned [L1H] to [L4H] L1 to L14 active High [LUH] LIU active High
	602- AUTOMATIC RESTART MENU
Phase loss	602.0 Automatic restart [00]* No [01] Yes
	602.1 Max. automatic restart [00]* 5 min [01] 10 min [02] 30 min [03] 1 hour [04] 2 hours [05] 3 hours [06] Infinite
Undervoltage	603 Catch on the fly [00]* Function inactive [01] Function active
	604- MOTOR THERMAL PROTECTION MENU
IGBT	604.0 Motor thermal current 0.2-1.5In (Determined by drive rating and dual rating*)
	604.1 Motor protection type [01]* Self-ventilated [02] Motor-ventilated
Communication menu	604.2 Overload fault management [00] Detected fault ignored [01]* Free wheel stop [08] DC injection stop
	604.3 Motor thermal state memo [00]* thermal state not stored at power off [01] thermal state is stored at power off
Degr. line	605 Output Phase loss [00]* Deactivated [01]* Tripping then freewheel stop
	606 Input Phase loss [00] Detected fault ignored [01]* Detected fault with freewheel stop [08] DC injection stop
Reset power run	607- UNDERVOLTAGE MENU
	607.0 Undervoltage detected fault management [00]* Detected fault and R1 relay set 0 [01] Detected fault and R1 relay set 1
Speed limitation function	607.1 Undervoltage prevention [00]* No action (freewheel) [02] Stop following an adjustable ramp
	607.2 Undervoltage ramp deceleration time 0.0 to 10.0s (1.0s*)
Communication menu	607.3 Precharge resistor protection level 430 to 560 VDC (0 V* with protection removed)
	608 IGBT test [00]* No test [01] Starting test

4-20 mA loss	609 4-20mA loss Behaviour [00]* Detected fault ignored [01] Freewheel stop [08] DC injection stop
	610 Detected fault inhibition assignment [00]* Function inactive [L1H] to [L4H] L1 to L14 active High [LUH] LIU active High
Degr. line	611 Modbus detected fault management [00] Detected fault ignored [01]* Freewheel stop [08] DC injection stop
	612 Degraded line supply operation [00]* No [01] Yes
Reset power run	613 Reset power run [00]* No [03] Reset drive running time [04] Reset power-on time [07] Reset fan operation time
	614 Reset all previous detected faults via Run key of HMI [00]* Deactivated [01] Active
Communication menu	700- COMMUNICATION MENU
	701 Modbus address Off to 247 (off*)
Degr. line	702 Modbus baud rate [24] 4.8 kbps [28] 9.6 kbps [32]* 19.2 kbps [36] 38.4 kbps
	703 Modbus format [02] 8o1 [03]* 8E1 [04] 8n1 [05] 8n2
Reset power run	704 Modbus time out 0.1 to 30s (10s*)
	705- INPUT SCANNER MENU
Communication menu	705.0 Com scanner read address parameter 1 0C81*
	705.1 Com scanner read address parameter 2 219C*
Degr. line	705.2 Com scanner read address parameter 3 0000
	705.3 Com scanner read address parameter 4 0000
Reset power run	706- OUTPUT SCANNER MENU
	706.0 Com scanner write address parameter 1 2135*
Communication menu	706.1 Com scanner write address parameter 2 219A*
	706.2 Com scanner write address parameter 3 0000
Degr. line	706.3 Com scanner write address parameter 4 0000
	707- INPUT SCANNER ACCESS MENU
Reset power run	707.0 Com scanner read address value 1 ETA value*
	707.1 Com scanner read address value 2 RFRD value*
Communication menu	707.2 Com scanner read address value 3 8000
	707.3 Com scanner read address value 4 8000
Degr. line	708- OUTPUT SCANNER ACCESS MENU
	708.0 Com scanner write address value 1 CMD value*
Reset power run	708.1 Com scanner write address value 2 LFRD value*
	708.2 Com scanner write address value 3 8000
Communication menu	708.3 Com scanner write address value 4 8000

The (*) indicates a parameter factory setting.