Specification Sheet schneider-electric.com | 1

STT900 Series

Frost Thermostats





Product Description

The STT900 Series is a mechanical thermostat suitable for use in general ventilation and air conditioning applications, to assist in the prevention of equipment operating exceptions due to frost conditions. Typical applications include air or water-side temperature monitoring of heat exchangers, hot water circulation systems and water / air heaters.

The entire length of the capillary is active and responds to a temperature change over a minimum length of 60 cm (2 ft.). The capillary itself is available in five different lengths, either with automatic reset functionality or mechanical locking and manual reset by push button.

The change-over contact switch can be used to request the switch-off of fans, closure of outside air dampers, the opening of heating valves, enabling of heat pumps, to de-energise refrigeration compressors and humidifiers, or to initiate a visual and / or acoustic frost condition.

Features

- · Transparent cover with inspection window
- · Multiple capillary lengths
- · Water and air applications
- · Manual or automatic reset
- IP65 plastic enclosure

Available Products

Part Number	Model Number	Description	Capillary Length (L)	Reset Function	Permissible Medium
5127040000	STT900	Frost Thermostat	0.6 m (2 ft.)	Automatic	Air
5127010000	STT901	Frost Thermostat	1.8 m (5.9 ft.)	Automatic	Water
5127020000	STT902	Frost Thermostat	3 m (9.8 ft.)	Automatic	Air
5127000000	STT903	Frost Thermostat	6 m (19.7 ft.)	Automatic	Air
5127030000	STT904	Frost Thermostat	12 m (39 ft.)	Automatic	Air
5127090000	STT910	Frost Thermostat	0.6 m (2 ft.)	Manual	Air
5127060000	STT911	Frost Thermostat	1.8 m (5.9 ft.)	Manual	Water
5127070000	STT912	Frost Thermostat	3 m (9.8 ft.)	Manual	Air
5127050000	STT913	Frost Thermostat	6 m (19.7 ft.)	Manual	Air
5127080000	STT914	Frost Thermostat	12 m (39 ft.)	Manual	Air

North America (USA): +1 888 444 1311 Europe, Middle East & Africa (Sweden): +46 10 478 2000 Asia Pacific (Singapore): +65 6484 7877 product.support@schneider-electric.com www.schneider-electric.com



-10 +15 °C (14 59 °F) +5 °C (41 °F)			
10 (6) A at 250 Vac gold-plated switching contacts			
SPDT (change-over)			
2 K ±1 K (3.6 °F ±1.8 °F)			
±0.5 K (±0.9 °F)			
Copper			
R507 refrigerant gas			
0.6 12 m (2 39 ft.)			
60 cm (2 ft.)			
Fixing clamps (included)			
Ambient max.: +70 °C (158 °F) Ambient min.: Setting + minimum 2 °C (3.6 °F) Storage: -30 +70 °C (-22 +158 °F)			
Case: Polyamide (30% glass beads reinforced) Cover: ABS			
IP65			
I (EN 60730-1)			
0.14 2.5 mm ² Screw terminals Cable gland type M16 x 1.5 complete with cable strain relief			
Electromagnetic compatibility: CE conformity according to EN 61326-1, EN 61326-2-3 EU conformity: EMC Directive 2014/30/EU			

Functions

The operating temperature of the change-over contact switch can be adjusted using the rotary dial found beneath the enclosure cover. If desired, this setting can be lead-sealed at the adjustment screw. The temperature is detected over the entire length of the capillary tube. The gas-filled (R507) membrane system and the capillary tube constitute one measuring unit, which is mechanically coupled to the changeover switch.

A frost condition occurs when the temperature falls below the defined set-point over a minimum 60 cm (2 ft.) of the capillary tube length. Frost condition is signified when terminal C and terminal 2 are closed. Normal operation is signified when terminal C and terminal 3 are closed. Terminals 2 and 3 operate simultaneously in a change-over contact switch arrangement. See Figure 1 for switch connection details.

Resetting of a frost condition for models STT90x occurs automatically once the temperature rises above the defined set-point plus the switching hysteresis, whilst models STT91x are mechanically locked and fitted with a manual reset button on the cover of the plastic enclosure.

It is necessary to ensure that the ambient temperature at the enclosure does not fall below the defined temperature setting of the change-over contact switch. The device must also be operated in a non-precipitating, pollutant-free environment.

© 2020 Schneider Electric. All rights reserved. All trademarks are owned by Schneider Electric Industries SAS or its affiliated companies.

The STT900 Series are intrinsically safe devices, such that in the event of the capillary tube membrane becoming damaged, the device automatically switches to a frost condition, i.e. terminals C and 2 are closed.

The capillary tube should be laid at the warm side of the air heater to offer maximum protection. In the case of air coolers the device should be upstream of the air cooler. It should be fitted uniformly over the entire duct area at a distance of approximately 5 cm across the heat exchanger tubes





Figure 1




Dimensions mm (in.)

STT90x (automatic reset)



STT91x (manual reset)



North America (USA): +1 888 444 1311
Europe, Middle East & Africa (Sweden): +46 10 478 2000
Asia Pacific (Singapore): +65 6484 7877
product.support@schneider-electric.com
www.schneider-electric.com

