

A large red graphic on the left side of the page, consisting of four downward-pointing chevrons stacked vertically, creating a jagged, arrow-like shape.

**Power Distribution
Unit (PDU)**

AP7620

AP7621

AP7622

AP7626

User's Manual

APC[®]



This manual is available in English on the enclosed CD.



Dieses Handbuch ist in Deutsch auf der beiliegenden
CD-ROM verfügbar.



Este manual está disponible en español en el CD-ROM
adjunto.



Ce manuel est disponible en français sur le CD-ROM
ci-inclus.



Questo manuale è disponibile in italiano nel CD-ROM
allegato.

Contents

Product Descriptions and Safety Information	1
Installation	6
Operation	11
Configuration	12
Downloading the Latest Firmware Revision.	17
Specifications	18
Warranty and Service	22
Life-Support Policy	24

Product Descriptions and Safety Information

Features of single-branch PDU models

This manual explains how to install and use the following Rack-mount PDUs:

PDU	Voltage	Number of Outlets	Outlet Type
AP7620	100–120 VAC	24	NEMA 5-20R
AP7622	200–240 VAC	6	NEMA L6-20R
AP7621 AP7626	200–240 VAC	25	21 outlets of type IEC 320 C13 4 outlets of type IEC 320 C19

All the PDUs distribute input power from a single source to the PDU outlets for use by connected equipment and provide current-sensing to guard against overload conditions.

Safety information

In all applications, the plug on the power supply cord is the means to disconnect the PDU. The receptacle (outlet) into which the PDU is plugged must be installed near the connected equipment and must be easily accessible.




Note

In 208 and 230 VAC applications, the PDU relies on the building installation for over-current and short-circuit current protection.

You must connect the PDU to a branch circuit that is rated as follows:


- 20 amps, 250 volts (in accordance with NFPA 70) in 208 VAC applications.
- 16 amps, 250 volts in 230 VAC applications.

120V PDU




- ❶ Rack-mount PDU (AP7620)
- ❷ Display interface
- ❸ NEMA 5-20R outlets (24)
- ❹ Cord retainer holes
- ❺ NEMA L5-20 power cord
- ❻ Serial cable
- ❼ Cord retainer

208V PDU




- ❶ Rack-mount PDU (AP7622)
- ❷ Display interface
- ❸ NEMA L6-20R outlets (6)
- ❹ NEMA L6-20 power cord
- ❺ Serial Cable

**230V PDU with
IEC 320 C20
power cord**



- ❶ Rack-mount PDU (AP7621)
- ❷ IEC C13 outlets (21)
- ❸ IEC C19 outlets (4)
- ❹ Display interface
- ❺ Cord retainer holes
- ❻ IEC 320 C20 power cord
- ❼ Serial cable
- ❽ Cord retainers (21 short, for use at the C13 outlets; 4 long, for use at the C19 outlets)

**230V PDU with
NEMA L6-20
power cord**



- ❶ Rack-mount PDU (AP7626)
- ❷ IEC C13 outlets (21)
- ❸ IEC C19 outlets (4)
- ❹ Display interface
- ❺ Cord retainer holes
- ❻ NEMA L6-20 power cord
- ❼ Serial cable
- ❽ Cord retainers (21 short, for use at the C13 outlets; 4 long, for use at the C19 outlets)

Installation

Mounting options

You can install Rack-mount PDUs in one of two ways: using toolless mounting pegs or the mounting brackets. You mount the Rack-mount PDUs in the rear of the enclosure, in the channel directly behind the rear vertical mounting rails. Before you begin to install the Rack-mount PDUs, choose a location for them in the enclosure and decide on the mounting method.

**Toolless
mounting**

1. Decide where to mount the PDU and whether the power cord will be at the upper or lower end of the PDU.

Make sure that the power cord can reach an outlet easily, does not interfere with other equipment, and does not bend sharply.




- In a PowerStruXure Type A system, you **must** mount the PDU so that its power cord is at the lower end.
- In any system, if you orient the PDU so that the power cord is at the lower end, **do not** mount the PDU in the lowest position possible in the enclosure.

2. Slide the mounting pegs into a set of holes in the channel

in the rear panel of the enclosure.


3. Push the PDU downward until it locks into position.




Bracket-mounting

You can order a rack-mount bracket kit from APC—AR8116BLK. The brackets attach to the Rack-mount PDU in two different directions, shown in the figures in step 1. Consider the orientation of the Rack-mount PDU in the enclosure before attaching the brackets. A recessed orientation allows the Rack-mount PDU to be mounted flush with the enclosure; a raised orientation allows you to route cables through the channel (see the figures in step 2).

1. Attach two brackets to the rear of the Rack-mount PDU, using six pan-head screws (provided in the bracket kit) for each bracket.
 - Recessed Orientation




- Raised Orientation




2. Insert one mounting screw (provided with the bracket kit) in the top and bottom positions in the channel where the

brackets align with the holes. Tighten to secure the Rack-mount PDU to the enclosure.

– Recessed Orientation




– Raised Orientation



Operation

Rack-mount PDU display interface



1	Control Button	To view the orientation of the LED display, press and hold the button for 5 seconds To change the orientation, hold the button for an additional 5 seconds until "AA" flashes and then changes orientation. To silence an alarm, press the button.
2	LED display	Displays the current that is drawn by the load equipment.
3	Serial Port	Provides the connection to access the internal configuration menus.
4	Line LED	Alerts you to warning and alarm conditions: <ul style="list-style-type: none"> • normal: green • warning: yellow • alarm: red

Configuration

Using a serial port connection

1. Connect an available serial port of your computer to the serial port on the front panel of the PDU, using the supplied serial cable.
2. Run a terminal emulation program such as Windows® HyperTerminal.
3. Configure the following settings for the serial port:
 - 19,200 bps
 - no parity
 - 8 data bits
 - 1 stop bit
 - no flow control



Note

Some terminal emulation programs require that a device be disconnected and then reconnected for the new serial port settings to take effect.

4. Press any key on the computer to display the PDU login screen, which contains the **Username** and **Password** prompts.
5. Log on by using the user name and password for the appropriate access level:

Access Level	Default User Name	Default Password
Administrator	Press ENTER.	Type apc (in lowercase).
User	Press ENTER.	Press ESC.

Access to menus When you log in as User, you can view information but cannot configure settings or enter data.

When you log in as Administrator, you can view information, configure settings, and enter data. Any changes take effect immediately.

To navigate the menus and their options, type the number of the selection you want, and press ENTER.

Main menu

Menu Number	Option Name	Access
1	Status Information	Administrator and User
2	Metered Rack-Mount PDU Configuration	Administrator and User
3	Device Data	Administrator and User
4	Factory Data	Administrator and User
5	Logout	Administrator and User
6	System Management	Administrator only (The menu is not displayed when you are logged on as User)

Status Information option

Choosing this option displays the following information about the PDU.

- The current in amps
- The status (whether it is within the configured limits for output current or has reached or exceeded those limits).

This option includes no items configurable through this screen.

Metered Rack-Mount PDU Configuration option

Choosing this option displays the following additional options.

Option Number	Option Name	Access
1	Warning and Alarm Threshold Data	Administrator has configuration access.
2	Audio/Visual Indicator Settings	User has display access only. <ul style="list-style-type: none">• Type 1 and press ENTER to move to the next item• Type 2 and press ENTER to change the item.

Device Data option

Choosing this option displays the following information:

Item	Definition	Access
Product Name	The name of the product, such as Rack-mount PDU.	Administrator has configuration access. <ul style="list-style-type: none"> • Type 1 and press ENTER to move to the next item • Type 2 and press ENTER to change the item. User has display access only.
Product Location	Where this PDU is located, such as Rack 4.	
Contact Information	Whom to contact about this PDU.	
Log Timeout (mins)	The number of minutes of inactivity that is permitted before you are logged out automatically.	
Admin Password	The password required to log on as Administrator. When logged on as User, you can not view this password.	

Factory Data option

Choosing this option displays the following information about the PDU.

- The model number
- The serial number
- The hardware revision
- The date of manufacture
- The firmware revision
- The date the firmware was installed.

This option includes no configurable items.

System Management option

Choosing this option displays the following additional options

Menu Number	Menu Name	Definition	Access
1	Restart RMPDU	Restart the PDU, using the parameters that are currently configured.	This menu option is displayed only if you are logged on as Administrator.
2	Restore Parameters and Restart	Restart the PDU, using the default values for all parameters.	
3	Firmware Download	Prepare to download new firmware	

Downloading the Latest Firmware Revision

How to download firmware to a Rack-mount PDU



Note

During firmware downloads, power will not be interrupted to the PDU outlets.

1. Go to www.apcc.com/tools/download/, and check to see if there is a version of firmware for your type of Rack-mount PDU later than the version you are currently using.
2. Access the PDU internal menus through a serial port connection.



See “Using a serial port connection” on page 12.

3. Log on to the Rack-mount PDU as an Administrator.
4. Type 6 (for **System Management**) on the Main menu and press ENTER.
5. Type 3 (for **Firmware Download**) on the **System Management** menu, and press ENTER.
6. From the **Firmware Download** menu:
 - a. Type 1 and press ENTER to initiate a download. The menu displays C repeatedly and the display interface displays dL.
 - b. Select the **Transfer** pull-down menu from the menu bar.
 - c. Select **Send File** from the **Transfer** pull-down menu.
 - d. Browse for and select the firmware file you copied to your computer.
 - e. Set the protocol to **Xmodem** and press the **Send** button.

When the firmware download is complete, the display interface refreshes and displays the current in amps.

Specifications

AP7620

Electrical Specifications	
Input	100–120 V; 50–60 Hz; 16 A
Output	100–120 V; 50–60 Hz; 16 A
Physical Specifications	
Dimensions	1.75 × 3.5 × 48 in 4.5 × 8.9 × 121.9 cm
Weight	11.75 lb 5.3 kg
Shipping dimensions	3.75 × 5.0 × 60 in 9.5 × 12.7 × 152.4 cm
Shipping weight	15.0 lb (6.8 kg)
Operating temperature	23 to 113° F (-5 to 45° C)
Operating humidity	5–95% RH non-condensing
Operating elevation	10,000 ft (3000 m) above MSL
Storage temperature	-13 to 149° F (-25 to 65° C)
Storage humidity	5–95% RH non-condensing
Compliance Specifications	
Approvals	UL, cUL, FCC, VCCI

AP7621

Electrical Specifications	
Input	200–240 V; 50–60 Hz; 16 A
Output	200–240 V; 50–60 Hz; 10 A (IEC C13 outlets); 16 A (IEC C19 outlets)
Physical Specifications	
Dimensions	1.75 × 3.5 × 48 in 4.5 × 8.9 × 121.9 cm
Weight	13.0 lb 5.9 kg
Shipping dimensions	3.75 × 5.0 × 60 in 9.5 × 12.7 × 152.4 cm
Shipping weight	14.5 lb (6.6 kg)
Operating temperature	23 to 113° F (-5 to 45° C)
Operating humidity	5–95% RH non-condensing
Operating elevation	10,000 ft (3000 m) above MSL
Storage temperature	-13 to 149° F (-25 to 65° C)
Storage humidity	5–95% RH non-condensing
Compliance Specifications	
Approvals	VDE, CE, VCCI

AP7622

Electrical Specifications	
Input	200–240 V; 50–60 Hz; 16 A
Output	200–240 V; 50–60 Hz; 16 A
Physical Specifications	
Dimensions	1.75 × 3.5 × 48 in 4.5 × 8.9 × 121.9 cm
Weight	14.0 lb 6.4 kg
Shipping dimensions	3.75 × 5.0 × 60 in 9.5 × 12.7 × 152.4 cm
Shipping weight	15.5 lb 7.0 kg
Operating temperature	23 to 113° F (-5 to 45° C)
Operating humidity	5–95% RH non-condensing
Operating elevation	10,000 ft (3000 m) above MSL
Storage temperature	-13 to 149° F (-25 to 65° C)
Storage humidity	5–95% RH non-condensing
Compliance Specifications	
Approvals	UL, cUL, FCC, VCCI

AP7626

Electrical Specifications	
Input	200–240 V; 50–60 Hz; 16 A
Output	200–240 V; 50–60 Hz; 10 A (IEC C13 outlets); 16 A (IEC C19 outlets)
Physical Specifications	
Dimensions	1.75 × 3.5 × 48 in 4.5 × 8.9 × 121.9 cm
Weight	13.0 lb 5.9 kg
Shipping dimensions	3.75 × 5.0 × 60 in 9.5 × 12.7 × 152.4 cm
Shipping weight	14.5 lb (6.6 kg)
Operating temperature	23 to 113° F (-5 to 45° C)
Operating humidity	5–95% RH non-condensing
Operating elevation	10,000 ft (3000 m) above MSL
Storage temperature	-13 to 149° F (-25 to 65° C)
Storage humidity	5–95% RH non-condensing
Compliance Specifications	
Approvals	UL, cUL, FCC, VCCI

Warranty and Service

Limited warranty

APC warrants the Power Distribution Unit to be free from defects in materials and workmanship for a period of two years from the date of purchase. Its obligation under this warranty is limited to repairing or replacing, at its own sole option, any such defective products. This warranty does not apply to equipment that has been damaged by accident, negligence, or misapplication or has been altered or modified in any way. This warranty applies only to the original purchaser.

Warranty limitations

Except as provided herein, APC makes no warranties, express or implied, including warranties of merchantability and fitness for a particular purpose. Some jurisdictions do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

Except as provided above, in no event will APC be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of this product, even if advised of the possibility of such damage.

Specifically, APC is not liable for any costs, such as lost profits or revenue, loss of equipment, loss of use of equipment, loss of software, loss of data, costs of substitutes, claims by third parties, or otherwise. This warranty gives you specific legal rights and you may also have other rights, which vary according to jurisdiction.

Obtaining service

To obtain support for problems with your Power Distribution Unit:

1. Note the serial number and date of purchase. The serial number is on a label on the back of the PDU.
2. Contact Customer Support at a phone number on the back cover of this document. A technician will try to help you solve the problem by phone.
3. If you must return the product, the technician will give you a return material authorization (RMA) number. If the warranty expired, you will be charged for repair or

replacement.

4. Pack the unit carefully. The warranty does not cover damage sustained in transit. Enclose a letter with your name, address, RMA number and daytime phone number; a copy of the sales receipt; and a check as payment, if applicable.
5. Mark the RMA number clearly on the outside of the shipping carton.
6. Ship by insured, prepaid carrier to the address provided by the Customer Support technician.

Life-Support Policy

General policy

American Power Conversion (APC) does not recommend the use of any of its products in the following situations:

- In life-support applications where failure or malfunction of the APC product can be reasonably expected to cause failure of the life-support device or to affect significantly its safety or effectiveness.
- In direct patient care.

APC will not knowingly sell its products for use in such applications unless it receives in writing assurances satisfactory to APC that (a) the risks of injury or damage have been minimized, (b) the customer assumes all such risks, and (c) the liability of American Power Conversion is adequately protected under the circumstances.

Examples of life-support devices

The term *life-support device* includes but is not limited to neonatal oxygen analyzers, nerve stimulators (whether used for anesthesia, pain relief, or other purposes), autotransfusion devices, blood pumps, defibrillators, arrhythmia detectors and alarms, pacemakers, hemodialysis systems, peritoneal dialysis systems, neonatal ventilator incubators, ventilators (for adults and infants), anesthesia ventilators, infusion pumps, and any other devices designated as “critical” by the U.S. FDA.

Hospital-grade wiring devices and leakage current protection may be ordered as options on many APC UPS systems. APC does not claim that units with this modifications are certified or listed as hospital-grade by APC or any other organization. Therefore these units do not meet the requirements for use in direct patient care.

Radio Frequency Interference



Warning

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with this user manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference. The user will bear sole responsibility for correcting such interference.

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.



APC Worldwide Customer Support

Customer support for this or any other APC product is available at no charge in any of the following ways:

- Visit the APC Web site to find answers to frequently asked questions (FAQs), to access documents in the APC Knowledge Base, and to submit customer support requests.
 - **www.apc.com** (Corporate Headquarters)
Connect to localized APC Web sites for specific countries, each of which provides customer support information.
 - **www.apc.com/support/**
Global support with FAQs, knowledge base, and e-support.
- Contact an APC Customer Support center by telephone or e-mail.
 - Regional centers:

APC headquarters U.S., Canada	(1)(800)800-4272 (toll free)
Latin America	(1)(401)789-5735 (USA)
Europe, Middle East, Africa	(353)(91)702020 (Ireland)
Japan	(03)5434-2021 Guidance 3

- Local, country-specific centers: go to **www.apc.com/support/contact** for contact information.

Contact the APC representative or other distributor from whom you purchased your APC product for information on how to obtain local customer support.

Entire contents copyright © 2002 American Power Conversion. All rights reserved. Reproduction in whole or in part without permission is prohibited. APC, the APC logo, and PowerStruXure are trademarks of American Power Conversion Corporation and may be registered in some jurisdictions. All other trademarks, product names, and corporate names are the property of their respective owners and are used for informational purposes only.