

NetBotz 0-5V Sensor Cable

Thank you for purchasing this NetBotz 0-5V Sensor Cable. This cable enables you to connect a single 0-5V sensor to your NetBotz appliance. With this cable you can now use many standard 0-5V sensors as external NetBotz sensors.

The NetBotz 0-5V Sensor Cable package includes the following items:

- The NetBotz 0-5V Sensor Cable



Note

If the cable is not long enough, use an Extension Cable for External Sensors (available in 50' and 100' lengths from your NetBotz reseller) to lengthen the cable.

- This flyer

Installation

To use your NetBotz 0-5V Sensor Cable, connect the two wire leads at the end of the NetBotz 0-5V Sensor Cable to the 0-5V sensor. Use the instructions included with your sensor to determine the proper wiring for the sensor.

Then, connect the other end of the NetBotz 0-5V Sensor Cable to an External Sensor port on your NetBotz appliance or on a Sensor Pod 120.



Note

Be sure to note the number of the External Port when you connect the cable; you will need it when you configure your NetBotz appliance to use the sensor. The External Port number is printed above the port on the appliance or pod.

When you have finished installing, use the Advanced View to configure the NetBotz appliance to use the 0-5V sensor. Once you have configured your appliance you will be able to use the Advanced View to specify the conditions that will cause this sensor to generate a NetBotz alert notification. For more information, refer to the documentation that came with your appliance.

