

Thank you for purchasing an INV-APP-500 ihiji invisision monitoring appliance.

This new low-cost, energy-efficient remote monitoring and support hardware appliance installs in just minutes and enables the cloud based portal to communicate with your client sites. No network configuration of the device is necessary.

Check The Contents Of The Box

1. INV-APP-500 Monitoring Appliance
2. Ethernet Cable
3. Quick Start Guide

Onsite Setup

1



Plug one end of the Ethernet cable into the INV-APP-500 Ethernet port

2



Plug the other end of the Ethernet cable into a LAN port on the back of the router

3



Plug the INV-APP-500 into a power outlet
(Note: AC Input - 100-240 V_{AC}, 50/60Hz)

(Please Detach and Retain for reference)
Final Setup (Can Be Done Offsite)

4

Go to the invisision portal to continue setup:
<https://invisision.ihiji.com>
You can access "Getting Started" and other support resources at <http://support.ihiji.com>

Support and additional instructions:

- Dealer Support Portal: <http://support.ihiji.com>
- Support Phone: 512-538-0520

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IMPORTANT SAFETY INFORMATION



CAUTION ELECTRIC SHOCK HAZARD

- Install in accordance with manufacturer's instructions.
- Do not use this device near or in water.
- Maintain a minimum distance of at least 6 inches around device for sufficient ventilation.
- This device should be clear of items such as newspapers, table cloth, curtains, etc.
- No open flame sources, such as lighted candles, should be placed on or near the device
- Do not install near any heat sources such as radiators, heat registers, stoves, or other devices that produce heat
- Protect the network cable from being worked on or pinched particularly at plugs, convenience receptacles, and the point where they exit at the apparatus.
- Only use attachment/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel. Servicing is required when the device has been damaged in any way, such as network adapter or cable is damaged, liquid has been spilled or objects have been into device, the device has been exposed to rain or moisture, does not operate normally, or has been dropped.

NOTE: To comply with electromagnetic compatibility (EMC) requirements, a ferrite core must be installed on the Ethernet cable and USB cable.

(Please Detach and Retain for reference)



Site Name: _____

Site Key

PLACE KEY STICKER HERE

Serial Number

PLACE SERIAL NUMBER STICKER HERE